



Interface Unit CC-Link for EJ Counter



User's Manual - Instructions for use -

Read this document thoroughly before operating the product. After reading, retain it close at hand for future reference.

This English language version of the document contains the original instructions.

- For the related User's Manuals, see "■ Positioning of this document, document map" on page 1".

No. 99MBC141A2
Date of publication: January 1, 2023



■ Product names and model numbers covered in this document

● Product name

| | |
|--------------|---------------------------------------|
| Product name | Interface Unit CC-Link for EJ Counter |
|--------------|---------------------------------------|

■ Notice regarding this document

- Mitutoyo Corporation assumes no responsibilities for any damage to the product, caused by its use not conforming to the procedure described in this document.
- In the event of loss or damage to this document, immediately contact the agent where you purchased the product or a Mitutoyo sales office.
- Read this document thoroughly before operating the product. In particular, be sure to fully understand "Safety Precautions" on page 6 and "Precautions for Use" on page 6.
- The contents of this document are based on information current as of January 2024.
- No part or whole of this document may be transmitted or reproduced by any means without prior written permission of Mitutoyo Corporation.
- Some screen displays in this document may be highlighted, simplified or partially omitted for convenience of explanation. In addition, some of them may differ from actual ones to the extent that no user will misunderstand the functions and operations.
- The corporation, organization and product names that appear in this document are their trademarks or registered trademarks.

©2020-2024 Mitutoyo Corporation. All rights reserved.

Contents

| | |
|--|---------------|
| Contents | i |
| About This Document | 1 |
| Conventions Used in This Document | 3 |
| Safety Precautions | 6 |
| Precautions for Use | 6 |
| Electromagnetic Compatibility (EMC) | 8 |
| Export Control Compliance | 8 |
| Notes on Export to European Countries | 8 |
| Disposal of Products outside the European Countries | 8 |
| Disposal of Old Electrical & Electronic Equipment (Applicable in the European Countries with Separate Collection Systems) | 9 |
| China RoHS Compliance Information | 9 |
| Warranty | 10 |
| Disclaimer | 10 |
| 1 Overview | 11 |
| 1.1 Main Functions and Features | 12 |
| 1.2 System Configuration | 13 |
| 1.3 Part Names | 14 |
| 1.3.1 Main Unit | 14 |
| 1.3.2 Front Panel | 15 |
| 1.4 Standard Accessories | 16 |
| 1.5 Operation Flow | 18 |
| 2 Setup | 19 |
| 2.1 Mounting | 20 |
| 2.1.1 DIN Rail Attachment / Removal | 20 |
| 2.1.2 Linking to EJ Counters | 21 |
| 2.1.3 Attaching the DIN Rail Fixing Bracket | 22 |
| 2.2 Connection of External Devices | 24 |
| 2.2.1 USB Connection | 24 |
| 2.2.2 CC-Link Connection | 25 |

| | | |
|------------------------------|---|--------------|
| 2.3 | Power Supply Connection | 29 |
| 2.3.1 | Ground Connection | 29 |
| 2.3.2 | Power ON/OFF | 30 |
| 3 | USB Communication | 31 |
| 3.1 | USB Specifications | 32 |
| 3.2 | USB Communication Format | 33 |
| 3.2.1 | ID Number Assignment During USB Communication | 33 |
| 3.2.2 | Send and Receive Data Format | 34 |
| 3.2.3 | List of Commands | 36 |
| 3.3 | List of USB Communication Errors | 40 |
| 3.3.1 | Interface Unit Communications Error Flags | 40 |
| 3.3.2 | EJ Counter Error Flags | 41 |
| 3.4 | Tolerance Judgment Result..... | 44 |
| 4 | CC-Link Communication | 45 |
| 4.1 | Outline of CC-Link Communication | 46 |
| 4.2 | CC-Link Communication Settings | 47 |
| 4.2.1 | Communications Settings | 47 |
| 4.2.2 | Verifying Communication..... | 47 |
| 4.3 | CC-Link Communication Format | 49 |
| 4.3.1 | ID Number Assignment during CC-Link Communication | 49 |
| 4.3.2 | Input/Output Allocation | 50 |
| 4.3.3 | List of Commands | 60 |
| 4.4 | CC-Link Communication Errors | 65 |
| 4.4.1 | EJ Counter Error Flags | 65 |
| 4.5 | Tolerance Judgment Result..... | 66 |
| 4.6 | Communication Response Time | 67 |
| 5 | EJ Counter Parameter Settings | 69 |
| 6 | Troubleshooting | 75 |
| 7 | Specifications | 79 |
| 7.1 | Basic Specifications | 79 |
| 7.2 | Communication Specification | 80 |
| 7.2.1 | USB Communication | 80 |
| 7.2.2 | CC-Link Communication | 80 |
| 7.3 | Outline Dimensional Drawing | 82 |
| SERVICE NETWORK | | App-1 |

About This Document

■ Positioning of this document, document map

The position of this document and its relationship to other product documentation are as follows.

● Interface unit manual

Interface Unit
Quick Start Guide

Explains setup, specifications and troubleshooting.
This document is included in the product package together with the Interface Unit.
(Common to all interface unit models)

Interface Unit CC-Link
User's Manual
(This Document)

This is the User's Manual that explains the Interface Unit CC-Link in detail.

● Counter manual

EJ Counter
Quick Start Guide

Covers handling precautions, operating procedures, specifications, troubleshooting for EJ Counters to which the Interface Unit CC-Link is connected for use. For details, see EJ Counter User's Manual. This document is included in the product package together with the EJ Counter.

EJ Counter
User's Manual

This is the User's Manual that provides a detailed explanation of the EJ Counter that is connected to the Interface Unit CC-Link.
Not included with product. Please download the manual from Mitutoyo's web site (<https://manual.mitutoyo.co.jp>).

● Linear Gage manual

LG100
User's Manual

Covers installation procedures, specifications, maintenance and so forth for Linear Gages that can be connected to EJ Counters.

Select and purchase Linear Gages according to your application.

LG200
User's Manual

LGB
User's Manual

■ Intended readers and purpose of this document

● Intended readers



This manual is intended for customers who are installing or using the Interface Unit CC-Link for EJ Counter for the first time.

● Purpose




The purpose of this document is to help you understand the product overview, functions of each part, procedures for use and care of the product.

Conventions Used in This Document



■ Safety reminder conventions warning against potential hazards

| | |
|--|--|
|  CAUTION | Indicates a hazard with a low level of risk which, if not avoided, could result in minor or moderate injury . |
|  NOTICE | Indicates a situation which, if not avoided, may result in property damage . |

■ Conventions indicating prohibited and mandatory actions

| | |
|--|--|
|  | Indicates concrete information about prohibited actions. |
|  | Indicates concrete information about mandatory actions. |
|  | Indicates that grounding needs to be implemented. |

■ Conventions indicating referential information or reference location

| | |
|---|---|
| IMPORTANT | Indicates information that must be known when using the product. |
| Tips | Indicates further information and details relevant for the operating methods and procedures that are explained in that section. |
|  | Indicates reference location if there is information that should be referred to in this document or an extraneous User's Manual. Example: For details about XX, see  "1.3 Part Names" on page 14 in "1 Overview". |

■ Other conventions

| | |
|------------------------------------|--|
| (): Round brackets | Represent a paraphrase of an immediately preceding phrase or a supplementary explanation. |
| " ": Double quotation marks | Represent a highlighted phrase. They also indicate an index where information to be referenced is described. |
| []: Square brackets | Indicates the name of an operation key. |
| 1, 2, 3 | Indicates the order and the contents of tasks. |
| » | Indicates the action resulted from some operation(s). |

■ Example of conventions use

2 Setup


2.1.2 Linking to EJ Counters

Link this product to EJ Counters.
Up to eight EJ Counters can be linked to this product.

Tips
The interface unit is intended for use with the EJ-102N (Code No. 542-080) and EJ-102NE (Code No. 542-081) EJ Counters. These two types of EJ Counters can be used in mixed configurations.

- 1 Remove the protective covers from the counter linkage connectors of this product and the EJ Counter.
- 2 Attach this product to the DIN rail on the side facing the EJ Counter's counter linkage connector (male).

Tips
For details, see ■ "2.1.1 DIN Rail Attachment / Removal" on page 20.

- 3 Link the product to the EJ Counter.
Slide the product or EJ Counter along the DIN rail to fully mate the counter linkage connector on the product (female) with the counter linkage connector (male) on the EJ Counter.


NOTICE
Do not link more than eight EJ Counters together. Failure to observe this precaution may result in damage.

IMPORTANT
When sliding this product or EJ Counters along the DIN rail, move them slowly.

21

No. 99MBC141A

Indicates an operating procedure to be performed or its outline.

Indicates reference to some other document or section.

Indicates safety information.

Indicates important information that must be known when using the product.

Safety Precautions

Read these "Safety Precautions" thoroughly before operating the product to use it properly. These safety precautions include such information as to prevent injury to the operator and other persons, damage to property and product defects. Be sure to observe these precautions carefully.

■ Precautions for this product

CAUTION



Do not disassemble or modify this product. Otherwise you may be subject to electric shock, and there is a risk of fire due to a short circuit caused by metallic powders that have gotten inside the product.

Precautions for Use

■ Use and handling of the product

- Use this product only by connecting to measuring instruments which supports this product.

Do not use this product for measuring instruments which does not support this product.

For measuring instruments supported by this product, contact the agent where you purchased the product or a Mitutoyo sales office.

- This product is a measuring instrument.

Do not use it for any purposes other than measuring.

- This product is for industrial usage.

Do not use this product for purposes other than for industrial usage.

- The product is a precision instrument.

Handle this product with care. Do not apply excessive shock or force to any of the parts during operation.

■ Environment for placement

This product is designed for indoor use. To ensure that the product is used in a suitable environment, take the following conditions into account when installing it.

- **Vibration**
Install this product in an environment where it will be subject to minimal vibration. Using this product in a place with significant vibration for an extended period of time may result in malfunction of the precision components.
- **Dust**
Dust in the installation site negatively affects the electrical components. Install this product in an environment where it will be subject to minimal dust.
- **Sunlight**
If this product is exposed to direct sunlight, the heat will cause deformations in the main unit, negatively affecting its operation. If installing this product in an environment that is exposed to direct sunlight, such as near a window, is unavoidable, protect it from the sunlight by curtaining it off, etc.
- **Ambient temperature and humidity**
Avoid using the product in any place that is subject to sudden changes in temperature or humidity.

When using this product in the following environments, take necessary shielding measures.

- Where noise is generated due to static electricity, etc.
- Where there is strong electrical field intensity
- Where power wires and motor lines pass nearby
- Where there is risk of direct contact with materials such as chips, cutting fluids or water
- Where there is risk of exposure to radiation
- Where there is the risk of exposure to corrosive gas

■ Maintenance

Do not use organic solvents such as thinner or benzene. Gently wipe dirt off of the product with a soft, tightly woven cloth.

■ Power supply

Be sure to connect this product to ground.

Provide a power supply with capacity sufficient to accommodate switch-on surge current.

Tips

This product is supplied with power by the connected EJ Counter.

Electromagnetic Compatibility (EMC)

This product complies with the EMC Directive and the UK Electromagnetic Compatibility Regulations; however, if this receives electromagnetic interference that exceeds these requirements, it will be out of warranty and require appropriate measures.

This product is an industrial product, and is not intended to be used in residential environment. If this product is used in residential environment, this product may cause electromagnetic interference with other instruments. In such a case, it is required to take appropriate measures for preventing such electromagnetic interference.

Export Control Compliance

This product falls into the Catch-All-Controlled Goods and/or Catch-All-Controlled Technologies (including Programs) under Category 16 of Appended Table 1 of Export Trade Control Order or under Category 16 of Appended Table of Foreign Exchange Control Order, based on Foreign Exchange and Foreign Trade Act of Japan.

If you intend re-export of the product from a country other than Japan, re-sale of the product in a country other than Japan, or re-providing of the technology (including Programs), you shall observe the regulations of your country.

Also, if an option is added or modified to add a function to this product, this product may fall under the category of List-Control Goods, List-Control Technology (including Programs) under Category 1 - 15 of Appended Table 1 of Export Trade Control Order or under Category 1 - 15 of Appended Table of Foreign Exchange Control Order, based on Foreign Exchange and Foreign Trade Act of Japan. In that case, if you intend re-export of the product from a country other than Japan, re-sale of the product in a country other than Japan, or re-providing of the technology (including Programs), you shall observe the regulations of your country. Please contact Mitutoyo in advance.

Notes on Export to European Countries

When you intend exporting of this product to any of the European countries, it may be required to provide User's Manual(s) in English and Declaration of Conformity in English (in some cases, the official language of the country to be exported). For detailed information, please contact Mitutoyo in advance.

Disposal of Products outside the European Countries

Please follow the official instruction in each community and country.

Disposal of Old Electrical & Electronic Equipment (Applicable in the European Countries with Separate Collection Systems)



This symbol on the product or on its packaging is based on WEEE Directive (Directive on Waste Electrical and Electronic Equipment), and this symbol indicates that this product shall not be treated as household waste.



To reduce the environmental impact and minimize the volume of landfills, please cooperate in reuse and recycle.

For how to dispose of the product, please contact the agent where you purchased the product or a Mitutoyo sales office.

China RoHS Compliance Information

This product meets China RoHS requirements. See the table below.

产品中有害物质的名称及含量

| 部件名称 | 有害物质 | | | | | |
|------|------|------|------|----------|-------|--------|
| | 铅 | 汞 | 镉 | 六价铬 | 多溴联苯 | 多溴二苯醚 |
| | (Pb) | (Hg) | (Cd) | (Cr(VI)) | (PBB) | (PBDE) |
| 本体 | × | ○ | ○ | ○ | ○ | ○ |
| 配件 | ○ | ○ | ○ | ○ | ○ | ○ |

本表格依据 SJ/T 11364 的规定编制。

○: 表示该有害物质在该部件所有均质材料中的含量均在 GB/T 26572 规定的限量要求以下。

×: 表示该有害物质至少在该部件的某一均质材料中的含量超出 GB/T 26572 规定的限量要求。



环保使用期限标识是根据《电器电子产品有害物质限制使用管理办法》以及《电子电气产品有害物质限制使用标识要求(SJ/T11364—2014)》制定的,适用于中国境内销售的电子电气产品的标识。

电器电子产品只要按照安全及使用说明内容在正常使用情况下,从生产日期算起,在此期限内产品中含有的有毒有害物质不致发生外泄或突变,不致对环境造成严重污染或对其人身、财产造成严重损害。

产品使用后,要废弃在环保使用年限内或者刚到年限的产品,请根据国家标准采取适当的方法进行处置。

另外,此期限不同于质量/功能的保证期限。

Warranty

This product has been manufactured under strict quality management, but should it develop problems within one year of the date of purchase in normal use, repair shall be performed free of charge. Please contact the agent where you purchased the product or Mitutoyo sales representative (☎ "SERVICE NETWORK" on page App-1).

If this product fails or is damaged for any of the following reasons, it will be subject to a repair charge, even if it is still under warranty.

- Failure or damage owing to fair wear and tear
- Failure or damage owing to inappropriate handling, maintenance or repair, or to unauthorized modification
- Failure or damage owing to transport, dropping, or relocation of the product after purchase
- Failure or damage owing to fire, salt, gas, abnormal voltage, lightning surge, or natural disaster
- Failure or damage owing to use in combination with hardware or software other than those designated or permitted by Mitutoyo
- Failure or damage owing to use in ultra-hazardous activities

This warranty is effective only where the product is properly installed and operated in conformance with the instructions in this document within the original country of the installation.

EXCEPT AS SPECIFIED IN THIS WARRANTY, ALL EXPRESS OR IMPLIED CONDITIONS, REPRESENTATIONS, AND WARRANTIES OF ANY NATURE WHATSOEVER INCLUDING, WITHOUT LIMITATION, ANY IMPLIED WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, NONINFRINGEMENT OR WARRANTY ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE, ARE HEREBY EXCLUDED TO THE MAXIMUM EXTENT ALLOWED BY APPLICABLE LAW.

You assume responsibility for all results due to the selection of this product to achieve your intended results.

Disclaimer

IN NO EVENT WILL MITUTOYO, ITS AFFILIATED AND RELATED COMPANIES AND SUPPLIERS BE LIABLE FOR ANY LOST REVENUE, PROFIT, OR DATA, OR FOR SPECIAL, DIRECT, INDIRECT, CONSEQUENTIAL, INCIDENTAL, OR PUNITIVE DAMAGES HOWEVER CAUSED AND REGARDLESS OF THE THEORY OF LIABILITY ARISING OUT OF THE USE OF OR INABILITY TO USE THIS PRODUCT EVEN IF MITUTOYO OR ITS AFFILIATED AND RELATED COMPANIES AND/OR SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

If, notwithstanding the foregoing, Mitutoyo is found to be liable to you for any damage or loss which arises out of or is in any way connected with use of this product by you, in no event shall Mitutoyo's and/or its affiliated and related companies' and suppliers' liability to you, whether in contract, tort (including negligence), or otherwise, exceed the price paid by you for the product only.

The foregoing limitations shall apply even if the above-stated warranty fails of its essential purpose. BECAUSE SOME COUNTRIES, STATES OR JURISDICTIONS DO NOT ALLOW THE EXCLUSION OR THE LIMITATION OF LIABILITY FOR CONSEQUENTIAL OR INCIDENTAL DAMAGES, IN SUCH COUNTRIES, STATES OR JURISDICTIONS, MITUTOYO'S LIABILITY SHALL BE LIMITED TO THE EXTENT PERMITTED BY LAW.

1 Overview

This chapter describes the Interface Unit CC-Link for EJ Counter product overview, name and functions of each part.

| | | |
|-----|-----------------------------------|----|
| 1.1 | Main Functions and Features | 12 |
| 1.2 | System Configuration | 13 |
| 1.3 | Part Names | 14 |
| 1.4 | Standard Accessories | 16 |
| 1.5 | Operation Flow | 18 |

1.1 Main Functions and Features

This product is an interface unit for use with the EJ Counter.


- This is a compact and space-saving interface unit, which is attached to a DIN rail to be used.
- It supports USB and CC-Link communication. It is compatible with CC-Link Ver. 1.10 and Ver. 2.00. Output content available differs depending on the version.
- Linear Gage measurements read by the EJ Counter can be output by USB or CC-Link Ver. 2.00 to external devices such as a PC and or PLC (programmable logic controller). Also, tolerance judgment results obtained by EJ Counters can be output by USB or CC-Link Ver. 1.10/Ver. 2.00 communication.
- The Interface Unit CC-Link can be coupled to up to eight EJ Counters, allowing data output from up to 16 Linear Gages.
- It allows EJ Counter parameter settings to be made by PC or PLC using USB or CC-Link Ver. 1.10/Ver. 2.00 communication.
- The LG QuickSetupTool application software (freeware) is used to make EJ Counter settings and display measurements using USB communication.

Tips

Please download the LG QuickSetupTool application from Mitutoyo's web site. (<https://www.mitutoyo.co.jp>)

The LG QuickSetupTool is compatible with the Windows 10 operating system. No assurance is provided of full operability in any given operating environment. While use of this application is free of charge, the user must bear communication charges incurred during download of the software.

1.2 System Configuration




IMPORTANT

Be sure to install the terminal unit.


Normal communication between this product and EJ Counters requires installation of the terminal unit.

Tips

- This product must be connected to an EJ Counter for use. It cannot be used by itself.
- For details on the EJ Counter, see  the separate "Compact Display Unit for Linear Gage EJ Counter User's Manual".
- Select and purchase Linear Gages according to your application.
- A PC and/or PLC must be provided by the customer.


1.3 Part Names

1.3.1 Main Unit













| No. | Name | Description |
|-----|---------------------------------|--|
| ① | Connector for linking counter | Connect to an EJ Counter. |
| ② | CC-Link communication connector | Connect to a CC-Link network using the provided connector plug and commercially-available CC-Link compliant cable. |
| ③ | Grounding terminal | Connect to ground using the provided ground wire. Tips <ul style="list-style-type: none">• The provided ground wire is to be used only for connecting the ground terminal on the interface unit to the ground terminal on the EJ Counter.• Overall grounding of coupled units is to be made using the ground wire provided with the EJ Counter. For details, see the separate "Compact Display Unit for Linear Gage EJ Counter User's Manual". |
| ④ | DIN rail attachment point | Used for attaching this product to a DIN rail. |



1.3.2 Front Panel



| No. | Name | Description |
|-----|------------------------|--|
| ① | [POWER] indicator | Lights when power is supplied to the unit. |
| ② | [RUN] indicator | Lights when the unit is connected to a CC-Link network. |
| ③ | [ERROR] indicator | <p>Lights or flashes to indicate a CC-Link communication error.</p> <p>Lit</p> <p>Indicates an error in setting of the CC-Link communication ([STATION No.] switch) at the time of power-on.</p> <p>Tips</p> <p>For details, see "● Station number setting" on page 27".</p> <p>Flashing</p> <p>Indicates the version or baud rate setting ([B.RATE] switch) was changed while the power was on.</p> |
| ④ | [EJ-CONNECT] indicator | <p>Lights during communication between the unit and an EJ Counter.</p> <p>Lights off or flashes to indicate an error during communication with an EJ Counter.</p> <p>Tips</p> <p>For details about when the indicator is out or flashing (when an error occurs), see "6 Troubleshooting" on page 75.</p> |
| ⑤ | USB connector (Type-C) | Allows USB connection to a PC. |
| ⑥ | [B.RATE] switch | <p>Sets the CC-Link version and baud rate.</p> <p>Tips</p> <p>For the setting procedure, see "● Setting the CC-Link version and baud rate" on page 28.</p> |
| ⑦ | [STATION No.] switches | <p>Sets the CC-Link station number. The [x10] switch sets the ten's place and the [x1] switch sets the one's place.</p> <p>Tips</p> <p>For the setting procedure, see "● Station number setting" on page 27.</p> |

1.4 Standard Accessories


| Name | Quantity | Description |
|--|----------|---|
| Connector plug (PHOENIX CONTACT 1908732 TMSTBP 2,5/ 5-STF-5,08 AU with pin assignment label)  | 1 | Connection to the unit's connector is made using this connector plug together with a cable rated for CC-Link communication. Tips For details, see  "2.2.2 CC-Link Connection" on page 25. |
| DIN rail fixing bracket  | 2 | Used to fasten the unit and EJ Counter(s) to a DIN rail. Fasten the bracket to the DIN rail using an M4 screw. Tips The screw provided with the bracket is suitable for fastening to a TH35-7.5 rail. For details, see  "2.1.3 Attaching the DIN Rail Fixing Bracket" on page 22. |
| Terminal unit  | 1 | The terminal unit is required for communication between this unit and EJ Counters. Connect it to the EJ Counter furthest from the interface unit. IMPORTANT Be sure to install the terminal unit. Normal communication between this product and EJ Counters requires installation of the terminal unit. Tips For details, see  "2.1.2 Linking to EJ Counters" on page 21. |
| Terminal resistor for CC-Link communication (Resistance: 110 Ω , 1/2 W, J)  | 1 | Attach the terminal resistor to the connector plug if the interface unit is the terminal device in the CC-Link network. Tips For details, see  "2.2.2 CC-Link Connection" on page 25. |
| Ground wire  | 1 | Use this wire to connect the ground terminal on the interface unit to the ground terminal on the EJ Counter. Tips For details, see  "2.3.1 Ground Connection" on page 29. |

| Name | Quantity | Description |
|---|----------|--|
| Clamp filter  | 1 | Attach this filter to the CC-Link cable when connecting the interface unit to a CC-Link network. Tips For details, see  "2.2.2 CC-Link Connection" on page 25. |
| Quick Start Guide | 1 | 99MBC146B |
| WEEE User's Manual | 1 | |
| Warranty | 1 | |

1.5 Operation Flow

The basic flow of operation is explained below.

Be sure to perform operations enclosed by solid lines. Perform operations enclosed by dashed lines as necessary.



2 Setup

| | | |
|-----|--------------------------------------|----|
| 2.1 | Mounting | 20 |
| 2.2 | Connection of External Devices | 24 |
| 2.3 | Power Supply Connection | 29 |

2.1 Mounting

2.1.1 DIN Rail Attachment / Removal

This product is attached to a DIN rail for use.

IMPORTANT

Attach this product to or remove it from the DIN rail a single unit at a time after first disconnecting USB cables and connector plugs.


Tips

A DIN rail must be provided by the customer.

Suitable DIN rail type names (IEC 60715): TH35-7.5Al, TH35-7.5Fe, TH35-15Fe


■ Attachment

Press the clip (gray) on the rear side of this product onto the DIN rail, and then hook the clip on the opposite side onto the DIN rail.



■ Removal

Pressing this product in the direction indicated by arrow 1, raise the clip on the opposite side so that it comes clear of the rail.



2.1.2 Linking to EJ Counters

Link this product to EJ Counters.

Up to eight EJ Counters can be linked to this product.

Tips

The interface unit is intended for use with the EJ-102N (Code No. 542-080) and EJ-102NE (Code No. 542-081) EJ Counters. These two types of EJ Counters can be used in mixed configurations.


- 1 Remove the protective covers from the counter linkage connectors of this product and the EJ Counter.**
- 2 Attach this product to the DIN rail on the side facing the EJ Counter's counter linkage connector (male).**

Tips

For details, see  "2.1.1 DIN Rail Attachment / Removal" on page 20.

- 3 Link the product to the EJ Counter.**

Slide the product or EJ Counter along the DIN rail to fully mate the counter linkage connector on the product (female) with the counter linkage connector (male) on the EJ Counter.



NOTICE

Do not link more than eight EJ Counters together. Failure to observe this precaution may result in damage.

IMPORTANT


When sliding this product or EJ Counters along the DIN rail, move them slowly.

4 Attach the provided terminal unit to the counter linkage connector (female) on the EJ Counter.

Connect the terminal unit to the EJ Counter furthest from the Interface Unit CC-Link.

IMPORTANT


Be sure to install the terminal unit. Normal communication between this product and EJ Counters requires installation of the terminal unit.




2.1.3 Attaching the DIN Rail Fixing Bracket

This product and EJ Counters are fastened to the DIN rail using the provided DIN rail fixing brackets.

1 Hook the clip that is closer to the screw hole in the fixing bracket onto the DIN rail, then press toward the opposite side and hook the other clip onto the rail.




2 Slide the fixing bracket along the DIN rail to where it comes in contact with this product.



- 3** Fasten the fixing bracket in place by threading the screw provided with the fixing bracket into the screw hole in the bracket, and then tightening the screw so that it presses against the DIN rail, immobilizing the fixing bracket.

Tips

The screw provided with the bracket is suitable for fastening to a TH35-7.5 rail.
A different screw (M4) must be used for fastening to a TH35-15 rail.



- 4** Repeat step **1** through **3** to attach the other fixing bracket also to the side with the terminal unit.

2.2 Connection of External Devices

Connection between this product and external devices such as a PC or PLC (programmable logic controller) is made by USB or CC-Link network connection.

2.2.1 USB Connection

Use a USB cable to connect the USB connector (Type-C) on the front panel of this product to a USB connector on the PC.


IMPORTANT

For permanent USB cable connection, fasten the cable so that it does not place any strain on the USB connectors.

NOTICE

This product requires a Type-C USB connector.

Note that connectors other than Type-C (such as miniB and microB) cannot be used.




2.2.2 CC-Link Connection

■ Connecting to a CC-Link network

Connect a CC-Link cable to the provided connector plug.

To connect the cable, loosen the screws on the side of the connector plug with a standard screwdriver to open the terminal holes, and then set the cable leads all the way into the terminal holes and re-tighten the screws to secure the leads.

The SLD terminal is for connecting the braided shield of the dedicated CC-Link cable, which should be twisted before connection. Cover the exposed shield with insulating tape as necessary.



| Terminal name | Insulation color, other |
|---------------|-------------------------|
| DA | Blue |
| DB | White |
| DG | Yellow |
| SLD | Shield |
| FG | N/A |

Tips

Recommended connector plugs are as follows.

- PHOENIX CONTACT 1908732 TMSTBP 2,5/ 5-STF-5,08 AU (provided)
- PHOENIX CONTACT 1876628 MSTB 2,5/ 5-STF-5,08 AU
- PHOENIX CONTACT 1916902 MVSTBR 2,5/ 5-STF-5,08 AU
- PHOENIX CONTACT 1908253 MVSTBW 2,5/ 5-STF-5,08 AU
- PHOENIX CONTACT 1962590 TFKC 2,5/ 5-STF-5,08 AU
- PHOENIX CONTACT 1945672 FK 2,5/ 5-STF-5,08 AU
- PHOENIX CONTACT 1966907 FKCT 2,5/ 5-STF-5,08 AU


A pin assignment label is affixed to the provided connector plug. However, connectors purchased by the customer will not be provided with such labels.

1 Attach the provided clamp filter.


The clamp filter should be attached at a location that is in close proximity to the connector plug on the master device end of the cable.

2 When this product is to be the terminal device in the CC-Link network, connect the provided terminal resistor for CC-Link communication (110 Ω , 1/2 W, J) across the DA and DB terminals of the connector plug.

When attaching the terminal resistor for CC-Link communication, first open the connector plug holes by loosening the terminal screws with a standard screwdriver, and then set the leads of the terminal resistor into the holes and re-tighten the screws.



3 Attach the connector plug to this product's CC-Link communication connector, and then fasten it in place by tightening the screws on the sides of the connector plug using a standard screwdriver.



■ CC-Link communication settings


Set this product's station number in the CC-Link network, the CC-Link version and the baud rate.

Tips

- Changes made to the station number, version and baud rate become effective when the product is powered on. Changes made while the product is powered on do not take effect, and will cause the [ERROR] indicator to flash.
- Turn off the power for a moment and then turn it back on again for the setting changes to take effect.

● Station number setting

Set the product's station number with the two [STATION No.] switches.



The [x10] switch sets the ten's place and the [x1] switch sets the one's place.

Using a standard screwdriver, set the switch to the desired station number.

The range of possible station number settings depends on the CC-Link version as follows:

CC-Link Ver. 1.10: 1 through 63


CC-Link Ver. 2.00: 1 through 61

Tips

Setting a number outside of range will cause the [ERROR] indicator to light when the power is turned on.

● Setting the CC-Link version and baud rate

The CC-Link version and baud rate are set using the [B.RATE] switch.



CC-Link version and baud rate settings are assigned to the various positions of the [B.RATE] switch.

Using a standard screwdriver, set the switch to the desired number.

CC-Link versions and baud rates are assigned to switch settings as follows.

| [B.RATE] switch number | CC-Link version | Baud rate |
|---------------------------|-----------------|-----------|
| 0 | Ver. 1.10 | 156 Kbps |
| 1 | | 625 Kbps |
| 2 | | 2.5 Mbps |
| 3 | | 5 Mbps |
| 4 | | 10 Mbps |
| 5 | Ver. 2.00 | 156 Kbps |
| 6 | | 625 Kbps |
| 7 | | 2.5 Mbps |
| 8 | | 5 Mbps |
| 9 | | 10 Mbps |

Tips

Content that can be output differs depending on the CC-Link version.

For details, see "4.3.2 Input/Output Allocation" on page 50.


2.3 Power Supply Connection

This section describes the power supply connection procedure.

IMPORTANT

Provide a power supply with capacity sufficient to accommodate switch-on surge current.

Tips

- Prepare for CC-Link communication by making CC-Link communication connections and settings. For details, see  "4.2 CC-Link Communication Settings" on page 47.
- This product is supplied with power by the connected EJ Counter.


2.3.1 Ground Connection

This product is grounded through the connected EJ Counter. Use the provided ground wire for connecting this product to the EJ Counter.




Be sure to connect this product to ground before connecting it to the power supply. Failure to ground the product will make it susceptible to electrical noise.


1 Remove the ground terminal screw.



2 Pass the removed terminal screw through the hole in the ground wire's ring lug, and then loosely fasten the lug to the ground terminal.




- 3 Loosen the ground terminal screw on the adjacent EJ Counter, and then slip the ground wire's fork lug under the head of the screw.



- 4 Firmly tighten the ground terminal screws on this product and the EJ Counter.
- 5 Connect the EJ Counter's ground wire.

Tips


For details on the EJ Counter's ground wire, see  the separate "Compact Display Unit for Linear Gage EJ Counter User's Manual".

2.3.2 Power ON/OFF

This product is not equipped with a power switch. It is supplied with power by the connected EJ Counter. To power the product ON/OFF, either switch the EJ Counter ON/OFF, or connect/disconnect the power cable.

When the power is turned on, an ID number is automatically assigned to the EJ Counter, and then it becomes ready for communication with this product.

Tips

- When using CC-Link connection, switch on the CC-Link master device power only after supplying power to this product.
- The ID number assigned to the EJ Counter differs for USB communication and CC-Link communication. For details, see  "3.2.1 ID Number Assignment During USB Communication" on page 33 and "4.3.1 ID Number Assignment during CC-Link Communication" on page 49.

3 USB Communication



| | | |
|-----|---------------------------------------|----|
| 3.1 | USB Specifications | 22 |
| 3.2 | USB Communication Format | 23 |
| 3.3 | List of USB Communication Errors..... | 30 |
| 3.4 | Tolerance Judgment Result | 34 |

3.1 USB Specifications

The USB interface provided with this product conforms to the USB 2.0 standard (with Full-speed communication).

It communicates using a virtual COM port on a PC.

Tips

- For details on the content of USB communication, see  "3.2.2 Send and Receive Data Format" on page 34 and  "3.2.3 List of Commands" on page 36.
- This product cannot output data directly to a printer.
- USB communication can be performed when power is supplied to this product. Power cannot be supplied through the USB terminal.
- The LG QuickSetupTool application software (freeware) is provided to allow EJ Counter settings and display of measurement values to be done by USB communication.
Please download the software from Mitutoyo's web site. (<https://www.mitutoyo.co.jp>)
Note that the software may not be usable in all environments. Further, Mitutoyo makes no assurance or representation of any kind regarding the fitness or usability of the software. While use of this application is free of charge, the user must bear communication charges incurred during download of the software.

■ Compatible connector

Type-C connector

■ Compatible cable

Cable compatible with Type-C connector

Tips

- No USB cable is provided with this product. Use a commercially available cable.
- The software works with Windows 10 standard device drivers.


3.2 USB Communication Format

3.2.1 ID Number Assignment During USB Communication

During USB communication, ID numbers from 01 to 08 are automatically assigned to EJ Counters in sequence, starting with the device that is adjacent to this product. However, if arbitrary ID numbers (50 to 99) were set for Parameter Number 19 when the product was last powered on, those values are assigned instead.

Tips

For details about setting parameters, see  "5 EJ Counter Parameter Settings" on page 69.



ID numbers are assigned sequentially
(figure shows automatic ID number assignments).

3.2.2 Send and Receive Data Format

■ Send data format (from PC to this product)

Tips

Send data consists of ASCII codes.

● Commands

Commands are made up of three alphanumeric characters.

Example: The command for reading the current value is "GCJ".



● Counter ID and channel (Ch.) numbers

Counter ID and channel numbers are made up of four numeric characters.

The uppermost digit is always 0, followed by two digits indicating the EJ Counter ID, and then a single digit indicating the channel (Ch.).

Example: For an EJ Counter whose ID is 02 on Ch.1, specify "0021".

Tips

- Commands that do not specify an EJ Counter channel (Ch.) should always have "1" as the last digit.
- Use "0011" for commands that do not specify an EJ Counter.
For details, see  "3.2.3 List of Commands" on page 36.
- The content of individual channels are specified by parameter settings.
For details about setting parameters, see  "5 EJ Counter Parameter Settings" on page 69.

● Numeric values (only for commands requiring such values)

When setting preset and tolerance values, use the + or - sign together with 10-digit numbers. The least significant digit corresponds to a resolution of 10 nm (0.0000001 in).

Example 1: To set +10.5 mm, specify "+0001050000".

Example 2: To set -0.001 in, specify "-0000010000".

Tips

- Unit, without decimal point.
- Numeric values must be specified as 10 digits. Pad empty parts with zero (0).
- When setting the resolution of an EJ Counter, any fractional value below the set resolution is discarded.

● Delimiter

Commands are delimited by the 2-byte sequence CRLF ("0x0D 0x0A").

■ Receive data format (to PC from this product)

Tips

Receive data consists of ASCII codes.

● Commands

Commands are made up of three alphanumeric characters.


These are the same as for send commands (except for commands that are undefined).

● Counter ID and channel (Ch.) numbers

Counter ID and channel numbers are made up of four numeric characters.

ID and channel (Ch.) numbers are specified in the same manner as for send data.

However, "0000" is received for commands that do not specify an EJ Counter.

For details, see  "3.2.3 List of Commands" on page 36.

● Numeric values (only for commands requiring such values)

When outputting preset and tolerance values, use the + or - sign together with 10-digit numbers. The least significant digit corresponds to a resolution of 10 nm (0.0000001 in). Values are rounded according to the EJ Counter's resolution setting.

Example 1: To set +10.5 mm, specify "+0001050000".

Example 2: To set -0.001 in, specify "-0000010000".

Tips

- Unit, without decimal point.
- Numeric values must be specified as 10 digits. Pad empty parts with zero (0).
- When setting the resolution of an EJ Counter, any fractional value below the set resolution is discarded.

● Delimiter

Commands are delimited by the 2-byte sequence CRLF ("0x0D 0x0A").

3.2.3 List of Commands

Commands sent from the PC and corresponding content output from this product are explained below.

■ View commands


These commands are used to verify the settings of EJ Counters. They do not affect the EJ Counter settings or display.

IMPORTANT


Do not send these commands during communication with a PLC. Doing so might result in incorrect measurement.

| Command format ^{*1} | Corresponding output ^{*1*2} | Description |
|------------------------------|---|--|
| GCJ,****(CRLF) | GCJ,****,(Err-1),+0123456789,(TJ-2),(DataER-2)(CRLF) | Read current values and tolerance judgments ^{*3*4} |
| GPR,****(CRLF) | GPR,****,(Err-1),+0123456789,(DataER-2)(CRLF) | Read preset values ^{*4} |
| GS1,****(CRLF) | GS1,****,(Err-1),+0123456789,(DataER-2)(CRLF) | Read tolerance value S1 ^{*4} |
| GS2,****(CRLF) | GS2,****,(Err-1),+0123456789,(DataER-2)(CRLF) | Read tolerance value S2 ^{*4} |
| GS3,****(CRLF) | GS3,****,(Err-1),+0123456789,(DataER-2)(CRLF) | Read tolerance value S3 ^{*4} |
| GS4,****(CRLF) | GS4,****,(Err-1),+0123456789,(DataER-2)(CRLF) | Read tolerance value S4 ^{*4} |
| GST,****(CRLF) | GST,****,(Err-1),(D-1)(D-2)(D-3)(D-4),(DataER-2)(CRLF) | Read the EJ Counter display state ^{*5} |
| GER,****(CRLF) | GER,****,(Err-1),(DataC-8),(DataER-2)(CRLF) | Read EJ Counter error flag details ^{*6} |
| GEH,****(CRLF) | GEH,****,(Err-1),(DataC-8),(DataER-2)(CRLF) | Read the EJ Counter error flag details history ^{*7} |
| GPM,****,(PMNum-2)(CRLF) | GPM,****,(Err-1),(PMNum-2),(PMDData-2),(DataER-2)(CRLF) | Read EJ Counter parameter settings ^{*8} |
| FNM,0011(CRLF) | FNM,0000,(Err-1),(Data-1)(CRLF) | Read the number of connected EJ Counters ^{*9} |
| FCI,0011(CRLF) | FCI,0000,(Err-1),(Data-16)(CRLF) | Reads EJ Counter IDs ^{*10} |

*1 "****" indicates the counter ID and channel (Ch.) numbers.

For details, see  "3.2.2 Send and Receive Data Format" on page 34.

*2 "Err-1" is the interface unit's communications error flag.

For details, see  "3.3 List of USB Communication Errors" on page 40.

*3 "TJ-2" is the result of tolerance judgment.




When tolerance judgment is enabled, the result of tolerance judgment is output as a value from L1 to L5.

When tolerance judgment is disabled (when the EJ Counter produces as error), L0 is output.

For details on tolerance judgment result, see  "3.4 Tolerance Judgment Result" on page 44.

*4 Output of data conforming to the settings of EJ Counter Parameter Numbers 03 (display mode selection) and 22 (unit setting).

For details on numeric data output, see  "■ Receive data format (to PC from this product)" on page 35.

- *5 "D-1" indicates the display state. "00" indicates standby, "01" indicates count display, and "02" indicates that a parameter preset or tolerance value is being set.
"D-2" indicates peak mode. "00" indicates the current value, "01" indicates MAX (the maximum value), "02" indicates MIN (the minimum value) and "03" indicates TIR (the value of MAX-MIN).
"D-3" indicates the HOLD state. "00" indicates no HOLD, and any other value indicates HOLD.
"D-4" is fixed to "00".
"D-4" indicates the unit. "00" indicates mm, and "01" indicates inch.
- *6 For details, see  "3.3.2 EJ Counter Error Flags" on page 41.
- *7 The EJ Counter error history contains up to the last four errors, and errors are read out starting with the oldest. Note that the error history is deleted even if the error data is not received by the PC.
For details, see  "3.3.2 EJ Counter Error Flags" on page 41.
- *8 For the command's "PMNum-2" parameter, specify the Parameter Number. In the corresponding output, the setting of the specified Parameter Number is output for "PMDData-2". For details about parameters, see  "5 EJ Counter Parameter Settings" on page 69.
- *9 "Data-1" is the number of connected EJ Counters (1 to 8).
- *10 ID numbers of connected EJ Counters are output for "Data-16". "FF" is output if no EJ Counter is connected.
For example, if eight EJ Counters with ID numbers 1 to 8 are connected, "0102030405060708" is output, and if three EJ Counters with ID numbers 1, 2 and 51 are connected, "010251FFFFFFFFFFFF" is output.

■ Setting and control commands

These commands are used to change EJ Counter settings and control operation of EJ Counters.

IMPORTANT

Do not send these commands during communication with a PLC. Doing so might result in incorrect measurement.

| Command format ^{*1} | Corresponding output ^{*1*2} | Description |
|---|--|---|
| SPR,****,+0123456789 (CRLF) | SPR,****,(Err-1),+0123456789, (DataER-2)(CRLF) | Write preset values ^{*3} |
| SS1,****,+0123456789 (CRLF) | SS1,****,(Err-1),+0123456789, (DataER-2)(CRLF) | Write tolerance value S1 ^{*3*4} |
| SS2,****,+0123456789 (CRLF) | SS2,****,(Err-1),+0123456789, (DataER-2)(CRLF) | Write tolerance value S2 ^{*3*4} |
| SS3,****,+0123456789 (CRLF) | SS3,****,(Err-1),+0123456789, (DataER-2)(CRLF) | Write tolerance value S3 ^{*3*4} |
| SS4,****,+0123456789 (CRLF) | SS4,****,(Err-1),+0123456789, (DataER-2)(CRLF) | Write tolerance value S4 ^{*3*4} |
| SSU,****(CRLF) | SSU,****,(Err-1),(DataER-2)(CRLF) | Cancel the start-up standby state ("-----" display) |
| SPK,****,(D-2)(CRLF) | SPK,****,(Err-1),(DataC-8), (DataER-2)(CRLF) | Switch the peak mode ^{*5} |
| SEC,****(CRLF) | SEC,****,(Err-1),(DataER-2)(CRLF) | Clear the EJ Counter error history |
| PST,****(CRLF) | PST,****,(Err-1),(DataER-2)(CRLF) | Perform presets (set preset values set with the SPR command) |
| PZS,****(CRLF) | PZS,****,(Err-1),(DataER-2)(CRLF) | Zero current values |
| PCL,****(CRLF) | PCL,****,(Err-1),(DataER-2)(CRLF) | Clear preset values |
| PKC,****(CRLF) | PKC,****,(Err-1),(DataER-2)(CRLF) | Clear peak data (MAX and MIN data) |
| PEC,****(CRLF) | PEC,****,(Err-1),(DataER-2)(CRLF) | Clear errors ^{*6} |
| PSH,****(CRLF) | PSH,****,(Err-1),(DataER-2)(CRLF) | Hold current value ^{*7} |
| PCH,****(CRLF) | PCH,****,(Err-1),(DataER-2)(CRLF) | Cancel current value hold ^{*8} |
| PDA,****(CRLF) | PDA,****,(Err-1),(DataER-2)(CRLF) | Display EJ Counter ID (displays an EJ Counter's ID num- ber for a preset interval) |
| PDB,****(CRLF) | PDB,****,(Err-1),(DataER-2)(CRLF) | Specify EJ Counter display axis (switches display axes of the cur- rent value on an EJ Counter) |
| PPM,****,(PMNum-2), (PMData-2)(CRLF) | PPM,****,(Err-1),(PMNum-2), (PMData-2),(DataER-2)(CRLF) | Write parameter settings ^{*9} |
| RST,0011,SRST (CRLF) | RST,0000,(Err-1)(CRLF) | System reset ^{*10} |

*1 "****" indicates the counter ID and channel (Ch.) numbers.

For details, see  "3.2.2 Send and Receive Data Format" on page 34.

*2 "Err-1" is the interface unit's communications error flag.

For details, see  "3.3 List of USB Communication Errors" on page 40.


*3 Use the + or - sign and specify 10-digit numbers with no decimal point.

For details on numeric data settings, please see  ■ Send data format (from PC to this product)" on page 34.

*4 For 3-step tolerance, set tolerance values S1 and S4. Setting of S2 and S3 and read-out are not possible. Attempting to set S2/S3 or perform read-out will result in setting of an error flag (bit 0 of DataER-2) and transmission of error output "+2147483647".

For 5-step tolerance, set tolerance values S1 through S4.

Set the tolerance values in sequence from S1 to S4 or from S4 to S1.

- *5 For "D-2", specify the peak mode.
Specify "00" for the current value, "01" for MAX (the maximum value), "02" for MIN (the minimum value), or "03" for TIR (the value of MAX-MIN).
When the peak mode is set properly, "00000000" is output for "DataC-8".
- *6 Clear the error state after first eliminating the cause of the error.
- *7 The HOLD signal is shared by all linked EJ Counters, and all linked EJ Counters enter the HOLD state.
When canceling HOLD with the PCH command, cancellation is required for EJ Counters on which HOLD is set. Set HOLD against the ID number of the linked EJ Counter that is adjacent to the interface unit.
- *8 The HOLD signal is shared by all linked EJ Counters, and HOLD is canceled for all linked EJ Counters.
Cancel HOLD on EJ Counters for which HOLD was set with the PSH command.
- *9 Specify the Parameter Number for "PMNum-2" and the setting value for "PMDData-2". For details about parameters, see  "5 EJ Counter Parameter Settings" on page 69.
- *10 A software reset is performed on this product and linked EJ Counters. Do not execute this command during while measurement is in progress.

3.3 List of USB Communication Errors

3.3.1 Interface Unit Communications Error Flags

When a communication error is detected by this product, it outputs the communications error flag (Err-1).

■ Communications error flags (Err-1)

| Err-1 | Description |
|-------|--|
| 5 | Commands cannot be executed in this state. EJ Counters are in the standby or error state. |
| 4 | This indicates an undefined command. The command sent is undefined or its format is incorrect (missing a comma). |
| 3 | The data length of the command is incorrect. The command is missing data or includes unneeded data. |
| 2 | The command content is incorrect. The command includes an incorrect ID number or channel specification (contains a character other than a numeral). |
| 1 | There was an error in communication between the interface unit and EJ Counters. The ID number specified in a command does not belong to a connected EJ Counter. |
| 0 | No error |

In the event of a command abnormality (undefined command), the response takes the following format.

CER,***,(Err-1)(CRLF)

For example, if the undefined command "GGG" is sent, the response is as follows.

Send command: GGG,0000(CRLF)

Output data: CER,0000,4(CRLF)

3.3.2 EJ Counter Error Flags

These error flags are output when an EJ Counter detects an error.

■ Error flags (DataER-2)

This error flag (DataER-2) is made up of data in hexadecimal notation. Bits that are set to "1" indicate the location of the alarm or error.

| Data ER-2 | Judgment | Description |
|-----------|--------------------------------------|---|
| bit 0 | 0: Normal 1: Alarm or error state | Indicates an error in communication between the interface unit and EJ Counters. Whether or not the command was normally executed cannot be determined. Check the command and execute it again. |
| bit 1 | | The EJ Counter is in the Busy state. EJ Counter settings are being made by key operation. Commands cannot be executed. Execute the command after putting the EJ Counter in the counting state. |
| bit 2 | | The origin of the requested channel has not been detected. Commands cannot be executed. Execute the command again after performing gage origin detection or disabling origin detection. |
| bit 3 | | An alarm occurred on the requested channel or both channels. Commands cannot be executed. The flag is set if the EJ Counter is in the Busy state (DataER-2 bit1), its origin has not been detected (DataER-2 bit 2), or it is in the counter stand-by state. |
| bit 4 | | A hardware error occurred on the requested channel or both channels. |
| bit 5 | | An alarm or hardware error occurred on one of the channels. The flag is set even if the alarm or hardware error occurred on the channel that was not requested. The command is executed if there is no abnormality the requested channel. |
| bit 6 | | Fixed to 0 |
| bit 7 | | Fixed to 0 |

■ Error flag details (DataC-8)

Error flag details (DataC-8) are made up of data in hexadecimal notation. Bits that are set to "1" indicate the location of the alarm or error.

| Data C-8 | Judgment | Description | |
|-------------|--------------------------------------|----------------|---|
| bit 0 | 0: Normal 1: Alarm or error state | Alarm | EJ Counter Busy state (EJ Counter settings are being made by key operation). Put the EJ Counter in the counting state. |
| bit 1 | | | A-axis origin not detected. Go through A-axis origin detection. |
| bit 2 | | | B-axis origin not detected Go through B-axis origin detection. |
| bit 3 | | | Counter stand-by state Cancel the counter standby state, putting the EJ Counter in the counting state. |
| Bits 4 to 7 | | | Fixed to 0 |
| bit 8 | | Hardware error | A-axis peak detection error (with peak mode only) If this error occurs continuously, verify measurement conditions (such as plunger movement speed). |
| bit 9 | | | B-axis peak detection error (with peak mode only) If this error occurs continuously, verify measurement conditions (such as plunger movement speed). |
| bit 10 | | | Ch.1 counter value overflow. Verify preset values. |
| bit 11 | | | Ch.2 counter value overflow. Verify preset values. |
| bit 12 | | | A-axis excess speed error. Verify measurement conditions (such as plunger movement speed). |
| bit 13 | | | B-axis excess speed error. Verify measurement conditions (such as plunger movement speed). |
| bit 14 | | | No gage head on the A-axis or discontinuity detection error. Verify gage head connection. |
| bit 15 | | | No gage head on the B-axis or discontinuity detection error. Verify gage head connection. |
| bit 16 | | | Internal memory abnormality. If operation is not restored upon clearing the error, there may be an internal malfunction. |
| bit 17 | | | Power supply voltage abnormality. Clear the error after verifying supply of correct voltage. |
| bit 18 | | | A-axis counter IC reset error. Occurred because a Linear Gage was connected or removed during operation. |
| bit 19 | | | B-axis counter IC reset error. Occurred because a Linear Gage was connected or removed during operation. |
| bit 20 | | | A-axis counter IC overflow. Electrical noise could be a problem. |
| bit 21 | | | B-axis counter IC overflow. Electrical noise could be a problem. |

| Data C-8 | Judgment | Description | |
|---------------|--------------------------------------|----------------|--|
| bit 22 | 0: Normal 1: Alarm or error state | Hardware error | No A-axis origin signal. When using a Linear Gage with origin, check whether the origin signal is disconnected. When using a Linear Gage without origin, set Parameter Number 05 to 0. |
| bit 23 | | | No B-axis origin signal. When using a Linear Gage with origin, check whether the origin signal is disconnected. When using a Linear Gage without origin, set Parameter Number 05 to 0. |
| bit 24 | | | Internal memory access error. If operation is not restored upon clearing the error, there may be an internal malfunction. |
| bit 25 | | | Wrong number of EJ Counters connected (nine or more devices). Turn the power on after reducing the number of connected EJ Counters to no more than eight. |
| Bits 26 to 31 | | | Fixed to 0 |

■ EJ Counter error history

If a hardware error occurs, error flag details are stored in the error history in the EJ Counter. Error details are not stored when alarms occur.

The EJ Counter error history holds up to the last four errors, and errors are read out starting with the oldest.


If a hardware error occurs when the error history already contains four errors, the oldest error is discarded.

If the error history is read when there are no errors in the EJ Counter error history, the value 0(0x00000000) is output.


3.4 Tolerance Judgment Result

■ Tolerance judgment output

● 3-step tolerance



● 5-step tolerance






4 CC-Link Communication

- 4.1 Outline of CC-Link Communication 36
- 4.2 CC-Link Communication Settings 37
- 4.3 CC-Link Communication Format 39
- 4.4 CC-Link Communication Errors 55
- 4.5 Tolerance Judgment Result..... 56
- 4.6 Communication Response Time..... 57

4.1 Outline of CC-Link Communication

This product functions as a CC-Link slave device, and communicates with a CC-Link master device (such as a PLC).

It is compatible with CC-Link Ver. 1.10 and 2.00.

| Item | CC-Link Ver. 1.10 | CC-Link Ver. 2.00 |
|-----------------------------|--|--|
| Station type | Remote device station | |
| Device type | Generic device (0x7F) | |
| Number of occupied stations | 2 | 4 |
| Maximum data bits | 128 (64 each for RX and RY) | 896 (448 each for RX and RY) |
| Data words | 16 words (8 each for RWw and RWr) | 128 words (64 each for RWw and RWr) |
| Extended cyclic setting | N/A | 4x |
| Assignable station numbers | 1–63 | 1–61 |
| Baud rate | 156 kbps, 625 kbps, 2.5 Mbps, 5 Mbps, 10 Mbps | |
| Data transferred | <ul style="list-style-type: none"> • Tolerance judgment result (L3) For details on tolerance judgment result (L3), see  "4.5 Tolerance Judgment Result" on page 66. • EJ Counter parameter settings • EJ Counter connection status • Tolerance judgment/current value output status | <ul style="list-style-type: none"> • Tolerance judgment results (L1/L2/L3/L4/L5) For details on tolerance judgment result (L1 to L5), see  "4.5 Tolerance Judgment Result" on page 66. • Tolerance judgment results (LT1/LT2/LT3) For details on tolerance judgment result (LT1 to LT3), see  "4.5 Tolerance Judgment Result" on page 66. • EJ Counter parameter settings • EJ Counter connection status • Tolerance judgment/current value output status • Current value data |


4.2 CC-Link Communication Settings

4.2.1 Communications Settings

Before using CC-Link communication, power on the devices to be used and make data allocations.

- 1 When powering on devices, power on this product before powering on the CC-Link master device.**

Tips

For details on powering on this product, see  "2.3.2 Power ON/OFF" on page 30.

- 2 Start up an engineering tool such as GX Works on your PC and make CC-Link communication settings for this product.**

Tips

- For details on operation of GX Works, see Mitsubishi Electric's GX Works manual.
- CC-Link settings can be easily made by using the CSP+ (CC-Link System Profile). CSP+ can be downloaded from the CC-Link Association or Mitutoyo's website.

4.2.2 Verifying Communication

Verify that all devices are properly connected and configured, and that I/O data can be properly read and written.

■ Verifying device status

Verify that indicators on the front panel of the product appear as follows.

| Name | Status |
|------------------------|--------|
| [POWER] indicator | Lit |
| [RUN] indicator | Lit |
| [ERROR] indicator | Off |
| [EJ-CONNECT] indicator | Lit |

Also verify the status of the CC-Link master device.

Tips

For details on the CC-Link master device, see the manual of the CC-Link master device being used.

■ Verifying data

Read CC-Link master device IN and OUT data and verify I/O data is properly read and written.
If I/O signals cannot be read or written, verify that the remote READY flag is ON.

Tips

To set the remote READY flag, make initial settings from GX-Works or other engineering tool.

■ Remote READY flag

When this product is powered ON, the initial data processing request flag goes ON.

Since this product will not output some CC-Link I/O signals while in this state, set initial data processing completed flag ON from the PLC.


The remote READY flag goes ON at the same time.

Next, set the initial data processing completed flag OFF (for example, by detecting that the initial data processing request flag is OFF, which sets the initial data processing completed flag OFF).

Tips

Signal allocation differs depending on whether the CC-Link Ver. is 1.10 or 2.00.

For details, see  "4.3.2 Input/Output Allocation" on page 50.



4.3 CC-Link Communication Format

4.3.1 ID Number Assignment during CC-Link Communication

ID numbers used during CC-Link communication are assigned according to the combination of axes connected to each of the EJ Counters being used.

ID numbers are automatically assigned in sequence from EJ01 to EJ08, starting with the EJ Counter that is adjacent to this product. For the Linear Gage, channel number "Ch.1" is assigned to the A-axis of each EJ Counter, and "Ch.2" is assigned to the B-axis.

The ID number for the axes is formed of combinations of the above in the format "EJxx-Chx".

Example:

The ID number assigned to the B-axis of the second EJ Counter from this product will be "EJ02-Ch.2".


IMPORTANT

Do not change ID numbers by setting EJ Counter parameters during CC-Link communication (while the [RUN] indicator is lit). Changing the ID numbers will prevent normal communication with the EJ Counters.

Tips

Arbitrary ID numbers (50 to 99) set with EJ Counter Parameter Number 19 apply to USB communication.

ID numbers are automatically assigned in sequence beginning with the EJ Counter that is adjacent to this product.



4.3.2 Input/Output Allocation


The following items are allocated by this product according to the CC-Link version being used.

Tips

For details on making allocations, see the manual for the CC-Link master device.

■ Ver. 1.10 input/output signals

● From this product to master device

| Address | Name | Notes |
|-----------------|--|---|
| RXn0 | EJ01-Ch.1 tolerance judgment (L3) | 1: In range 0: Out of range Tips For details on tolerance judgment (L3), see  "4.5 Tolerance Judgment Result" on page 66. |
| RXn1 | EJ01-Ch.2 tolerance judgment (L3) | |
| RXn2 | EJ02-Ch.1 tolerance judgment (L3) | |
| RXn3 | EJ02-Ch.2 tolerance judgment (L3) | |
| RXn4 | EJ03-Ch.1 tolerance judgment (L3) | |
| RXn5 | EJ03-Ch.2 tolerance judgment (L3) | |
| RXn6 | EJ04-Ch.1 tolerance judgment (L3) | |
| RXn7 | EJ04-Ch.2 tolerance judgment (L3) | |
| RXn8 | EJ05-Ch.1 tolerance judgment (L3) | |
| RXn9 | EJ05-Ch.2 tolerance judgment (L3) | |
| RXnA | EJ06-Ch.1 tolerance judgment (L3) | |
| RXnB | EJ06-Ch.2 tolerance judgment (L3) | |
| RXnC | EJ07-Ch.1 tolerance judgment (L3) | |
| RXnD | EJ07-Ch.2 tolerance judgment (L3) | |
| RXnE | EJ08-Ch.1 tolerance judgment (L3) | |
| RXnF | EJ08-Ch.2 tolerance judgment (L3) | |
| RX(n+1)0 | Tolerance judgment ALLGO determination | "1" results if tolerance judgment is OK for all axes (if each axis is available and its tolerance judgment is OK); if any result fails, "0" results. |
| RX(n+1)1 | Not used | |
| RX(n+1)2 | HOLD update complete flag (common to both internal HOLD and external HOLD) | Becomes "1" following data update. Restored to "0" when HOLD clear changes from "1" to "0" (by external input or RYn0). |
| RX(n+1)3 | Not used | |
| RX(n+1)4 | Command normally completed flag | |
| RX(n+1)5 | Command abnormally completed flag | |
| RX(n+1)6 | Command busy flag | |
| RX(n+1)7 | Not used | |
| ... RX(n+3)F | | |
| RX(n+3)8 | Initial data processing request flag | |
| RX(n+3)9 | Initial data setting completed flag | |
| RX(n+3)A | Not used | |
| RX(n+3)B | Remote READY | |
| RX(n+3)C | | |
| ... RX(n+3)F | Not used | |




n: Address assigned from the master device according to station number setting

● From master device to this product

| Address | Name | Notes |
|-----------------------------|--|--|
| RYn0 | Current value internal HOLD | 1: Internal HOLD set 0: Internal HOLD cleared |
| RYn1 ... RY(n+1)3 | Not used | |
| RY(n+1)4 | Command request flag | |
| RY(n+1)5 ... RY(n+3)F | Not used | |
| RY(n+3)8 | Initial data processing completed flag | |
| RY(n+3)9 | Initial data setting request flag | |
| RY(n+3)A ... RY(n+3)F | Not used | |

n: Address assigned from the master device according to station number setting

● Read registers

| Address | Name | Notes |
|---------|--|---|
| RWrn | Connection status flag | 1: Axis available 0: Counter not connected, or axis not available*1 |
| RWrn+1 | Not used | |
| RWrn+2 | Tolerance judgment/current value output flag | 1: Output not possible 0: Output possible*1 |
| RWrn+3 | Not used | |
| RWrn+4 | Receive data 1 |  "4.3.3 List of Commands" on page 60 |
| RWrn+5 | Receive data 2 |  "4.3.3 List of Commands" on page 60 |
| RWrn+6 | Receive data 3 |  "4.3.3 List of Commands" on page 60 |
| RWrn+7 | Not used | |

n: Address assigned from the master device according to station number setting

*1 EJ Counters and channels are assigned to bits as follows.

| | | | |
|-------------------|-------------------|-------------------|-------------------|
| bit 0: EJ01-Ch.1 | bit 1: EJ01-Ch.2 | bit 2: EJ02-Ch.1 | bit 3: EJ02-Ch.2 |
| bit 4: EJ03-Ch.1 | bit 5: EJ03-Ch.2 | bit 6: EJ04-Ch.1 | bit 7: EJ04-Ch.2 |
| bit 8: EJ05-Ch.1 | bit 9: EJ05-Ch.2 | bit 10: EJ06-Ch.1 | bit 11: EJ06-Ch.2 |
| bit 12: EJ07-Ch.1 | bit 13: EJ07-Ch.2 | bit 14: EJ08-Ch.1 | bit 15: EJ08-Ch.2 |

● Write registers

| Address | Name | Notes |
|---------|--|--|
| RWwn | Command target unit selection data | Ordinarily, ID numbers from 0x01 to 0x08 are assigned to EJ Counters in sequence, starting with the device adjacent to this product. |
| RWwn+1 | Command target gage (Ch.1/Ch.2) selection data | 0: Ch.1 1: Ch.2 Tips Data other than bit 0 are invalid. |
| RWwn+2 | Command setting data | "4.3.3 List of Commands" on page 60 |
| RWwn+3 | Not used | |
| RWwn+4 | Command send data 1 | "4.3.3 List of Commands" on page 60 |
| RWwn+5 | Command send data 2 | "4.3.3 List of Commands" on page 60 |
| RWwn+6 | Command send data 3 | "4.3.3 List of Commands" on page 60 |
| RWwn+7 | Not used | |


n: Address assigned from the master device according to station number setting



■ Ver. 2.00 input/output signals

● From this product to master device


| Address | Name | Notes |
|---------|-----------------------------------|---|
| RXn0 | EJ01-Ch.1 tolerance judgment (L3) | 1: In range 0: Out of range Tips For details on tolerance judgment (L3), see "4.5 Tolerance Judgment Result" on page 66. |
| RXn1 | EJ01-Ch.2 tolerance judgment (L3) | |
| RXn2 | EJ02-Ch.1 tolerance judgment (L3) | |
| RXn3 | EJ02-Ch.2 tolerance judgment (L3) | |
| RXn4 | EJ03-Ch.1 tolerance judgment (L3) | |
| RXn5 | EJ03-Ch.2 tolerance judgment (L3) | |
| RXn6 | EJ04-Ch.1 tolerance judgment (L3) | |
| RXn7 | EJ04-Ch.2 tolerance judgment (L3) | |
| RXn8 | EJ05-Ch.1 tolerance judgment (L3) | |
| RXn9 | EJ05-Ch.2 tolerance judgment (L3) | |
| RXnA | EJ06-Ch.1 tolerance judgment (L3) | |
| RXnB | EJ06-Ch.2 tolerance judgment (L3) | |
| RXnC | EJ07-Ch.1 tolerance judgment (L3) | |
| RXnD | EJ07-Ch.2 tolerance judgment (L3) | |
| RXnE | EJ08-Ch.1 tolerance judgment (L3) | |
| RXnF | EJ08-Ch.2 tolerance judgment (L3) | |

| Address | Name | Notes |
|-----------------------------|--|--|
| RX(n+1)0 | Tolerance judgment ALLGO determination | "1" results if tolerance judgment is OK for all axes (if each axis is available and its tolerance judgment is OK); if any result fails, "0" results. |
| RX(n+1)1 | Not used | |
| RX(n+1)2 | HOLD update complete flag (common to both internal HOLD and external HOLD) | Becomes "1" following data update. Restored to "0" when HOLD clear changes from "1" to "0" (by external input or RYn0). |
| RX(n+1)3 | Not used | |
| RX(n+1)4 | Command normally completed flag | |
| RX(n+1)5 | Command abnormally completed flag | |
| RX(n+1)6 | Command busy flag | |
| RX(n+1)7 ... RX(n+1)F | Not used | |

| Address | Name | Notes |
|----------|-----------------------------------|---|
| RX(n+2)0 | EJ01-Ch.1 tolerance judgment (L1) | <p>1: In range 0: Out of range</p> <p>Tips For details on tolerance judgment (L1 to L5), see  "4.5 Tolerance Judgment Result" on page 66.</p> |
| RX(n+2)1 | EJ01-Ch.2 tolerance judgment (L1) | |
| RX(n+2)2 | EJ02-Ch.1 tolerance judgment (L1) | |
| RX(n+2)3 | EJ02-Ch.2 tolerance judgment (L1) | |
| RX(n+2)4 | EJ03-Ch.1 tolerance judgment (L1) | |
| RX(n+2)5 | EJ03-Ch.2 tolerance judgment (L1) | |
| RX(n+2)6 | EJ04-Ch.1 tolerance judgment (L1) | |
| RX(n+2)7 | EJ04-Ch.2 tolerance judgment (L1) | |
| RX(n+2)8 | EJ05-Ch.1 tolerance judgment (L1) | |
| RX(n+2)9 | EJ05-Ch.2 tolerance judgment (L1) | |
| RX(n+2)A | EJ06-Ch.1 tolerance judgment (L1) | |
| RX(n+2)B | EJ06-Ch.2 tolerance judgment (L1) | |
| RX(n+2)C | EJ07-Ch.1 tolerance judgment (L1) | |
| RX(n+2)D | EJ07-Ch.2 tolerance judgment (L1) | |
| RX(n+2)E | EJ08-Ch.1 tolerance judgment (L1) | |
| RX(n+2)F | EJ08-Ch.2 tolerance judgment (L1) | |
| RX(n+3)0 | EJ01-Ch.1 tolerance judgment (L2) | |
| RX(n+3)1 | EJ01-Ch.2 tolerance judgment (L2) | |
| RX(n+3)2 | EJ02-Ch.1 tolerance judgment (L2) | |
| RX(n+3)3 | EJ02-Ch.2 tolerance judgment (L2) | |
| RX(n+3)4 | EJ03-Ch.1 tolerance judgment (L2) | |
| RX(n+3)5 | EJ03-Ch.2 tolerance judgment (L2) | |
| RX(n+3)6 | EJ04-Ch.1 tolerance judgment (L2) | |
| RX(n+3)7 | EJ04-Ch.2 tolerance judgment (L2) | |
| RX(n+3)8 | EJ05-Ch.1 tolerance judgment (L2) | |
| RX(n+3)9 | EJ05-Ch.2 tolerance judgment (L2) | |
| RX(n+3)A | EJ06-Ch.1 tolerance judgment (L2) | |
| RX(n+3)B | EJ06-Ch.2 tolerance judgment (L2) | |
| RX(n+3)C | EJ07-Ch.1 tolerance judgment (L2) | |
| RX(n+3)D | EJ07-Ch.2 tolerance judgment (L2) | |
| RX(n+3)E | EJ08-Ch.1 tolerance judgment (L2) | |
| RX(n+3)F | EJ08-Ch.2 tolerance judgment (L2) | |
| RX(n+4)0 | EJ01-Ch.1 tolerance judgment (L4) | |
| RX(n+4)1 | EJ01-Ch.2 tolerance judgment (L4) | |
| RX(n+4)2 | EJ02-Ch.1 tolerance judgment (L4) | |
| RX(n+4)3 | EJ02-Ch.2 tolerance judgment (L4) | |

| Address | Name | Notes |
|----------|------------------------------------|---|
| RX(n+4)4 | EJ03-Ch.1 tolerance judgment (L4) | <p>1: In range 0: Out of range</p> <p>Tips For details on tolerance judgment (L1 to L5), see  "4.5 Tolerance Judgment Result" on page 66.</p> |
| RX(n+4)5 | EJ03-Ch.2 tolerance judgment (L4) | |
| RX(n+4)6 | EJ04-Ch.1 tolerance judgment (L4) | |
| RX(n+4)7 | EJ04-Ch.2 tolerance judgment (L4) | |
| RX(n+4)8 | EJ05-Ch.1 tolerance judgment (L4) | |
| RX(n+4)9 | EJ05-Ch.2 tolerance judgment (L4) | |
| RX(n+4)A | EJ06-Ch.1 tolerance judgment (L4) | |
| RX(n+4)B | EJ06-Ch.2 tolerance judgment (L4) | |
| RX(n+4)C | EJ07-Ch.1 tolerance judgment (L4) | |
| RX(n+4)D | EJ07-Ch.2 tolerance judgment (L4) | |
| RX(n+4)E | EJ08-Ch.1 tolerance judgment (L4) | |
| RX(n+4)F | EJ08-Ch.2 tolerance judgment (L4) | |
| RX(n+5)0 | EJ01-Ch.1 tolerance judgment (L5) | |
| RX(n+5)1 | EJ01-Ch.2 tolerance judgment (L5) | |
| RX(n+5)2 | EJ02-Ch.1 tolerance judgment (L5) | |
| RX(n+5)3 | EJ02-Ch.2 tolerance judgment (L5) | |
| RX(n+5)4 | EJ03-Ch.1 tolerance judgment (L5) | |
| RX(n+5)5 | EJ03-Ch.2 tolerance judgment (L5) | |
| RX(n+5)6 | EJ04-Ch.1 tolerance judgment (L5) | |
| RX(n+5)7 | EJ04-Ch.2 tolerance judgment (L5) | |
| RX(n+5)8 | EJ05-Ch.1 tolerance judgment (L5) | |
| RX(n+5)9 | EJ05-Ch.2 tolerance judgment (L5) | |
| RX(n+5)A | EJ06-Ch.1 tolerance judgment (L5) | |
| RX(n+5)B | EJ06-Ch.2 tolerance judgment (L5) | |
| RX(n+5)C | EJ07-Ch.1 tolerance judgment (L5) | |
| RX(n+5)D | EJ07-Ch.2 tolerance judgment (L5) | |
| RX(n+5)E | EJ08-Ch.1 tolerance judgment (L5) | |
| RX(n+5)F | EJ08-Ch.2 tolerance judgment (L5) | |
| RX(n+6)0 | EJ01-Ch.1 tolerance judgment (LT1) | <p>1: H 0: L</p> <p>Tips For details on tolerance judgment (LT1 to LT3), see  "4.5 Tolerance Judgment Result" on page 66.</p> |
| RX(n+6)1 | EJ01-Ch.2 tolerance judgment (LT1) | |
| RX(n+6)2 | EJ02-Ch.1 tolerance judgment (LT1) | |
| RX(n+6)3 | EJ02-Ch.2 tolerance judgment (LT1) | |
| RX(n+6)4 | EJ03-Ch.1 tolerance judgment (LT1) | |
| RX(n+6)5 | EJ03-Ch.2 tolerance judgment (LT1) | |
| RX(n+6)6 | EJ04-Ch.1 tolerance judgment (LT1) | |
| RX(n+6)7 | EJ04-Ch.2 tolerance judgment (LT1) | |
| RX(n+6)8 | EJ05-Ch.1 tolerance judgment (LT1) | |
| RX(n+6)9 | EJ05-Ch.2 tolerance judgment (LT1) | |
| RX(n+6)A | EJ06-Ch.1 tolerance judgment (LT1) | |
| RX(n+6)B | EJ06-Ch.2 tolerance judgment (LT1) | |
| RX(n+6)C | EJ07-Ch.1 tolerance judgment (LT1) | |
| RX(n+6)D | EJ07-Ch.2 tolerance judgment (LT1) | |
| RX(n+6)E | EJ08-Ch.1 tolerance judgment (LT1) | |
| RX(n+6)F | EJ08-Ch.2 tolerance judgment (LT1) | |

| Address | Name | Notes |
|-------------------------------|--------------------------------------|--------------|
| RX(n+7)0 | EJ01-Ch.1 tolerance judgment (LT2) | 1: H 0: L |
| RX(n+7)1 | EJ01-Ch.2 tolerance judgment (LT2) | |
| RX(n+7)2 | EJ02-Ch.1 tolerance judgment (LT2) | |
| RX(n+7)3 | EJ02-Ch.2 tolerance judgment (LT2) | |
| RX(n+7)4 | EJ03-Ch.1 tolerance judgment (LT2) | |
| RX(n+7)5 | EJ03-Ch.2 tolerance judgment (LT2) | |
| RX(n+7)6 | EJ04-Ch.1 tolerance judgment (LT2) | |
| RX(n+7)7 | EJ04-Ch.2 tolerance judgment (LT2) | |
| RX(n+7)8 | EJ05-Ch.1 tolerance judgment (LT2) | |
| RX(n+7)9 | EJ05-Ch.2 tolerance judgment (LT2) | |
| RX(n+7)A | EJ06-Ch.1 tolerance judgment (LT2) | |
| RX(n+7)B | EJ06-Ch.2 tolerance judgment (LT2) | |
| RX(n+7)C | EJ07-Ch.1 tolerance judgment (LT2) | |
| RX(n+7)D | EJ07-Ch.2 tolerance judgment (LT2) | |
| RX(n+7)E | EJ08-Ch.1 tolerance judgment (LT2) | |
| RX(n+7)F | EJ08-Ch.2 tolerance judgment (LT2) | |
| RX(n+8)0 | EJ01-Ch.1 tolerance judgment (LT3) | |
| RX(n+8)1 | EJ01-Ch.2 tolerance judgment (LT3) | |
| RX(n+8)2 | EJ02-Ch.1 tolerance judgment (LT3) | |
| RX(n+8)3 | EJ02-Ch.2 tolerance judgment (LT3) | |
| RX(n+8)4 | EJ03-Ch.1 tolerance judgment (LT3) | |
| RX(n+8)5 | EJ03-Ch.2 tolerance judgment (LT3) | |
| RX(n+8)6 | EJ04-Ch.1 tolerance judgment (LT3) | |
| RX(n+8)7 | EJ04-Ch.2 tolerance judgment (LT3) | |
| RX(n+8)8 | EJ05-Ch.1 tolerance judgment (LT3) | |
| RX(n+8)9 | EJ05-Ch.2 tolerance judgment (LT3) | |
| RX(n+8)A | EJ06-Ch.1 tolerance judgment (LT3) | |
| RX(n+8)B | EJ06-Ch.2 tolerance judgment (LT3) | |
| RX(n+8)C | EJ07-Ch.1 tolerance judgment (LT3) | |
| RX(n+8)D | EJ07-Ch.2 tolerance judgment (LT3) | |
| RX(n+8)E | EJ08-Ch.1 tolerance judgment (LT3) | |
| RX(n+8)F | EJ08-Ch.2 tolerance judgment (LT3) | |
| RX(n+9)0 ... RX(n+27)7 | Not used | |
| RX(n+27)8 | Initial data processing request flag | |
| RX(n+27)9 | Initial data setting completed flag | |
| RX(n+27)A | Not used | |
| RX(n+27)B | Remote READY | |
| RX(n+27)C ... RX(n+27)F | Not used | |

Tips
For details on tolerance judgment (LT1 to LT3), see  "4.5 Tolerance Judgment Result" on page 66.




n: Address assigned from the master device according to station number setting

● From master device to this product

| Address | Name | Notes |
|-------------------------------|---------------------------------------|--|
| RYn0 | Current value internal HOLD | 1: Internal HOLD set 0: Internal HOLD cleared |
| RYn1 ... RY(n+1)3 | Not used | |
| RY(n+1)4 | Command request flag | |
| RY(n+1)5 ... RY(n+27)7 | Not used | |
| RY(n+27)8 | Initial data processing complete flag | |
| RY(n+27)9 | Initial data setting request flag | |
| RY(n+27)A ... RY(n+27)F | Not used | |

n: Address assigned from the master device according to station number setting

● Read registers

| Address | Name | Notes |
|---------|--|---|
| RWrn | Connection status flag | 1: Axis available 0: Counter not connected, or axis not available*1 |
| RWrn+1 | Not used | |
| RWrn+2 | Tolerance judgment/current value output flag | 1: Output not possible 0: Output possible*1 |
| RWrn+3 | Not used | |
| RWrn+4 | Receive data 1 |  "4.3.3 List of Commands" on page 60 |
| RWrn+5 | Receive data 2 |  "4.3.3 List of Commands" on page 60 |
| RWrn+6 | Receive data 3 |  "4.3.3 List of Commands" on page 60 |
| RWrn+7 | Not used | |
| RWrn+8 | EJ01-Ch.1 Current value data (upper part) | <ul style="list-style-type: none"> • Output of data conforming to the setting of EJ Counter Parameter Numbers 03 (display mode selection) and 22 (unit setting). • Data is output in the following format as a sign (1 bit) and a numeric value (31 bits). <ul style="list-style-type: none"> – Minimum resolution: 0.00001 mm (0.0000001 in), fixed – Unit/ decimal point: None – Sign: "0" when positive, "1" when negative (complement of 2) |
| RWrn+9 | EJ01-Ch.1 Current value data (lower part) | |
| RWrn+A | EJ01-Ch.2 Current value data (upper part) | |
| RWrn+B | EJ01-Ch.2 Current value data (lower part) | |
| RWrn+C | EJ02-Ch.1 Current value data (upper part) | |
| RWrn+D | EJ02-Ch.1 Current value data (lower part) | |

| Address | Name | Notes |
|----------|---|---|
| RWrn+E | EJ02-Ch.2 Current value data (upper part) | <ul style="list-style-type: none"> • Output of data conforming to the setting of EJ Counter Parameter Numbers 03 (display mode selection) and 22 (unit setting). • Data is output in the following format as a sign (1 bit) and a numeric value (31 bits). <ul style="list-style-type: none"> – Minimum resolution: 0.00001 mm (0.0000001 in), fixed – Unit/ decimal point: None – Sign: "0" when positive, "1" when negative (complement of 2) |
| RWrn+F | EJ02-Ch.2 Current value data (lower part) | |
| RWrn+1 0 | EJ03-Ch.1 Current value data (upper part) | |
| RWrn+1 1 | EJ03-Ch.1 Current value data (lower part) | |
| RWrn+1 2 | EJ03-Ch.2 Current value data (upper part) | |
| RWrn+1 3 | EJ03-Ch.2 Current value data (lower part) | |
| RWrn+1 4 | EJ04-Ch.1 Current value data (upper part) | |
| RWrn+1 5 | EJ04-Ch.1 Current value data (lower part) | |
| RWrn+1 6 | EJ04-Ch.2 Current value data (upper part) | |
| RWrn+1 7 | EJ04-Ch.2 Current value data (lower part) | |
| RWrn+1 8 | EJ05-Ch.1 Current value data (upper part) | |
| RWrn+1 9 | EJ05-Ch.1 Current value data (lower part) | |
| RWrn+1 A | EJ05-Ch.2 Current value data (upper part) | |
| RWrn+1 B | EJ05-Ch.2 Current value data (lower part) | |
| RWrn+1 C | EJ06-Ch.1 Current value data (upper part) | |
| RWrn+1 D | EJ06-Ch.1 Current value data (lower part) | |
| RWrn+1 E | EJ06-Ch.2 Current value data (upper part) | |
| RWrn+1 F | EJ06-Ch.2 Current value data (lower part) | |
| RWrn+2 0 | EJ07-Ch.1 Current value data (upper part) | |
| RWrn+2 1 | EJ07-Ch.1 Current value data (lower part) | |
| RWrn+2 2 | EJ07-Ch.2 Current value data (upper part) | |
| RWrn+2 3 | EJ07-Ch.2 Current value data (lower part) | |
| RWrn+2 4 | EJ08-Ch.1 Current value data (upper part) | |
| RWrn+2 5 | EJ08-Ch.1 Current value data (lower part) | |
| RWrn+2 6 | EJ08-Ch.2 Current value data (upper part) | |
| RWrn+2 7 | EJ08-Ch.2 Current value data (lower part) | |





| Address | Name | Notes |
|-----------------------------|----------|-------|
| RWrn+2 8 ... RWrn+3 F | Not used | |

n: Address assigned from the master device according to station number setting

*1 EJ Counters and channels are assigned to bits as follows.

| | | | |
|-------------------|-------------------|-------------------|-------------------|
| bit 0: EJ01-Ch.1 | bit 1: EJ01-Ch.2 | bit 2: EJ02-Ch.1 | bit 3: EJ02-Ch.2 |
| bit 4: EJ03-Ch.1 | bit 5: EJ03-Ch.2 | bit 6: EJ04-Ch.1 | bit 7: EJ04-Ch.2 |
| bit 8: EJ05-Ch.1 | bit 9: EJ05-Ch.2 | bit 10: EJ06-Ch.1 | bit 11: EJ06-Ch.2 |
| bit 12: EJ07-Ch.1 | bit 13: EJ07-Ch.2 | bit 14: EJ08-Ch.1 | bit 15: EJ08-Ch.2 |

● Write registers

| Address | Name | Notes |
|---------------------------|--|--|
| RWwn | Command target unit selection data | Ordinarily, ID numbers from 0x01 to 0x08 are assigned to EJ Counters in sequence, starting with the device adjacent to this product. |
| RWwn+1 | Command target gage (Ch.1/Ch.2) selection data | 0: Ch.1 1: Ch.2 Tips Data other than bit 0 are invalid. |
| RWwn+2 | Command setting data |  "4.3.3 List of Commands" on page 60 |
| RWwn+3 | Not used | |
| RWwn+4 | Command send data 1 |  "4.3.3 List of Commands" on page 60 |
| RWwn+5 | Command send data 2 |  "4.3.3 List of Commands" on page 60 |
| RWwn+6 | Command send data 3 |  "4.3.3 List of Commands" on page 60 |
| RWwn+7 ... RWwn+3 F | Not used | |

n: Address allocated from the master device according to station number setting

4.3.3 List of Commands

You can read/write settings and status of this product and EJ Counters by communication of commands using the read register or write register.

Tips

When checking tolerance judgment results, check them as a set together with the tolerance judgment/current value output status flag (RWrn+2). Results of tolerance judgment are valid only if the tolerance judgment/current value output status flag (RWrn+2) is "0" (ready for output).

■ Read

1 Store command setting data in the prescribed location (remote register RWw) and set the command request flag ON.

- » Data is communicated to the EJ Counter, and then the command complete flag goes ON after required data has been obtained.
- » Data obtained is stored to receive data 1 to 3.

2 Verify the receive data, and then set the command request flag OFF.

- » The command normally completed flag goes OFF.

■ Write

1 Store command setting data in the prescribed location (remote register RWw) and set the command request flag ON.

- » Data is communicated to the EJ Counter, and then the command complete flag goes ON after data has been written.
- » Data written is stored to receive data 1 to 3.

2 Verify the receive data, and then set the command request flag OFF.

- » The command normally completed flag goes OFF.

Read commands

| Com- mands | Com- mand setting data RWwn+2 | Command target unit selec- tion data RWwn+1 ^{*1} | Command target gage selec- tion data RWwn+1 ^{*2} | Send data 1 (16 bit) | Send data 2 (16 bit) | Send data 3 (16 bit) | Receive data 1 (16 bit) | Receive data 2 (16 bit) | Receive data 3 (16 bit) |
|--|---|---|--|--|----------------------------|----------------------------|---|--|-------------------------------|
| Current value ^{*3} | 0x0010 | 0x0001 to 0x0008 | 0x0000 or 0x0001 | 0x0000 | 0x0000 | 0x0000 | Current value (upper part) | Current value (lower part) | Error flag ^{*4} |
| Preset value ^{*3} | 0x0020 | 0x0001 to 0x0008 | 0x0000 or 0x0001 | 0x0000 | 0x0000 | 0x0000 | Preset value (upper part) | Preset value (lower part) | Error flag ^{*4} |
| Toler- ance value S1 ^{*3} | 0x0021 | 0x0001 to 0x0008 | 0x0000 or 0x0001 | 0x0000 | 0x0000 | 0x0000 | Toler- ance value S1 (upper part) | Toler- ance value S1 (lower part) | Error flag ^{*4} |
| Toler- ance value S2 ^{*3} | 0x0022 | 0x0001 to 0x0008 | 0x0000 or 0x0001 | 0x0000 | 0x0000 | 0x0000 | Toler- ance value S2 (upper part) | Toler- ance value S2 (lower part) | Error flag ^{*4} |
| Toler- ance value S3 ^{*3} | 0x0023 | 0x0001 to 0x0008 | 0x0000 or 0x0001 | 0x0000 | 0x0000 | 0x0000 | Toler- ance value S3 (upper part) | Toler- ance value S3 (lower part) | Error flag ^{*4} |
| Toler- ance value S4 ^{*3} | 0x0024 | 0x0001 to 0x0008 | 0x0000 or 0x0001 | 0x0000 | 0x0000 | 0x0000 | Toler- ance value S4 (upper part) | Toler- ance value S4 (lower part) | Error flag ^{*4} |
| EJ Counter display status | 0x0030 | 0x0001 to 0x0008 | 0x0000 or 0x0001 | 0x0000 | 0x0000 | 0x0000 | Upper 8 bits: Display status ^{*5} Lower 8 bits: Peak mode ^{*6} | Upper 8 bits: HOLD status ^{*7} Lower 8 bits: Unit ^{*8} | Error flag ^{*4} |
| Read EJ Counter param- eter set- tings | 0x0040 | 0x0001 to 0x0008 | 0x0000 or 0x0001 | Upper 8 bits: Fixed to 0x00 Lower 8 bits: Param- eter Number | 0x0000 | 0x0000 | Upper 8 bits: Fixed to 0x00 Lower 8 bits: Param- eter Number | Upper 8 bits: Fixed to 0x00 Lower 8 bits: Setting value. | Error flag ^{*4} |

| Com- mands | Com- mand setting data RWwn+2 | Command target unit selec- tion data RWwn ^{*1} | Command target gage selec- tion data RWwn+1 ^{*2} | Send data 1 (16 bit) | Send data 2 (16 bit) | Send data 3 (16 bit) | Receive data 1 (16 bit) | Receive data 2 (16 bit) | Receive data 3 (16 bit) |
|---|---|---|--|----------------------------|----------------------------|----------------------------|--|--|-------------------------------|
| Number of EJ Counters connect- ed | 0x00AA | 0x0000 | 0x0000 | 0x0000 | 0x0000 | 0x0000 | Upper 8 bits: Num- ber of counters connect- ed Lower 8 bits: Fixed to 0x00 | 0x0000 | 0x0000 |
| EJ Counter ID num- bers (units 1 to 4) | 0x00A4 | 0x0000 | 0x0000 | 0x0000 | 0x0000 | 0x0000 | EJ01, EJ02 ID num- bers ^{*9} | EJ03, EJ04 ID num- bers ^{*9} | 0x0000 |
| EJ Counter ID num- bers (units 5 to 8) | 0x00A4 | 0x0000 | 0x0000 | 0x0001 | 0x0000 | 0x0000 | EJ05, EJ06 ID num- bers ^{*9} | EJ07, EJ08 ID num- bers ^{*9} | 0x0000 |

*1: Assign 0x0001 to 0x0008 to EJ Counters in sequence starting with the device adjacent to this prod-
uct.

*2: Specify "0" for Ch.1, or "1" for Ch.2. (Data bits other than 0 are not valid.)

*3: The current value, preset value and tolerance data are each output as a sign (1 bit) and a numeric
value (31 bits).

– Minimum resolution: 0.00001 mm (0.0000001 in), fixed

– Decimal point: None

– Sign: "0" when positive, "1" when negative (complement of 2)

*4: When an error flag is output to receive data 3, the upper 8 bits are the error flag. The lower 8 bits are
fixed to "0x00".

*5: "0x00" indicates the standby state, "0x01" indicates counter display, and "0x02" indicates parameter
display.

*6: "0x00" indicates current value display, "0x01" indicates MAX value display, "0x02" indicates MIN
value display and "0x03" indicates TIR value display

*7: bit 0 indicates the external HOLD state, bit 1 indicates the internal HOLD state, and bit 2 indicates
the internal HOLD output state. Each is "1" when ON or during output. Bits 3 to 7 are fixed to 0.

*8: "0x00" indicates mm display, and "0x01" indicates inch display.

*9: If the relevant EJ Counter is not connected, the value read is "0xFF".

■ Setting and write commands

| Com- mands | Com- mand setting data RWwn+2 | Command target unit selec- tion data RWwn+1 ^{*1} | Command target gage selec- tion data RWwn+1 ^{*2} | Send data 1 (16 bit) | Send data 2 (16 bit) | Send data 3 (16 bit) | Receive data 1 (16 bit) | Receive data 2 (16 bit) | Receive data 3 (16 bit) |
|---|---|---|--|---|---|--|---|---|-------------------------------|
| Write preset values ^{*3} | 0x0060 | 0x0001 to 0x0008 | 0x0000 or 0x0001 | Preset value (upper part) | Preset value (lower part) | 0x0000 | Preset value (upper part) | Preset value (lower part) | Error flag ^{*4} |
| Write tolerance value S1 ^{*3} | 0x0061 | 0x0001 to 0x0008 | 0x0000 or 0x0001 | Toler- ance value S1 (upper part) | Toler- ance value S1 (lower part) | 0x0000 | Toler- ance value S1 (upper part) | Toler- ance value S1 (lower part) | Error flag ^{*4} |
| Write tolerance value S2 ^{*3} | 0x0062 | 0x0001 to 0x0008 | 0x0000 or 0x0001 | Toler- ance value S2 (upper part) | Toler- ance value S2 (lower part) | 0x0000 | Toler- ance value S2 (upper part) | Toler- ance value S2 (lower part) | Error flag ^{*4} |
| Write tolerance value S3 ^{*3} | 0x0063 | 0x0001 to 0x0008 | 0x0000 or 0x0001 | Toler- ance value S3 (upper part) | Toler- ance value S3 (lower part) | 0x0000 | Toler- ance value S3 (upper part) | Toler- ance value S3 (lower part) | Error flag ^{*4} |
| Write tolerance value S4 ^{*3} | 0x0064 | 0x0001 to 0x0008 | 0x0000 or 0x0001 | Toler- ance value S4 (upper part) | Toler- ance value S4 (lower part) | 0x0000 | Toler- ance value S4 (upper part) | Toler- ance value S4 (lower part) | Error flag ^{*4} |
| Cancel the start- up stand- by state (cancel "-----" display) | 0x0070 | 0x0001 to 0x0008 | 0x0000 or 0x0001 | 0x0000 | 0x0000 | 0x0000 | 0x0000 | 0x0000 | Error flag ^{*4} |
| Switch peak mode. | 0x0071 | 0x0001 to 0x0008 | 0x0000 or 0x0001 | 0x0000 | 0x0000 | Upper 8 bits: Peak mode ^{*4} Lower 8 bits: Fixed to 0x00 | 0x0000 | 0x0000 | Error flag ^{*4} |
| Current value preset | 0x0072 | 0x0001 to 0x0008 | 0x0000 or 0x0001 | 0x0000 | 0x0000 | 0x0000 | 0x0000 | 0x0000 | Error flag ^{*4} |
| Zero current values | 0x0073 | 0x0001 to 0x0008 | 0x0000 or 0x0001 | 0x0000 | 0x0000 | 0x0000 | 0x0000 | 0x0000 | Error flag ^{*4} |
| Clear presets/ zero set | 0x0074 | 0x0001 to 0x0008 | 0x0000 or 0x0001 | 0x0000 | 0x0000 | 0x0000 | 0x0000 | 0x0000 | Error flag ^{*4} |

| Com- mands | Com- mand setting data RWwn+2 | Command target unit selec- tion data RWwn ^{*1} | Command target gage selec- tion data RWwn+1 ^{*2} | Send data 1 (16 bit) | Send data 2 (16 bit) | Send data 3 (16 bit) | Receive data 1 (16 bit) | Receive data 2 (16 bit) | Receive data 3 (16 bit) |
|---|---|---|--|--|--|----------------------------|--|--|-------------------------------|
| Clear peak data (MAX and MIN data) | 0x0075 | 0x0001 to 0x0008 | 0x0000 or 0x0001 | 0x0000 | 0x0000 | 0x0000 | 0x0000 | 0x0000 | Error flag ^{*4} |
| Clear the EJ Counter error state | 0x0076 | 0x0001 to 0x0008 | 0x0000 or 0x0001 | 0x0000 | 0x0000 | 0x0000 | 0x0000 | 0x0000 | Error flag ^{*4} |
| Set current value internal hold | 0x0077 | 0x0001 to 0x0008 | 0x0000 or 0x0001 | 0x0000 | 0x0000 | 0x0000 | 0x0000 | 0x0000 | Error flag ^{*4} |
| Cancel current value internal hold | 0x0078 | 0x0001 to 0x0008 | 0x0000 or 0x0001 | 0x0000 | 0x0000 | 0x0000 | 0x0000 | 0x0000 | Error flag ^{*4} |
| Write EJ Counter param- eter set- tings | 0x0080 | 0x0001 to 0x0008 | 0x0000 or 0x0001 | Upper 8 bits: Fixed to 0x00 Lower 8 bits: Param- eter Number | Upper 8 bits: Fixed to 0x00 Lower 8 bits: Setting value | 0x0000 | Upper 8 bits: Fixed to 0x00 Lower 8 bits: Param- eter Number | Upper 8 bits: Fixed to 0x00 Lower 8 bits: Setting value | Error flag ^{*4} |
| System reset (en- able) ^{*6} | 0x00CA | 0x0000 | 0x0000 | 0xAAAA | 0x0000 | 0x0000 | 0x0000 | 0x0000 | 0x0000 |
| System reset (ex- ecute) ^{*6} | 0x00CA | 0x0000 | 0x0000 | 0x0000 | 0x0000 | 0x0000 | 0x0000 | 0x0000 | 0x0000 |

*1: Specify 0x01 to 0x08 in sequence starting with the device adjacent to this product.

*2: Specify "0" for Ch.1, or "1" for Ch.2. (Data bits other than 0 are not valid.)

*3: The preset value and tolerance data are each set as a sign (1 bit) and a numeric value (31 bits).

– Minimum resolution: 0.00001 mm (0.0000001 in), fixed

– Decimal point: None

– Sign: "0" when value is positive, "1" when negative (complement of 2)

*4: When an error flag is output to receive data 3, the upper 8 bits are the error flag. The lower 8 bits are fixed to "0x00".

*5: Specify "0x00" to switch peak mode to current value, "0x01" to switch to MAX value, "0x02" to switch to MIN value and "0x03" to switch to TIR value.

*6: When 0xAAAA followed by 0x0000 are sent to send data 1 in the same command, a software reset is executed.

4.4 CC-Link Communication Errors

4.4.1 EJ Counter Error Flags


Error flags are made up of data in hexadecimal notation. Bits that are set to "1" indicate the location of the alarm or error.

| bit | Judgment | Description |
|-------|--|---|
| bit 0 | 0: Normal 1: Alarm or error state | Indicates an error in communication between the interface unit and EJ Counters. Whether or not the command was normally executed cannot be determined. Check the command and execute it again. |
| bit 1 | | The EJ Counter is in the Busy state. EJ Counter settings are being made by key operation. Commands cannot be executed. Execute the command after putting the EJ Counter in the counting state. |
| bit 2 | | The origin of the requested channel has not been detected. Commands cannot be executed. Execute the command again after performing gage origin detection or disabling origin detection. |
| bit 3 | | An alarm occurred on the requested channel or both channels. Commands cannot be executed. The flag is set if the EJ Counter is in the Busy state (DataER-2 bit1), its origin has not been detected (DataER-2 bit 2), or it is in the counter stand-by state. |
| bit 4 | | A hardware error occurred on the requested channel or both channels. |
| bit 5 | | An alarm or hardware error occurred on one of the channels. The flag is set even if the alarm or hardware error occurred on the channel that was not requested. The command is executed if there is no abnormality the requested channel. |
| bit 6 | | Fixed to 0 |
| bit 7 | | Fixed to 0 |

4.5 Tolerance Judgment Result


■ Tolerance judgment output

● With 3-step tolerance



* With 3-step tolerance judgment, L2 and L4 are not used. (Fixed to 0)

● With 5-step tolerance



4.6 Communication Response Time

The current value data from the EJ Counter(s) connected to this product are sent to the CPU unit through the CC-Link master unit.

The time required to update data at the CPU unit is as follows.

Tips

The update times indicated below are for reference. The time fluctuates depending on the system used by the customer.

■ Conditions

Baud rate: 10 Mbps

CC-Link Ver.: 1.10 or Ver. 2.00.

Communication unit: L26CPU-BT CPU unit (Mitsubishi Electric)

| Number of EJ Counters | Update time (reference) |
|-----------------------|-------------------------|
| 1 unit | Approx. 12 ms |
| 8 units | Approx. 46 ms |

* The update time is the same regardless of whether the number of Linear Gages connected to the EJ Counter is one or two.

* The update time is the same for both CC-Link Ver. 1.10 and Ver. 2.00.

MEMO


5 EJ Counter Parameter Settings

| No. | Set value | Per-axis setting | Set value: Operation | Default value | Description | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|-----------|---|------------------|--|---------------|---|------|----|----------------|----------------|----|-----------|----------------|----|------------------|----------------|----|----------------|-----------|----|----------------|------------------|----|--------------|--------------|----|----------------|--------------|----|----------------|--------------|----|---|
| 01 | Key protect | N/A | 00: No key protect 01: Key protect | 00 | Operation of keys other than those used for setting parameters can be disabled to prevent operation errors. Tips Operation by external input cannot be disabled. | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 02 | Origin initialization (Origin clear) | N/A | 00: Do not initialize. 01: Initialize. | 00 | When a Linear Gage with origin mark is connected, the origin can be initialized without cycling on the power. | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 03 | Display mode selection | N/A | <table><tr><th>Set value</th><th>Ch.1</th><th>Ch.2</th></tr><tr><td>00</td><td>A-axis counter</td><td>B-axis counter</td></tr><tr><td>01</td><td>Sum (A+B)</td><td>B-axis counter</td></tr><tr><td>02</td><td>Difference (A-B)</td><td>B-axis counter</td></tr><tr><td>03</td><td>A-axis counter</td><td>Sum (A+B)</td></tr><tr><td>04</td><td>A-axis counter</td><td>Difference (A-B)</td></tr><tr><td>05</td><td>A-axis speed</td><td>B-axis speed</td></tr><tr><td>06</td><td>A-axis counter</td><td>A-axis speed</td></tr><tr><td>07</td><td>B-axis counter</td><td>B-axis speed</td></tr></table> | Set value | Ch.1 | Ch.2 | 00 | A-axis counter | B-axis counter | 01 | Sum (A+B) | B-axis counter | 02 | Difference (A-B) | B-axis counter | 03 | A-axis counter | Sum (A+B) | 04 | A-axis counter | Difference (A-B) | 05 | A-axis speed | B-axis speed | 06 | A-axis counter | A-axis speed | 07 | B-axis counter | B-axis speed | 00 | Selects the values to be displayed on Ch.1 and Ch.2. Tips <ul style="list-style-type: none">When using only the A-axis or the B-axis, set 06 or 07.If the displayed content is the same both before and after changing the setting, the tolerance value, preset value and preset state settings are maintained.In order to set the speed display, set the speed sampling cycle with Parameter Number 17.The speed display unit is mm/s (or in/s). Display of lower digits may be fixed depending on the speed sampling time.When the minimum value (MIN) is selected for Peak mode, the speed display indicates the maximum speed in the reverse direction.Because speed display is simplified, it is not suitable for feedback control. |
| Set value | Ch.1 | Ch.2 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 00 | A-axis counter | B-axis counter | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 01 | Sum (A+B) | B-axis counter | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 02 | Difference (A-B) | B-axis counter | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 03 | A-axis counter | Sum (A+B) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 04 | A-axis counter | Difference (A-B) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 05 | A-axis speed | B-axis speed | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 06 | A-axis counter | A-axis speed | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 07 | B-axis counter | B-axis speed | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

5 EJ Counter Parameter Settings

| No. | Set value | Per-axis setting | Set value: Operation | Default value | Description |
|-----|--|------------------|--|---------------|--|
| 04 | Linear Gage resolution (minimum reading) | ✓ | 00: 0.005 mm (5 μ m), 0.0002 in 01: 0.001 mm (1 μ m), 0.00005 in 02: 0.0005 mm (0.5 μ m), 0.00002 in 03: 0.0001 mm (0.1 μ m), 0.000005 in | 01 | Set the minimum reading according to the resolution of the connected Linear Gage. Make settings individually for the A-axis and B-axis. Tips <ul style="list-style-type: none"> Correct values will not be displayed if the settings do not match the resolution of the connected Linear Gage. The unit for minimum reading is "in" when Parameter Number 22 is set to "1". |
| 05 | Origin detection function | N/A | 00: Disabled 01: Enabled | 00 | Selects whether the origin function is enabled or disabled when a Linear Gage with an origin point mark is connected. |
| 06 | Counter direction | ✓ | 00: + direction 01: - direction | 00 | Sets the relationship between the direction in which the numeric value changes and the direction of movement of the Linear Gage plunger. When 00 is set, the numeric value increases as the plunger moves toward top dead center. When 01 is set, the numeric value increases as the plunger moves toward bottom dead center. Make settings individually for the A-axis and B-axis. |
| 07 | Origin detection direction | ✓ | 00: + direction 01: - direction | 00 | When a Linear Gage with an origin mark is connected, selects the direction of the plunger of the Linear Gage for origin detection. Make settings individually for the A-axis and B-axis. |

5 EJ Counter Parameter Settings

| No. | Set value | Per-axis setting | Set value: Operation | Default value | Description |
|-----|---|------------------|---|---------------|---|
| 08 | Tolerance judgment setting | N/A | 00: 3-step tolerance judgment 01: 5-step tolerance judgment 02: No tolerance judgment | 00 | <p>Selects whether or not the tolerance judgment function is used.</p> <p>When the tolerance judgment is used, selects the number of steps of tolerance judgment.</p> <p>Tips</p> <p>Changing the settings does not clear tolerance values S1 to S4, which are maintained. However, the following adjustments may be made in the event that the following inconsistencies occur.</p> <p>When the setting is changed from "3-step tolerance" or "No tolerance" to "5-step tolerance":</p> <p>When $S2 < S1$ or $S4 < S2$, S2 is replaced with the value of S1.</p> <p>When $S3 < S1$ or $S4 < S3$, S3 is replaced with the value of S4.</p> |
| 09 | Display at startup | N/A | 00: Counter stand-by 01: Counter displayed | 00 | <p>Selects whether to display the standby state or the counter display at startup.</p> <p>Tips</p> <p>For details about screen display in the counter stand-by state, see  the separate "Compact Display Unit for Linear Gage EJ Counter User's Manual".</p> |
| 10 | ERR/ALLGO selection (I/O input/output setting) | N/A | 00: Used as ERR 01: Used as ALLGO | 00 | <p>Selects whether to use the ERR or ALLGO signal as the external output function.</p> <p>Tips</p> <p>When multiple EJ Counters are linked together, all of them must have the same setting. Correct output will not be obtained if any of the EJ Counters has a different setting.</p> |
| 11 | Channel coupling selection (I/O input/output setting) | N/A | 00: Do not couple channels 01: Couple channels | 00 | <p>Selects whether to couple the 1 or 2 SEL external input signal to the EJ Counter's display channel.</p> <p>Tips</p> <p>The EJ Counter's [SEL/CE] key also works to couple the signal.</p> |

| No. | Set value | Per-axis setting | Set value: Operation | Default value | Description |
|-----|--|------------------|---|---------------|---|
| 12 | Origin re-detection (I/O input/output setting) | N/A | 00: Disabled 01: Only effective for the axis that is dependent on the channel selected by 1/2 SEL. 02: Axis dependent on Ch.1 and axis dependent on Ch.2. | 00 | <p>When setting is enabled, origin re-detection goes on stand-by when the HOLD signal (I/O input) rises. If the HOLD signal rises again while original detection is on stand-by, origin re-detection is canceled.</p> <p>Tips</p> <p>This setting affects all axes related to the specified channel. However, this does not include the axis whose channel is displaying speed.</p> <p>Example:</p> <ul style="list-style-type: none"> • If the channel displaying the sum (A+B) and difference (A-B) is selected, the A-axis and B-axis are affected. • If the channel displaying the B-axis coordinates is selected, the B-axis is affected. |
| 13 | Preset by I/O input (I/O input setting) | N/A | 00: Executed only for the channel selected by 1/2 SEL. 01: Executed for both channels. | 00 | Selects whether preset processing by external input is to be applied to just one channel or both channels. |
| 14 | Ch affected by the CLEAR signal (I/O input/output setting) | N/A | 00: Executed only for the channel selected by 1/2 SEL. 01: Executed for both channels. | 00 | Selects whether peak clear and error clear are to be applied to just the specified channel or to both channels. |
| 15 | Peak value preset | N/A | 00: Disabled 01: Enabled | 00 | <p>Sets whether the peak value is to be set as the standard during peak mode maximum value display or minimum value display.</p> <p>Tips</p> <p>Peak value preset cannot be set during run-out display.</p> |
| 16 | Smoothing | N/A | 00: No smoothing (update at 5 ms intervals). 01: The average of 16 measurements is displayed (update at 80 ms intervals). 02: The average of 32 measurements is displayed (update at 160 ms intervals). | 00 | Counter values are averaged to minimize flicker of the lowest-order digit. |

5 EJ Counter Parameter Settings

| No. | Set value | Per-axis setting | Set value: Operation | Default value | Description |
|-----|------------------------------|------------------|--|---------------|---|
| 17 | Speed sampling cycle | N/A | 00: 10 ms 01: 50 ms 02: 100 ms | 00 | Selects the sampling interval for speed calculation. |
| 18 | Hide the lowest-order digit. | N/A | 00: Display all digits. 01: Hide the lowest-order digit. | 00 | Hides the lowest-order digit. However, data output to the optional interface unit includes the lowest-order digit. |
| 19 | Arbitrary ID specification | N/A | 00 to 49: ID numbers assigned automatically. 50 to 99: Arbitrary ID numbers assigned (ID numbers specified). | 01 | <p>Set the ID number required when an optional interface unit is connected. When arbitrary ID numbers are set in the range 50 to 99, the ID numbers set are assigned the next time the power is turned on.</p> <p>Tips</p> <ul style="list-style-type: none"> • After setting IDs, be sure to cycle the power off and on or perform a system reset. • When 00 to 49 is set, ID numbers 01 to 08 are automatically reassigned when the power is cycled off and on or after the system is reset. • If the same ID number is arbitrarily assigned to more than one EJ Counter, [EJ-CONNECT] will flash following power-on or system reset and the interface unit will not function properly. This will require checking ID settings at the EJ Counters themselves. |
| 20 | Power saving function | N/A | 00: Display always lit 01 to 99: Display goes out after the specified interval passes (specify the interval length in minutes). | 00 | <p>Turning off display minimizes power consumption. Specify the time that elapses between when the last key is pressed until the display goes out (01 to 99 minutes). When display is turned off, press any key to turn it on again.</p> <p>Tips</p> <p>Counter operation for the axes, I/O input and output, and data communication through the optional interface unit continue even when the display is off.</p> |
| 21 | Parameter initialization | N/A | 00: Do not initialize. 01: Initialize. | 00 | When this parameter is set to 01, the settings for all parameters other than number 19 (the arbitrary ID) and number 22 (the unit setting) are reset to their default values. Further, the tolerance and preset values are cleared. |




5 EJ Counter Parameter Settings


| No. | Set value | Per-axis setting | Set value: Operation | Default value | Description |
|-----|--------------------------------|------------------|--------------------------------|---------------|--|
| 22 | Unit selection (EJ-102NE only) | N/A | 00: mm (mm/s) 01: in (in/s) | 00 | <p>The unit for displayed values can be set to "mm" or "in".</p> <p>Tips</p> <ul style="list-style-type: none">• Changing this setting clears the preset and tolerance values.• The default value is not restored even if the parameters are re-initialized.• The resolution of the Linear Gage is fixed to "in". |

6 Troubleshooting



When this product does not operate as expected, refer to the cause of the trouble and the solutions shown below:

Overall






| Problem | Cause | Solution |
|--|---|--|
| Power does not go on. | The interface unit is not connected to an EJ Counter. | The interface unit draws power from an EJ Counter. Connect it to an EJ Counter. Tips For details, see  "2.1.2 Linking to EJ Counters" on page 21 and "2.3 Power Supply Connection" on page 29. |
| | Power is not supplied to the EJ Counter. | The interface unit draws power from an EJ Counter. Supply power to the EJ Counter. |
| | Power is not properly connected to the EJ Counter's connection plug. | Properly connect the power to the EJ Counter's connection plug. Tips For details, see  the separate "Compact Display Unit for Linear Gage EJ Counter User's Manual". |
| | Power supply capacity is insufficient. | Connect a noise-free power supply with a capacity of 10 V DC–27 V DC (30 W). |
| | You are attempting to supply power via USB. | This product is not designed to receive power via USB bus. Power must be supplied by an EJ Counter. Supply power to the EJ Counter. |
| | The counter or interface unit linkage connector is defective. | Replace the defective counter or interface unit with a good one. |
| The [EJ-CONNECT] indicator does not light. (No communication with the EJ Counter.) | The terminal unit is not connected. | Normal communication requires connection of the terminal unit. Connect the terminal unit. Tips For details, see  "2.1.2 Linking to EJ Counters" on page 21. |
| | The interface unit was connected to the EJ Counter while the EJ Counter's power was on. | The interface unit detects the EJ Counter when its power is switched on. Turn off the power, and then turn it back on again. |
| | Nine or more EJ Counters are linked together. | Turn off the power and then turn it back on after reducing the number of linked EJ Counters to no more than eight. |
| | The counter or interface unit linkage connector is defective. | Replace the defective counter or interface unit with a good one. |


| Problem | Cause | Solution |
|-------------------------------------|---|---|
| The [EJ-CONNECT] indicator flashes. | When setting arbitrary IDs, the same ID was assigned to more than one EJ Counter. | Make parameter settings by key operation, taking care to assign a unique ID to each EJ Counter. |
| Connection lost between units. | DIN rail fixing bracket not installed. | Immobilize the interface unit and EJ Counter(s) using the DIN rail fixing bracket. Tips For details, see  "2.1.3 Attaching the DIN Rail Fixing Bracket" on page 22. |

■ USB communication


| Problem | Cause | Solution |
|-------------------------------------|--|---|
| Unable to connect USB connector. | The USB connector is of the wrong type. | The interface unit uses a Type-C connector. Use a Type-C compatible cable. Tips For details, see  "2.2.1 USB Connection" on page 24. |
| Unable to use USB communication. | Your device uses the wrong communication standard. | This product uses the USB 2.0 Full Speed communication standard and works with Windows 10 standard device drivers. Please verify that your device supports the USB 2.0 Full Speed standard. |
| | Your device has the wrong port setting. | With this interface unit, USB communication uses a virtual COM port. When making port settings on your device, check to make sure the settings work with the application use for communication. |
| Cannot retrieve current value data. | The EJ Counter has thrown an error, and is not counting. | Clear the error on the EJ Counter. Tips For details, see  the separate "Compact Display Unit for Linear Gage EJ Counter User's Manual". |

■ CC-Link communication

| Problem | Cause | Solution |
|--|--|---|
| Communication not working. | Connector plug is improperly wired. | Correctly rewire the connector plug. Tips For details, see  "2.2.2 CC-Link Connection" on page 25. |
| | The terminal resistor is not connected to the terminal device. | Install the provided CC-Link communication terminal resistor. Tips For details, see  "2.2.2 CC-Link Connection" on page 25. |
| | The baud rate setting is incorrect. | Set the baud rate that matches that of the network. Tips For details, see  "● Setting the CC-Link version and baud rate" on page 28. |
| | The baud rate setting was changed after power-on. | Turn off the power, and then turn it back on again. |
| Communication not working ([ERROR] indicator lights or flashes). | Station number settings are incorrect. | Correctly reset the station numbers. The number of stations that can be occupied differs depending on the version. Make sure you are using the correct numbers. Tips For details, see  "● Station number setting" on page 27. |
| | Station number settings were changed after power-on. | Turn off the power, and then turn it back on again. |
| Cannot retrieve current value data. | You are using Ver. 1.10. | Current value data can be transferred using Ver. 2.00. Use Ver. 2.00. |
| | The EJ Counter has thrown an error, and is not counting. | Clear the error on the EJ Counter. Tips For details, see  the separate "Compact Display Unit for Linear Gage EJ Counter User's Manual". |

| Problem | Cause | Solution |
|---------------------------------------|---|--|
| The current value is not as expected. | You may be applying the wrong unit (mm/in). | <p>This product transfers only numeric data, which does not include the unit of measurement. Check the unit setting on the EJ Counter.</p> <p>Tips For details, see  the separate "Compact Display Unit for Linear Gage EJ Counter User's Manual".</p> |
| | The number of digits is wrong. | <p>This interface unit uses a fixed minimum resolution for data transfer. (0.00001 mm or 0.0000001 in) No decimal point is included in send data. Take the above into consideration and convert data as needed.</p> |
| | Negative numbers not properly converted. | <p>This interface unit handles negative numbers as twos complements. Use a suitable method for converting data.</p> |

Tips

For details on handling output errors, see  "3.3 List of USB Communication Errors" on page 40.

7 Specifications

7.1 Basic Specifications

| | | |
|--|---------------------------|---|
| Part No. | | 21HZA186 |
| Product name | | Interface Unit CC-Link |
| Supported interfaces | | USB 2.0 Full Speed |
| | | CC-Link Ver. 1.10 |
| | | CC-Link Ver. 2.00 |
| User interface | Display | POWER (green), RUN (green), ERROR (red), EJ-CONNECT (green) |
| | Switches | Rotary switch x 3 (Station number setting x 2, baud rate setting x 1) |
| Functions | | Common protocol for USB and CC-Link Current value read-out*1, current value hold (software hold), EJ Counter parameter setting, tolerance evaluation setting, preset value setting, preset/zero set clear, peak clear, error clear *1 With CC-Link, only supported by Ver. 2.00. |
| Power supply specifications | Input voltage | 10 V–27 V DC (supplied from EJ Counter) Power cannot be supplied by USB. |
| | Maximum power consumption | Interface unit by itself: 3 W or less With maximum number of linked EJ Counters: 30 W or less (including 8 EJ Counters and 16 Linear Gages) |
| Operating temperature (humidity) range | | 0 °C–50 °C (20% RH–80% RH, without condensation) |
| Storage temperature (humidity) range | | -10 °C–60 °C (20% RH–80% RH, without condensation) |
| CE marking/UKCA marking | | EMC Directive/Electromagnetic Compatibility Regulations: EN IEC 61326-1 Immunity test requirement: Clause 6.2 Table 2 Emission limit: Class A RoHS Directive/The Restriction of the Use of Certain Hazardous Substances in Electrical and Electronic Equipment Regulations: EN IEC 63000 |


7.2 Communication Specification

7.2.1 USB Communication

| Item | | Specifications |
|---------|----------------|------------------------|
| USB 2.0 | Baud rate | Full Speed (12 Mbps)*1 |
| | Port used | Virtual COM port |
| | Connector type | Type-C |

*1 Communication time is 5 to 10 ms when acquiring current values, and 20 to 30 ms when setting EJ Counter parameters (reference values).
Actual times will vary depending on the computer operating environment and conditions of use.

7.2.2 CC-Link Communication

| Item | | Specifications |
|-----------|-----------------------------|--|
| Common | Station type | Remote device station |
| | Connector | 2-piece connector (PHOENIX CONTACT) Socket: MSTB 2,5/ 5-GF-5,08 AU (1876631) Plug: TMSTBP 2,5/ 5-STF-5,08 AU (1908732) Tips Other CC-Link plugs that fit the socket and meet specifications can also be used. For details on plugs that can be used, see  "2.2.2 CC-Link Connection" on page 25. |
| | Communication cable | CC-Link compliant cable |
| Ver. 1.10 | Device type | Generic device (0x7F) |
| | Number of occupied stations | 2 stations RX/RX: 64 each RWw/RWr: 8 words each |
| | Station number setting | 1–63 (set by rotary switch) |
| | Baud rate | 156 Kbps, 625 Kbps, 2.5 Mbps, 5 Mbps, 10 Mbps (set by rotary switch) |
| | Data transferred | Tolerance judgment result |


7 Specifications

| Item | | Specifications |
|-----------|-----------------------------|---|
| Ver. 2.00 | Device type | Generic device (0x7F) |
| | Number of occupied stations | 4 stations RX/RX: 448 each RWw/RWr: 64 words each |
| | Extended cyclic setting | 4x |
| | Station number setting | 1–61 (set by rotary switch) |
| | Baud rate | 156 Kbps, 625 Kbps, 2.5 Mbps, 5 Mbps, 10 Mbps (set by rotary switch) |
| | Data transferred | Tolerance judgment result Current value data (no unit, signed 32-bit data) |

7.3 Outline Dimensional Drawing


■ Main unit dimensions

Unit: mm




■ DIN rail and connector installation dimensional drawing

Unit: mm



■ Maximum configuration dimensional drawing

Unit: mm



SERVICE NETWORK

*As of June 2023

Europe

Mitutoyo Europe GmbH

Borsigstrasse 8-10, 41469 Neuss, GERMANY
TEL: 49 (0)2137 102-0 FAX: 49 (0)2137 102-351

Mitutoyo CTL Germany GmbH

Von-Gunzert-Strasse 17, 78727 Oberndorf, GERMANY
TEL: 49 (0)7423 8776-0 FAX: 49 (0)7423 8776-99

KOMEG Industrielle Messtechnik GmbH

Zum Wasserwerk 3, 66333 Völklingen, GERMANY
TEL: 49 (0)6898 91110 FAX: 49 (0)6898 911100

Germany

Mitutoyo Deutschland GmbH

Borsigstrasse 8-10, 41469 Neuss, GERMANY
TEL: 49 (0)2137 102-0 FAX: 49 (0)2137 86 85

M³ Solution Center Hamburg

Tempowerkring 9-im HIT-Technologiepark 21079
Hamburg, GERMANY
TEL: 49 (0)40 791894-0 FAX: 49 (0)40 791894-50

M³ Solution Center Berlin

Ernst-Lau-Straße 6, 12489 Berlin, GERMANY
TEL: 49 (0)30 2611 267 FAX: 49 30 67988729

M³ Solution Center Eisenach

Neue Wiese 4, 99817 Eisenach, GERMANY
TEL: 49 (0)3691 88909-0 FAX: 49 (0)3691 88909-9

M³ Solution Center Ingolstadt

Marie-Curie-Strasse 1A, 85055 Ingolstadt, GERMANY
TEL: 49 (0)841 954920 FAX: 49 (0)841 9549250

M³ Solution Center Leonberg

Am Längenbühl 3, 71229 Leonberg, GERMANY
TEL: 49 (0)7152 6080-0 FAX: 49 (0)7152 608060

Mitutoyo Deutschland GmbH - Small Tool Sales Division

Heidenheimer Strasse 14, 71229 Leonberg, GERMANY
TEL: 49 (0)7152 9237-0 FAX: 49 (0)7152 9237-29

U.K.

Mitutoyo (UK) Ltd. HQ

Joule Road, West Point Business Park,
Andover, Hampshire SP10 3UX, UNITED KINGDOM
TEL: 44 (0)1264 353123 FAX: 44 (0)1264 354883

Coventry M³ Solution Centre

Unit6, Banner Park, Wickmans Drive, Coventry,
West Midlands CV4 9XA, UNITED KINGDOM
TEL: 44 (0)2476 426300

Halifax M³ Solution Centre

Lowfields Business Park, Navigation Close, Elland,
West Yorkshire HX5 9HB, UNITED KINGDOM
TEL: 44 (0)1422 375566

East Kilbride M³ Solution Centre

The Bairds Building, Rankine Avenue, Scottish
Enterprise Technology Park, East Kilbride G75
0QF, UNITED KINGDOM
TEL: 44 (0)1355 581170

France

Mitutoyo France

Paris Nord 2-123 rue de la Belle Etoile, BP 59267
ROISSY EN FRANCE 95957 ROISSY CDG
CEDEX, FRANCE
TEL: 33 (0)149 38 35 00

M³ Solution Center LYON

Parc Mail 523, cours du 3ème millénaire, 69791
Saint-Priest, FRANCE
TEL: 33 (0)149 38 35 70

M³ Solution Center STRASBOURG

Parc de la porte Sud, Rue du pont du péage,
67118 Geispolsheim, FRANCE
TEL: 33 (0)149 38 35 80

M³ Solution Center CLUSES

290 Avenue des Lacs, 74950 Scionzier,
FRANCE
TEL: 33 (0)1 49 38 35 90

M³ Solution Center TOULOUSE

Aeroparc Saint Martin Cellule B08 ZAC de Saint
Martin du Touch 12 rue de Caulet 31300
Toulouse, FRANCE
TEL: 33 (0)1 49 38 42 90

M³ Solution Center RENNES

2, rue Claude Chappe, PA le Vallon - ZAC
Mivoie, 35230 Noyal-Châtillon-sur-Seiche,
FRANCE
TEL: 33 (0)1 49 38 42 10

Italy

Mitutoyo Italiana S.r.l.

Corso Europa, 7 - 20045 Lainate (MI), ITALY
TEL: 39 02 935781 FAX: 39 02 93578255

M³ Solution Center BOLOGNA

Via dei Carpini1/A - 40011 Anzola Emilia (BO), ITALY
TEL: 39 02 93578215 FAX: 39 02 93578255

M³ Solution Center CHIETI

Contrada Santa Calcagna - 66020 Rocca S. Giovanni (CH), ITALY
TEL: 39 02 93578280 FAX: 39 02 93578255

M³ Solution Center PADOVA

Via G. Galilei 21/F - 35035 Mestrino (PD), ITALY
TEL: 39 02 93578268 FAX: 39 02 93578255

Netherlands

Mitutoyo Nederland B.V.

Storkstraat 30, 3905 KX Veenendaal,
THE NETHERLANDS
TEL: 31(0)318-534911

Mitutoyo Nederland B.V. / M³ Solution Center Enschede

Institutenweg 50, 7521 PK Enschede,
THE NETHERLANDS
TEL: 31(0)318-534911

Mitutoyo Nederland B.V. / M³ Solution Center Eindhoven

De Run 1115, 5503 LB Veldhoven,
THE NETHERLANDS
TEL: 31(0)318-534911

Mitutoyo Research Center Europe B.V.

De Rijn 18, 5684 PJ Best, THE NETHERLANDS
TEL:31(0)499-320200 FAX:31(0)499-320299

Belgium

Mitutoyo Belgium N.V. / M³ Solution Center Melsele

Schaarbeekstraat 20, B-9120 Melsele, BELGIUM
TEL: 32 (0)3-2540444

Sweden

Mitutoyo Scandinavia AB

Släntvägen 6, 194 61 Upplands Väsby, SWEDEN
TEL: 46 (0)8 594 109 50

Mitutoyo Scandinavia AB / M³ Solution Center Alingsås

Ängsvaktaregatan 3A, 441 38 Alingsås, SWEDEN
TEL: 46 (0)8 594 109 50

Mitutoyo Scandinavia AB / M³ Solution Center Värnamo

Kalkstensvägen 7, 331 44 Värnamo, SWEDEN
TEL: 46 (0)8 594 109 50

Switzerland

Mitutoyo (Schweiz) AG

Steinackerstrasse 35, 8902 Urdorf, SWITZERLAND
TEL: 41 (0)447361150

Mitutoyo (Suisse) SA

Rue Galilée 4, 1400 Yverdon-les Bains, SWITZERLAND
TEL: 41 (0)244259422

Poland

Mitutoyo Polska Sp.z o.o.

Ul.Graniczna 8A, 54-610 Wrocław, POLAND
TEL: 48 (0)71354 83 50 FAX: 48 (0)71354 83 55

Czech Republic

Mitutoyo Česko s.r.o.

Dubská 1626, 415 01 Teplice, CZECH REPUBLIC
TEL: 420 417-514-011 Email: info@mitutoyo.cz

Mitutoyo Česko s.r.o. M³ Solution Center Ivančice

Ke Karlovu 62/10, 664 91 Ivančice, CZECH REPUBLIC
TEL: 420 417-514-011 Email: info@mitutoyo.cz

Mitutoyo Česko s.r.o. M³ Solution Center Ostrava Mošnov

Mošnov 314, 742 51 Mošnov, CZECH REPUBLIC
TEL: 420 417-514-050 Email: info@mitutoyo.cz

Mitutoyo Česko s.r.o. Slovakia Branch

Hviezdoslavova 124, 017 01 Povážská Bystrica, SLOVAKIA
TEL: 421 948-595-590 Email: info@mitutoyo.sk

Hungary

Mitutoyo Hungária Kft.

Galamb József utca 9, 2000 Szentendre, HUNGARY
TEL: 36 (30) 6410210

Romania

Mitutoyo Romania SRL

1A Drumul Garii Odai Street, showroom, Ground Floor, 075100 OTOPENI-ILFOV, ROMANIA
TEL: 40 (0)311012088 FAX: +40 (0)311012089

Showroom in Brasov

Strada Ionescu Crum Nr.1, Brasov Business Park Turnul 1, Mezanin, 500446 Brasov-Judetul Brasov, ROMANIA
TEL/FAX: 40 (0)371020017

Finland

Mitutoyo Scandinavia AB Finnish Branch

Vierkiitäjä 2A, 33960, Pirkkala, FINLAND

TEL: 358 (0)40 355 8498

Austria

Mitutoyo Austria GmbH

Salzburger Straße 260 / 3 A-4600 Wels, AUSTRIA

TEL: 43 (0)7242 219 998

Mitutoyo Austria GmbH Goetzis Regional showroom

Lastenstrasse 48a, 6840 Götzis, AUSTRIA

Singapore

Mitutoyo Asia Pacific Pte. Ltd.

Head office / M³ Solution Center

24 Kallang Avenue, Mitutoyo Building,
SINGAPORE 339415

TEL:(65)62942211 FAX:(65)62996666

Malaysia

Mitutoyo (Malaysia) Sdn. Bhd.

Kuala Lumpur Head Office / M³ Solution Center

Mah Sing Integrated Industrial Park, 4, Jalan Utarid U5/14,
Section U5, 40150 Shah Alam, Selangor, MALAYSIA

TEL:(60)3-78459318 FAX:(60)3-78459346

Penang Branch office / M³ Solution Center

30, Persiaran Mahsuri 1/2, Sunway Tunas, 11900
Bayan Lepas, Penang, MALAYSIA

TEL:(60)4-6411998 FAX:(60)4-6412998

Johor Branch office / M³ Solution Center

70 (Ground Floor), Jalan Molek 1/28, Taman
Molek, 81100 Johor Bahru, Johor, MALAYSIA

TEL:(60)7-3521626 FAX:(60)7-3521628

Thailand

Mitutoyo (Thailand) Co., Ltd.

Bangkok Head Office / M³ Solution Center

76/3-5, Chaengwattana Road, Kwaeng Anusaawaree,
Khet Bangkaen, Bangkok 10220, THAILAND

TEL:(66)2080 3500 FAX:(66)2521 6136

Chonburi Branch / M³ Solution Center

7/1, Moo 3, Tambon Bowin, Amphur Sriracha,
Chonburi 20230, THAILAND

TEL:(66)2080 3563 FAX:(66)3834 5788

ACC Branch / M³ Solution Center

122/8, 122/9, Moo 6, Tambon Donhuaroh, Amphur
Muangchonburi, Chonburi 20000, THAILAND

TEL:(66)2080 3565

Indonesia

PT. Mitutoyo Indonesia

Head Office / M³ Solution Center

Jalan Sriwijaya No.26 Desa cibatu Kec. Cikarang
Selatan Kab. Bekasi 17530, INDONESIA

TEL: (62)21-2962 8600 FAX: (62)21-2962 8604

Batam Branch Office

Business Center Adhya Building 3rd Floor Kom-
pleks Permata Niaga Blok A No. 1, Jalan jendral
Sudirman Kelurahan Sukajadi, Kecamatan Bat-
am Kota, Kepulauan Riau 29444, INDONESIA

TEL: (62)-778-4888000

Vietnam

Mitutoyo Vietnam Co., Ltd

Hanoi Head Office / M³ Solution Center

1st & 2nd floor, MHDI Building, No. 60 Hoang Quoc
Viet Road, Nghia Do Ward, Cau Giay District, Hanoi,
VIETNAM

TEL:(84)24-3768-8963 FAX:(84)24-3768-8960

Ho Chi Minh City Branch Office / M³ Solution Center

Unit No. B-00.07, Ground Floor, C1 Building, No.
6, Street D9, An Loi Dong Ward, Thu Duc City,
Ho Chi Minh City, VIETNAM

TEL:(84)28-3840-3489 FAX:(84)28-3840-3498

Hai Phong City Branch Office

Room 511, 5th Floor, Thanh Dat 3 Building, No. 4
Le Thanh Tong Street, May To Ward, Ngo Quyen
District, Hai Phong City, VIETNAM

TEL:(84)22-5398-9909

Philippines

Mitutoyo Philippines, Inc.

Head Office / M³ Solution Center

Unit 1B & 2B LTI, Administration Building 1, Annex 1, North
Main Avenue, Laguna Technopark, Binan Laguna 4024,
PHILIPPINES

TEL/FAX:(63) 49 544 0272

India

Mitutoyo South Asia Pvt. Ltd. Head Office

C-122, Okhla Industrial Area, Phase-I,
New Delhi-110 020, INDIA

TEL: (91) 11-40578485/86

MSA Technical Center

Plot no. 65, Ground Floor, Udyog Vihar, Phase-4 Gurga-
on, Haryana - 122016, INDIA

TEL : (91) 124-2340286/287

Mumbai Region Head office

303, Sentinel Hiranandani Business Park Powai,
Mumbai-400 076, INDIA

TEL: (91) 22-25700684/685/837/839

Pune Office / M³ Solution Center

G4/G5, Pride Kumar Senate, Off. Senapati Bapat
Road, Pune-411 016, INDIA

TEL:(91) 20-25660043/44/45

Ahmedabad Office / M³ Solution Center

A-104 & A-105, First Floor, Solitaire Corporate
Park, Near Divya Bhaskar Press, S.G. Road,
Ahmedabad - 380 015, INDIA

TEL: (91) 079 - 29704902/903

Bengaluru Region Head office / M³ Solution Center

116/117-2, Ground Floor, Sy. No. 93 & 94, 3rd
Phase, Peenya Industrial Area, Bengaluru-560
058, INDIA

TEL: (91) 80-25630946/47/48/49

Coimbatore Office

Regus, Srivari Srimath, 3rd Floor, Door No:1045,
Avinashi Road, Coimbatore - 641 018,INDIA

TEL: (91) 9345005663

Chennai Office / M³ Solution Center

No. 624, Anna Salai Teynampet, Chennai-600 018, INDIA

TEL: (91) 44-24328823/24/25

Kolkata Office

Unit No. 1208,Om Tower, 32,J.L.Nehru Road,
Kolkata-700 071, INDIA

TEL: (91) 33-22267088/40060635/22266817

Taiwan**Mitutoyo Taiwan Co., Ltd. / M³ Solution Center Taipei**

4F., No.71, Zhouzi St., Neihu Dist.,Taipei City 114,
TAIWAN

TEL:886(2)5573-5900 FAX:886(2)8752-3267

Taichung Branch / M³ Solution Center Taichung

1F., No. 299, Gaotie 1st Rd., Wuri Dist., Taichung
City 414, TAIWAN

TEL:886(4)2338-6822 FAX:886(4)2338-6722

Kaohsiung Branch / M³ Solution Center Kaohsiung

1F., No.31-1, Haibian Rd., Lingya Dist.,
Kaohsiung City 802, TAIWAN

TEL:886(7)334-6168 FAX:886(7)334-6160

South Korea**Mitutoyo Korea Corporation****Head Office / M³ Solution Center**

(Sanbon-Dong, Geumjeong High View Build.), 6F, 153-8,
Ls-Ro, Gunpo-Si, Gyeonggi-Do, 15808 KOREA

TEL:82(31)361-4200 FAX:82(31)361-4201

Busan Office / M³ Solution Center

(3150-3, Daejeo 2-dong) 8,Yutongdanji 1-ro
49beon-gil, Gangseo-gu, Busan, 46721 KOREA

TEL:82(51)324-0103 FAX:82(51)324-0104

Daegu Office / M³ Solution Center

(Galsan-dong, Daegu Business Center), 301-Ho, 217,
Seongseogongdan-ro, Dalseo-gu, Daegu 42704 KOREA

TEL:82(53)593-5602 FAX:82(53)593-5603

China**Mitutoyo Measuring Instruments (Shanghai) Co., Ltd.**

8th Floor, Tower 1 Lujiazui Jinkong Square
No.1788/1800 Century Ave., Pudong New Dis-
trict, Shanghai 200122, CHINA

TEL:86(21)5836-0718 FAX:86(21)5836-0717

Suzhou Office / M³ Solution Center China (Suzhou)

1/2 Floor, Building 4, No.175 Songbei Road,
Suzhou Free Trade Zone, Suzhou City, Jiangsu
215000, CHINA

TEL:86(512)6522-1790 FAX:86(512)6251-3420

Wuhan Office / M³ Solution Corner

Room 1701, Wuhan Wanda Center, No. 96,
Linjiang Road, Wuchang District, Wuhan
Hubei 430060, CHINA

TEL:86(27)8544-8631 FAX:86(27)8544-6227

Chengdu Office

Room 1-102, 1st Floor, Unit 1, Building 1, No. 24,
Wannian Road (Wannianchang Cool), Chenghua
District, Chengdu City, Sichuan 610056, CHINA

TEL:86(28)8671-8936 FAX:86(28)8671-9086

Hangzhou Office

Room 804, Eastern International Business Cen-
ter Building 1, No.600 Jinsha Road of

Hangzhou Economic and Technological
Development Zone, 310018, CHINA

TEL: 86(571)8288-0319 FAX: 86(571)8288-0320

Tianjin Office / M³ Solution Center China (Tianjin)

Room D 12/F, TEDA Building, No.256 Jie-fang
Nan Road Hexi District,Tianjin 300042, CHINA

TEL:86(22)5888-1700 FAX:86(22)5888-1701

Changchun Office

Room 815, 8F, Building A1, Upper East
International No.3000 Dongsheng Street,
Erdao District, Changchun, Jilin, 130031, CHINA

TEL:86(431)8192-6998 FAX:86(431)8192-6998

Chongqing Office

Room 1312, Building 3, Zhongyu Plaza, No.86,
Hongjin Avenue,Longxi Street, Yubei District,
Chongqing, 400000, CHINA

TEL:86(23)6595-9950 FAX:86(23)6595-9950

Qingdao Office

Room 638, 6F, No.192 Zhengyang Road, Chengyang District, Qingdao, Shandong, 266109, CHINA
TEL:86(532)8096-1936 FAX:86(532)8096-1937

Xi'an Office

Room 805, Xi'an International Trade Center, No. 196 Xiaozhai East Road, Xi'an, 710061, CHINA
TEL:86(29)8538-1380 FAX:86(29)8538-1381

Dalian Office / M³ Solution Center China (Dalian)

Room A-106 Shuijing SOHO, No.16 Harbin Road, Economic Development Zone, Dalian, 116600 CHINA
TEL:86(411)8718 1212 FAX:86(411)8754-7587

Zhengzhou Office

Room1801,18/F,Unit1,Building No.23, Shangwu Inner Ring Road, Zhengdong New District,Zhengzhou City, Henan 450018, CHINA
TEL:86(371)6097-6436 FAX:86(371)6097-6981

Dongguan Office / M³ Solution Center China (Dongguan)

Room 801, No 65, Chang'an Section Guanchang Road, Chang'an Town, Dongguan City, Guangdong 523841, CHINA
TEL:86(769)8541 7715 FAX:86(769)-8541 7745

Fuzhou Office

Unit 03, 7th floor of East Tower, Sansheng International Center, No.118 Wusi Road, Gulou Distrit, Fuzhou City, Fujian 350001, CHINA
TEL: 86 (591) 8761 8095
FAX: 86 (591) 8761 8096

Changsha Office

Room 2207, Building 1, Shiner International Plaza, No. 88, Kaiyuan Middle Road, Changsha City, Hunan 410100, CHINA
TEL: 86 (731) 8401 9276
FAX: 86 (731) 8401 9376

Changzhou Office

Room 1502, Joint Financial Tower, No.255, Tongjiang North Road, Tianning District, Changzhou City, Jiangsu 2130002, CHINA
TEL:86(519)8815 8319 FAX:86(519)8815 8319

Wenzhou Office

Room 512, Building 4, Xinjingdujiayuan, Sanyang Street, Ou Hai District, Wenzhou City, Zhejiang 325014, CHINA
TEL:86(577)8641 5280

Shunde Office

Room 1603, Buliding 26, Vanke Golden Riverside Plaza Phase II, No.13 Mid DeSheng Road, ShunDe District, Foshan City, Guangdong 528300, CHINA
TEL/FAX: 86(757)2228 8621

Mitutoyo Measuring Technology (Suzhou) Co., Ltd.

1/2 Floor, Building 4, No.175 Songbei Road, Suzhou Free Trade Zone, Suzhou City, Jiangsu 215000, CHINA
TEL:86(512)6252-2660 FAX:86(512)6252-2580

USA**Mitutoyo America Corporation**

965 Corporate Blvd., Aurora, IL 60502, U.S.A.
TEL:1-(630)820-9666 Toll Free No. 1-888-648-8869
FAX:1-(630)978-3501

Headquarters (Aurora) / M³ Solution Center

965 Corporate Blvd., Aurora, IL 60502, U.S.A.

Seattle (Renton) Office / M³ Solution Center

1000 SW 34th St. Suite G, Renton, WA 98057 U.S.A.
TEL:1-(888)-648-8869

Houston Office / M³ Solution Center

4560 Kendrick Plaza Drive Suite 120 Houston, TX 77032, U.S.A.
TEL:1-(888)-648-8869 FAX:1-(281)227-0937

Cincinnati (Mason) Office / M³ Solution Center

6220 Hi-Tek Ct., Mason, OH 45040, U.S.A.
TEL:1-(888)-648-8869 FAX:1-(513)754-0718

Detroit (Novi) Office / M³ Solution Center

46850 Magellan Drive, Suite 100 Novi, MI 48377, U.S.A.
TEL:1-(888)-648-8869 FAX: 1-(248)-926-0928

Los Angeles (City of Industry) Office / M³ Solution Center

16925 E. Gale Ave., City of Industry, CA 91745, U.S.A.
TEL:1-(888)-648-8869 FAX:1-(626)369-3352

Charlotte (Huntersville) Office / M³ Solution Center

11515 Vanstory Dr., Suite 140, Huntersville, NC 28078, U.S.A.
TEL:1-(888)-648-8869 FAX:1-(704)875-9273

Boston (Marlborough) Office / M³ Solution Center

753 Forest Street, Suite 110, Marlborough, MA 01752, U.S.A.
TEL:1-(888)648-8869 FAX:1-(508)485-0782

Mitutoyo America Corporation Calibration Lab

965 Corporate Blvd., Aurora, IL 60502, U.S.A.
TEL:1-(888)-648-8869 FAX:1-(630)978-6477

Mituoctyo America Corporation CT-Lab Chicago

965 Corporate Blvd., Aurora, IL 60502, U.S.A.
TEL: 1-(888)-648-8869 FAX: 1-(630)-820-3418

Mitutoyo Research & Development America, Inc.

11533 NE 118th St., Kirkland,
WA 98034-7111, U.S.A.

TEL:1-(425)821-3906 FAX:1-(425)821-32280

Mitutoyo Research & Development America, Inc. - California Office

16925 Gale Ave. City of Industry,
CA 91745-1806 U.S.A.

TEL: 1-(425)821-3906 FAX: 1-(425)821-3228

Canada

Mitutoyo Canada Inc.

2121 Meadowvale Blvd., Mississauga,
Ont. L5N 5N1., CANADA

TEL:1-(905)821-1261 FAX:1-(905)821-4968

Montreal Office

7075 Place Robert-Joncas Suite 129, Montreal,
Quebec H4M 2Z2, CANADA

TEL:1-(514)337-5994 FAX:1-(514)337-4498

Brazil

Mitutoyo Sul Americana Ltda.

Head office / M³ Solution Center

Avenida Mimes nº 25 – Loteamento Multivias II,
Jardim Ermida I, CEP 13212-216 Jundiaí - SP,
BRASIL

TEL: 55 (11) 5643-0004/0041

Filial Curitiba / M³ Solution Center

Rua Sergipe, nº 101, Sala A, Bairro Boneca
do Iguaçu, São José dos Pinhais – Paraná –
BRASIL CEP 83040120

TEL: 55 (41) 3534-1728

Argentina

Mitutoyo Sul Americana Ltda.

Argentina Branch / M³ Solution Center

Av. B. Mitre 891/899 – C.P. (B1603CQI)
Vicente López – Pcia. Buenos Aires – ARGENTINA

TEL:54 (11) 4730-1433 FAX:54 (11) 4730-1411

Sucursal Cordoba / M³ Solution Center

Av. Ricchieri 2872 L.4 – Bº Jardim – CP X5014O-
PJ Cordoba, ARGENTINA

TEL:54 (351) 464-4125

Mexico

Mitutoyo Mexicana, S.A. de C.V.

Industria Eléctrica No.15, Parque Industrial, Nau-
calpan de Juárez, Estado de México C.P.53370,
MÉXICO

TEL: 52 (01-55) 5312-5612

FAX: 52 (01-55) 5312-3380

Monterrey Office / M³ Solution Center

Blv. Interamericana No. 103, Parque Industrial
FINSA, C.P. 66636 Apodaca, N.L., MÉXICO

TEL: 52(01-81) 8398-8227/8228/8242/8244

FAX: 52(01-81) 8398-8226

Tijuana Office / M³ Solution Center

Calle José María Velazco 10501-C, Col. Cd. Industrial
Nueva Tijuana, C.P. 22500 Tijuana, B.C., MÉXICO

TEL: 52 (01-664) 647-5024

Querétaro Office / M³ Solution Center

Av. Cerro Blanco No.500-1, Colonia Centro Sur,
Querétaro, Querétaro, C.P. 76090, MÉXICO

TEL: 52 (01-442) 340-8018, 340-8019 and 340-8020

FAX: 52 (01-442) 340-8017

**Mitutoyo Mexicana, S.A. de C.V. Querétaro
Calibration Laboratory**

Av. Cerro Blanco 500 30 Centro Sur,
Querétaro, Querétaro, C.P. 76090, MÉXICO

TEL: 52 (01-442) 340-8018, 340-8019 and 340-8020

FAX: 52 (01-442) 340-8017

Aguascalientes Office / M³ Solution Center

Av. Aguascalientes No. 622, Local 15 Centro Comer-
cial El Cilindro Fracc. Pulgas Pandas Norte, C.P.
20138, Aguascalientes, Ags. MÉXICO

TEL: 52 (01-449) 174-4140 and 174-4143

Irapuato Office / M³ Solution Center

Boulevard a Villas de Irapuato No. 1460 L.1 Col. Ejido
Irapuato C.P. 36643

Irapuato, Gto., MÉXICO

TEL: 52 (01-462) 144-1200 and 144-1400

Revision Record

| Date of publication | Revision status | Details of revision |
|---------------------|------------------------|---|
| October 1, 2020 | First edition | Publication |
| December 1, 2021 | Revised first edition | Changes in orthography and expressions Additions and changes due to the application of the UKCA (UK Conformity Assessed) marking |
| January 1, 2024 | Revised second edition | Revision due to changes of the harmonized European standards, etc. |

Mitutoyo Corporation

20-1, Sakado 1-Chome, Takatsu-ku, Kawasaki-shi, Kanagawa 213-8533, Japan
Tel: +81 (0)44 813-8230 Fax: +81 (0)44 813-8231
Home page: <https://www.mitutoyo.co.jp/global.html>

For the EU Directive, Authorized representative and importer in the EU:
Mitutoyo Europe GmbH
Borsigstrasse 8-10, 41469 Neuss, Germany

For the UK Regulation, Authorized representative and importer in the UK:
Mitutoyo (UK) Ltd.
Joule Road, West Point Business Park, Andover, Hampshire SP10 3UX, UNITED KINGDOM