



Interface Unit USB for EJ Counter



User's Manual - Instructions for use -

Read this document thoroughly before operating the product. After reading, retain it close at hand for future reference.

This English language version of the document contains the original instructions.

- For the related User's Manuals, see "■ Positioning of this document, document map" on page 1".

No. 99MBC142A2
Date of publication: January 1, 2024



■ Product names and model numbers covered in this document

● Product name

Product name	Interface Unit USB for EJ Counter
--------------	-----------------------------------

■ Notice regarding this document

- Mitutoyo Corporation assumes no responsibilities for any damage to the product, caused by its use not conforming to the procedure described in this document.
- In the event of loss or damage to this document, immediately contact the agent where you purchased the product or a Mitutoyo sales office.
- Read this document thoroughly before operating the product. In particular, be sure to fully understand “Safety Precautions” on page 6 and “Precautions for Use” on page 6.
- The contents of this document are based on information current as of January 2024.
- No part or whole of this document may be transmitted or reproduced by any means without prior written permission of Mitutoyo Corporation.
- Some screen displays in this document may be highlighted, simplified or partially omitted for convenience of explanation. In addition, some of them may differ from actual ones to the extent that no user will misunderstand the functions and operations.
- The corporation, organization and product names that appear in this document are their trademarks or registered trademarks.

©2020-2024 Mitutoyo Corporation. All rights reserved.

Contents

Contents	i
About This Document	1
Conventions Used in This Document	3
Safety Precautions	6
Precautions for Use	6
Electromagnetic Compatibility (EMC)	8
Export Control Compliance	8
Notes on Export to European Countries	8
Disposal of Products outside the European Countries	8
Disposal of Old Electrical & Electronic Equipment (Applicable in the European Countries with Separate Collection Systems)	9
China RoHS Compliance Information	9
Warranty	10
Disclaimer	10
 1 Overview	 11
1.1 Main Functions and Features	12
1.2 System Configuration	13
1.3 Part Names	14
1.3.1 Main Unit	14
1.3.2 Front Panel	15
1.4 Standard Accessories	16
1.5 Operation Flow	17
 2 Setup	 19
2.1 Mounting	20
2.1.1 DIN Rail Attachment / Removal	20
2.1.2 Linking to EJ Counters	21
2.1.3 Attaching the DIN Rail Fixing Bracket	22
2.2 Connection of External Devices	24

2.3	Power Supply Connection	25
2.3.1	Ground Connection	25
2.3.2	Power ON/OFF	26
3	USB Communication	27
3.1	USB Specifications	28
3.2	USB Communication Format	29
3.2.1	ID Number Assignment During USB Communication	29
3.2.2	Send and Receive Data Format	30
3.2.3	List of Commands	32
3.3	List of USB Communication Errors	36
3.3.1	Interface Unit Communications Error Flags	36
3.3.2	EJ Counter Error Flags	37
3.4	Tolerance Judgment Result.....	40
4	EJ Counter Parameter Settings	41
5	Troubleshooting	47
6	Specifications	49
6.1	Basic Specifications	49
6.2	Communication Specification	49
6.3	Outline Dimensional Drawing	50
SERVICE NETWORK		App-1

About This Document

■ Positioning of this document, document map

The position of this document and its relationship to other product documentation are as follows.

● Interface unit manual

Interface Unit
Quick Start Guide

Explains setup, specifications and troubleshooting.
This document is included in the product package
together with the Interface Unit.
(Common to all interface unit models)

Interface Unit USB
User's Manual
(This Document)

This is the User's Manual that explains the Interface
Unit USB in detail.

● Counter manual

EJ Counter
Quick Start Guide

Covers handling precautions, operating procedures,
specifications, troubleshooting for EJ Counters to
which the Interface Unit USB is connected for use. For
details, see EJ Counter User's Manual. This document
is included in the product package together with the EJ
Counter.

EJ Counter
User's Manual

This is the User's Manual that provides a detailed
explanation of the EJ Counter that is connected to the
Interface Unit USB.

Not included with product. Please download the man-
ual from Mitutoyo's web site (<https://manual.mitutoyo.co.jp>).

● Linear Gage manual

LG100
User's Manual

Covers installation procedures, specifications, mainte-
nance and so forth for Linear Gages that can be con-
nected to EJ Counters.

Select and purchase Linear Gages according to your
application.

LG200
User's Manual

LGB
User's Manual

■ Intended readers and purpose of this document

● Intended readers



This manual is intended for customers who are installing or using the Interface Unit USB for EJ Counter for the first time.

● Purpose




The purpose of this document is to help you understand the product overview, functions of each part, procedures for use and care of the product.

Conventions Used in This Document



■ Safety reminder conventions warning against potential hazards

 CAUTION	Indicates a hazard with a low level of risk which, if not avoided, could result in minor or moderate injury .
 NOTICE	Indicates a situation which, if not avoided, may result in property damage .

■ Conventions indicating prohibited and mandatory actions

	Indicates concrete information about prohibited actions.
	Indicates concrete information about mandatory actions.
	Indicates that grounding needs to be implemented.

■ Conventions indicating referential information or reference location

IMPORTANT	Indicates information that must be known when using the product.
Tips	Indicates further information and details relevant for the operating methods and procedures that are explained in that section.
	Indicates reference location if there is information that should be referred to in this document or an extraneous User's Manual. Example: For details about XX, see  "1.3 Part Names" on page 14 in "1 Overview".

■ Other conventions

(): Round brackets	Represent a paraphrase of an immediately preceding phrase or a supplementary explanation.
" ": Double quotation marks	Represent a highlighted phrase. They also indicate an index where information to be referenced is described.
[]: Square brackets	Indicates the name of an operation key.
1, 2, 3	Indicates the order and the contents of tasks.
»	Indicates the action resulted from some operation(s).

■ Example of conventions use

2 Setup

2.1.2 Linking to EJ Counters

Link this product to EJ Counters.
Up to eight EJ Counters can be linked to this product.

Tips

The interface unit is intended for use with the EJ-102N (Code No. 542-080) and EJ-102NE (Code No. 542-081) EJ Counters. These two types of EJ Counters can be used in mixed configurations.


1

Remove the protective covers from the counter linkage connectors of this product and the EJ Counter.

2

Attach this product to the DIN rail on the side facing the EJ Counter's counter linkage connector (male).


Tips

For details, see  "2.1.1 DIN Rail Attachment / Removal" on page 20.

3

Link the product to the EJ Counter.

Slide the product or EJ Counter along the DIN rail to fully mate the counter linkage connector on the product (female) with the counter linkage connector (male) on the EJ Counter.



NOTICE

Do not link more than eight EJ Counters together. Failure to observe this precaution may result in damage.

IMPORTANT

When sliding this product or EJ Counters along the DIN rail, move them slowly.

21

No. 99MBC142A

Indicates an operating procedure to be performed or its outline.

Indicates reference to some other document or section.

Indicates safety information.

Indicates important information that must be known when using the product.

Safety Precautions

Read these "Safety Precautions" thoroughly before operating the product to use it properly. These safety precautions include such information as to prevent injury to the operator and other persons, damage to property and product defects. Be sure to observe these precautions carefully.

■ Precautions for this product

CAUTION



Do not disassemble or modify this product. Otherwise you may be subject to electric shock, and there is a risk of fire due to a short circuit caused by metallic powders that have gotten inside the product.

Precautions for Use

■ Use and handling of the product

- Use this product only by connecting to measuring instruments which supports this product.

Do not use this product for measuring instruments which does not support this product.

For measuring instruments supported by this product, contact the agent where you purchased the product or a Mitutoyo sales office.

- This product is a measuring instrument.

Do not use it for any purposes other than measuring.

- This product is for industrial usage.

Do not use this product for purposes other than for industrial usage.

- The product is a precision instrument.

Handle this product with care. Do not apply excessive shock or force to any of the parts during operation.

■ Environment for placement

This product is designed for indoor use. To ensure that the product is used in a suitable environment, take the following conditions into account when installing it.

- **Vibration**
Install this product in an environment where it will be subject to minimal vibration. Using this product in a place with significant vibration for an extended period of time may result in malfunction of the precision components.
- **Dust**
Dust in the installation site negatively affects the electrical components. Install this product in an environment where it will be subject to minimal dust.
- **Sunlight**
If this product is exposed to direct sunlight, the heat will cause deformations in the main unit, negatively affecting its operation. If installing this product in an environment that is exposed to direct sunlight, such as near a window, is unavoidable, protect it from the sunlight by curtaining it off, etc.
- **Ambient temperature and humidity**
Avoid using the product in any place that is subject to sudden changes in temperature or humidity.

When using this product in the following environments, take necessary shielding measures.

- Where noise is generated due to static electricity, etc.
- Where there is strong electrical field intensity
- Where power wires and motor lines pass nearby
- Where there is risk of direct contact with materials such as chips, cutting fluids or water
- Where there is risk of exposure to radiation
- Where there is the risk of exposure to corrosive gas

■ Maintenance

Do not use organic solvents such as thinner or benzene. Gently wipe dirt off of the product with a soft, tightly woven cloth.

■ Power supply

Be sure to connect this product to ground.

Provide a power supply with capacity sufficient to accommodate switch-on surge current.

Tips

This product is supplied with power by the connected EJ Counter.

Electromagnetic Compatibility (EMC)

This product complies with the EMC Directive and the UK Electromagnetic Compatibility Regulations; however, if this receives electromagnetic interference that exceeds these requirements, it will be out of warranty and require appropriate measures.

This product is an industrial product, and is not intended to be used in residential environment. If this product is used in residential environment, this product may cause electromagnetic interference with other instruments. In such a case, it is required to take appropriate measures for preventing such electromagnetic interference.

Export Control Compliance

This product falls into the Catch-All-Controlled Goods and/or Catch-All-Controlled Technologies (including Programs) under Category 16 of Appended Table 1 of Export Trade Control Order or under Category 16 of Appended Table of Foreign Exchange Control Order, based on Foreign Exchange and Foreign Trade Act of Japan.

If you intend re-export of the product from a country other than Japan, re-sale of the product in a country other than Japan, or re-providing of the technology (including Programs), you shall observe the regulations of your country.

Also, if an option is added or modified to add a function to this product, this product may fall under the category of List-Control Goods, List-Control Technology (including Programs) under Category 1 - 15 of Appended Table 1 of Export Trade Control Order or under Category 1 - 15 of Appended Table of Foreign Exchange Control Order, based on Foreign Exchange and Foreign Trade Act of Japan. In that case, if you intend re-export of the product from a country other than Japan, re-sale of the product in a country other than Japan, or re-providing of the technology (including Programs), you shall observe the regulations of your country. Please contact Mitutoyo in advance.

Notes on Export to European Countries

When you intend exporting of this product to any of the European countries, it may be required to provide User's Manual(s) in English and Declaration of Conformity in English (in some cases, the official language of the country to be exported). For detailed information, please contact Mitutoyo in advance.

Disposal of Products outside the European Countries

Please follow the official instruction in each community and country.

Disposal of Old Electrical & Electronic Equipment (Applicable in the European Countries with Separate Collection Systems)



This symbol on the product or on its packaging is based on WEEE Directive (Directive on Waste Electrical and Electronic Equipment), and this symbol indicates that this product shall not be treated as household waste.



To reduce the environmental impact and minimize the volume of landfills, please cooperate in reuse and recycle.

For how to dispose of the product, please contact the agent where you purchased the product or a Mitutoyo sales office.

China RoHS Compliance Information

This product meets China RoHS requirements. See the table below.

产品中有害物质的名称及含量

部件名称	有害物质					
	铅	汞	镉	六价铬	多溴联苯	多溴二苯醚
	(Pb)	(Hg)	(Cd)	(Cr(VI))	(PBB)	(PBDE)
本体	×	○	○	○	○	○
配件	○	○	○	○	○	○

本表格依据 SJ/T 11364 的规定编制。

○: 表示该有害物质在该部件所有均质材料中的含量均在 GB/T 26572 规定的限量要求以下。

×: 表示该有害物质至少在该部件的某一均质材料中的含量超出 GB/T 26572 规定的限量要求。



环保使用期限标识是根据《电器电子产品有害物质限制使用管理办法》以及《电子电气产品有害物质限制使用标识要求(SJ/T11364—2014)》制定的,适用于中国境内销售的电子电气产品的标识。

电器电子产品只要按照安全及使用说明内容在正常使用情况下,从生产日期算起,在此期限内产品中含有的有毒有害物质不致发生外泄或突变,不致对环境造成严重污染或对其人身、财产造成严重损害。

产品使用后,要废弃在环保使用年限内或者刚到年限的产品,请根据国家标准采取适当的方法进行处置。

另外,此期限不同于质量/功能的保证期限。

Warranty

This product has been manufactured under strict quality management, but should it develop problems within one year of the date of purchase in normal use, repair shall be performed free of charge. Please contact the agent where you purchased the product or Mitutoyo sales representative (📖 "SERVICE NETWORK" on page App-1).

If this product fails or is damaged for any of the following reasons, it will be subject to a repair charge, even if it is still under warranty.

- Failure or damage owing to fair wear and tear
- Failure or damage owing to inappropriate handling, maintenance or repair, or to unauthorized modification
- Failure or damage owing to transport, dropping, or relocation of the product after purchase
- Failure or damage owing to fire, salt, gas, abnormal voltage, lightning surge, or natural disaster
- Failure or damage owing to use in combination with hardware or software other than those designated or permitted by Mitutoyo
- Failure or damage owing to use in ultra-hazardous activities

This warranty is effective only where the product is properly installed and operated in conformance with the instructions in this document within the original country of the installation.

EXCEPT AS SPECIFIED IN THIS WARRANTY, ALL EXPRESS OR IMPLIED CONDITIONS, REPRESENTATIONS, AND WARRANTIES OF ANY NATURE WHATSOEVER INCLUDING, WITHOUT LIMITATION, ANY IMPLIED WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, NONINFRINGEMENT OR WARRANTY ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE, ARE HEREBY EXCLUDED TO THE MAXIMUM EXTENT ALLOWED BY APPLICABLE LAW.

You assume responsibility for all results due to the selection of this product to achieve your intended results.

Disclaimer

IN NO EVENT WILL MITUTOYO, ITS AFFILIATED AND RELATED COMPANIES AND SUPPLIERS BE LIABLE FOR ANY LOST REVENUE, PROFIT, OR DATA, OR FOR SPECIAL, DIRECT, INDIRECT, CONSEQUENTIAL, INCIDENTAL, OR PUNITIVE DAMAGES HOWEVER CAUSED AND REGARDLESS OF THE THEORY OF LIABILITY ARISING OUT OF THE USE OF OR INABILITY TO USE THIS PRODUCT EVEN IF MITUTOYO OR ITS AFFILIATED AND RELATED COMPANIES AND/OR SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

If, notwithstanding the foregoing, Mitutoyo is found to be liable to you for any damage or loss which arises out of or is in any way connected with use of this product by you, in no event shall Mitutoyo's and/or its affiliated and related companies' and suppliers' liability to you, whether in contract, tort (including negligence), or otherwise, exceed the price paid by you for the product only.

The foregoing limitations shall apply even if the above-stated warranty fails of its essential purpose. BECAUSE SOME COUNTRIES, STATES OR JURISDICTIONS DO NOT ALLOW THE EXCLUSION OR THE LIMITATION OF LIABILITY FOR CONSEQUENTIAL OR INCIDENTAL DAMAGES, IN SUCH COUNTRIES, STATES OR JURISDICTIONS, MITUTOYO'S LIABILITY SHALL BE LIMITED TO THE EXTENT PERMITTED BY LAW.

1 Overview

This chapter describes the Interface Unit USB for EJ Counter product overview, name and functions of each part.

1.1	Main Functions and Features	12
1.2	System Configuration	13
1.3	Part Names	14
1.4	Standard Accessories	16
1.5	Operation Flow	17

1.1 Main Functions and Features

This product is an interface unit for use with the EJ Counter.


- This is a compact and space-saving interface unit, which is attached to a DIN rail to be used.
- It supports USB communication.
- Linear Gage measurements read by the EJ Counter can be output to a PC. Also, tolerance judgment results obtained by EJ Counters can be output.
- This product can be coupled to up to eight EJ Counters, allowing data output from up to 16 Linear Gages.
- EJ Counter parameter settings can be made through a PC.
- The LG QuickSetupTool application software (freeware) is used to make EJ Counter settings and display measurements using USB communication.

Tips

Please download the LG QuickSetupTool application from Mitutoyo's web site. (<https://www.mitutoyo.co.jp>)

The LG QuickSetupTool is compatible with the Windows 10 operating system. No assurance is provided of full operability in any given operating environment. While use of this application is free of charge, the user must bear communication charges incurred during download of the software.

1.2 System Configuration




IMPORTANT

Be sure to install the terminal unit.


Normal communication between this product and EJ Counters requires installation of the terminal unit.

Tips

- This product must be connected to an EJ Counter for use. It cannot be used by itself.
- For details on the EJ Counter, see  the separate "Compact Display Unit for Linear Gage EJ Counter User's Manual".
- Select and purchase Linear Gages according to your application.
- A PC must be provided by the customer.


1.3 Part Names

1.3.1 Main Unit









No.	Name	Description
①	Connector for linking counter	Connect to an EJ Counter.
②	Grounding terminal	Connect to ground using the provided ground wire. Tips <ul style="list-style-type: none">• The provided ground wire is to be used only for connecting the ground terminal on the interface unit to the ground terminal on the EJ Counter.• Overall grounding of coupled units is to be made using the ground wire provided with the EJ Counter. For details, see the separate "Compact Display Unit for Linear Gage EJ Counter User's Manual".
③	DIN rail attachment point	Used for attaching this product to a DIN rail.

1.3.2 Front Panel




No.	Name	Description
①	[POWER] indicator	Lights when power is supplied to the unit. Flashes to indicate an error during communication with an EJ Counter.
②	USB connector (Type-C)	Allows USB connection to a PC.

1.4 Standard Accessories

Name	Quantity	Description
DIN rail fixing bracket 	2	<p>Used to fasten the unit and EJ Counter(s) to a DIN rail.</p> <p>Fasten the bracket to the DIN rail using an M4 screw.</p> <p>Tips</p> <p>The screw provided with the bracket is suitable for fastening to a TH35-7.5 rail.</p> <p>For details, see  "2.1.3 Attaching the DIN Rail Fixing Bracket" on page 22.</p>
Terminal unit 	1	<p>The terminal unit is required for communication between this unit and EJ Counters.</p> <p>Connect it to the EJ Counter furthest from the interface unit.</p> <p>IMPORTANT</p> <p>Be sure to install the terminal unit. Normal communication between this product and EJ Counters requires installation of the terminal unit.</p> <p>Tips</p> <p>For details, see  "2.1.2 Linking to EJ Counters" on page 21.</p>
Ground wire 	1	<p>Use this wire to connect the ground terminal on the interface unit to the ground terminal on the EJ Counter.</p> <p>Tips</p> <p>For details, see  "2.3.1 Ground Connection" on page 25.</p>
Quick Start Guide	1	99MBC146B
WEEE User's Manual	1	
Warranty	1	

1.5 Operation Flow

The basic flow of operation is explained below.



MEMO

2 Setup

2.1	Mounting	20
2.2	Connection of External Devices	24
2.3	Power Supply Connection	25

2.1 Mounting

2.1.1 DIN Rail Attachment / Removal

This product is attached to a DIN rail for use.

IMPORTANT

Disconnect the USB cable before attaching this product to or removing it from the DIN rail.


Tips

A DIN rail must be provided by the customer.

Suitable DIN rail type names (IEC 60715): TH35-7.5Al, TH35-7.5Fe, TH35-15Fe


■ Attachment

Press the clip (gray) on the rear side of this product onto the DIN rail, and then hook the clip on the opposite side onto the DIN rail.



■ Removal

Pressing this product in the direction indicated by arrow 1, raise the clip on the opposite side so that it comes clear of the rail.



2.1.2 Linking to EJ Counters

Link this product to EJ Counters.

Up to eight EJ Counters can be linked to this product.

Tips

The interface unit is intended for use with the EJ-102N (Code No. 542-080) and EJ-102NE (Code No. 542-081) EJ Counters. These two types of EJ Counters can be used in mixed configurations.


- 1 Remove the protective covers from the counter linkage connectors of this product and the EJ Counter.**
- 2 Attach this product to the DIN rail on the side facing the EJ Counter's counter linkage connector (male).**

Tips

For details, see  "2.1.1 DIN Rail Attachment / Removal" on page 20.

- 3 Link the product to the EJ Counter.**

Slide the product or EJ Counter along the DIN rail to fully mate the counter linkage connector on the product (female) with the counter linkage connector (male) on the EJ Counter.



NOTICE

Do not link more than eight EJ Counters together. Failure to observe this precaution may result in damage.

IMPORTANT


When sliding this product or EJ Counters along the DIN rail, move them slowly.

4 Attach the provided terminal unit to the counter linkage connector (female) on the EJ Counter.

Connect the terminal unit to the EJ Counter furthest from the Interface Unit USB.

IMPORTANT


Be sure to install the terminal unit. Normal communication between this product and EJ Counters requires installation of the terminal unit.




2.1.3 Attaching the DIN Rail Fixing Bracket

This product and EJ Counters are fastened to the DIN rail using the provided DIN rail fixing brackets.

1 Hook the clip that is closer to the screw hole in the fixing bracket onto the DIN rail, then press toward the opposite side and hook the other clip onto the rail.




2 Slide the fixing bracket along the DIN rail to where it comes in contact with this product.



- 3** Fasten the fixing bracket in place by threading the screw provided with the fixing bracket into the screw hole in the bracket, and then tightening the screw so that it presses against the DIN rail, immobilizing the fixing bracket.

Tips

The screw provided with the bracket is suitable for fastening to a TH35-7.5 rail.
A different screw (M4) must be used for fastening to a TH35-15 rail.



- 4** Repeat step **1** through **3** to attach the other fixing bracket also to the side with the terminal unit.

2.2 Connection of External Devices

Connect this product to the PC using a USB cable.

Use a USB cable to connect the USB connector (Type-C) on the front panel of this product to a USB connector on the PC.


IMPORTANT

For permanent USB cable connection, fasten the cable so that it does not place any strain on the USB connectors.

NOTICE

This product requires a Type-C USB connector.

Note that connectors other than Type-C (such as miniB and microB) cannot be used.



2.3 Power Supply Connection

This section describes the power supply connection procedure.

IMPORTANT

Provide a power supply with capacity sufficient to accommodate switch-on surge current.

Tips

This product is supplied with power by the connected EJ Counter.


2.3.1 Ground Connection

This product is grounded through the connected EJ Counter. Use the provided ground wire for connecting this product to the EJ Counter.




Be sure to connect this product to ground before connecting it to the power supply. Failure to ground the product will make it susceptible to electrical noise.


1 Remove the ground terminal screw.



2 Pass the removed terminal screw through the hole in the ground wire's ring lug, and then loosely fasten the lug to the ground terminal.




- 3 Loosen the ground terminal screw on the adjacent EJ Counter, and then slip the ground wire's fork lug under the head of the screw.



- 4 Firmly tighten the ground terminal screws on this product and the EJ Counter.
- 5 Connect the EJ Counter's ground wire.

Tips


For details on the EJ Counter's ground wire, see  the separate "Compact Display Unit for Linear Gage EJ Counter User's Manual".

2.3.2 Power ON/OFF

This product is not equipped with a power switch. It is supplied with power by the connected EJ Counter. To power the product ON/OFF, either switch the EJ Counter ON/OFF, or connect/disconnect the power cable.

When the power is turned on, an ID number is automatically assigned to the EJ Counter, and then it becomes ready for communication with this product.

Tips

The ID number assigned to EJ Counter differs according to the EJ Counter ID settings. For details, see  "3.2.1 ID Number Assignment During USB Communication" on page 29.

3 USB Communication



3.1	USB Specifications	28
3.2	USB Communication Format	29
3.3	List of USB Communication Errors.....	36
3.4	Tolerance Judgment Result	40

3.1 USB Specifications

The USB interface provided with this product conforms to the USB 2.0 standard (with Full-speed communication).

It communicates using a virtual COM port on a PC.

Tips

- For details on the content of USB communication, see  "3.2.2 Send and Receive Data Format" on page 30 and  "3.2.3 List of Commands" on page 32.
- This product cannot output data directly to a printer.
- USB communication can be performed when power is supplied to this product. Power cannot be supplied through the USB terminal.
- The LG QuickSetupTool application software (freeware) is provided to allow EJ Counter settings and display of measurement values to be done by USB communication.
Please download the software from Mitutoyo's web site. (<https://www.mitutoyo.co.jp>)
Note that the software may not be usable in all environments. Further, Mitutoyo makes no assurance or representation of any kind regarding the fitness or usability of the software. While use of this application is free of charge, the user must bear communication charges incurred during download of the software.

■ Compatible connector

Type-C connector

■ Compatible cable

Cable compatible with Type-C connector

Tips


- No USB cable is provided with this product. Use a commercially available cable.
- The software works with Windows 10 standard device drivers.


3.2 USB Communication Format

3.2.1 ID Number Assignment During USB Communication

During USB communication, ID numbers from 01 to 08 are automatically assigned to EJ Counters in sequence, starting with the device that is adjacent to this product. However, if arbitrary ID numbers (50 to 99) were set for Parameter Number 19 when the product was last powered on, those values are assigned instead.

Tips

For details about setting parameters, see  "4 EJ Counter Parameter Settings" on page 41.



ID numbers are assigned sequentially
(figure shows automatic ID number assignments).

3.2.2 Send and Receive Data Format

■ Send data format (from PC to this product)

Tips

Send data consists of ASCII codes.

● Commands

Commands are made up of three alphanumeric characters.

Example: The command for reading the current value is "GCJ".



● Counter ID and channel (Ch.) numbers

Counter ID and channel numbers are made up of four numeric characters.

The uppermost digit is always 0, followed by two digits indicating the EJ Counter ID, and then a single digit indicating the channel (Ch.).

Example: For an EJ Counter whose ID is 02 on Ch.1, specify "0021".

Tips

- Commands that do not specify an EJ Counter channel (Ch.) should always have "1" as the last digit.
- Use "0011" for commands that do not specify an EJ Counter.
For details, see  "3.2.3 List of Commands" on page 32.
- The content of individual channels are specified by parameter settings.
For details about setting parameters, see  "4 EJ Counter Parameter Settings" on page 41.

● Numeric values (only for commands requiring such values)

When setting preset and tolerance values, use the + or - sign together with 10-digit numbers. The least significant digit corresponds to a resolution of 10 nm (0.0000001 in).

Example 1: To set +10.5 mm, specify "+0001050000".

Example 2: To set -0.001 in, specify "-0000010000".

Tips

- Unit, without decimal point.
- Numeric values must be specified as 10 digits. Pad empty parts with zero (0).
- When setting the resolution of an EJ Counter, any fractional value below the set resolution is discarded.

● Delimiter

Commands are delimited by the 2-byte sequence CRLF ("0x0D 0x0A").

■ Receive data format (to PC from this product)

Tips

Receive data consists of ASCII codes.

● Commands

Commands are made up of three alphanumeric characters.

These are the same as for send commands (except for commands that are undefined).

● Counter ID and channel (Ch.) numbers

Counter ID and channel numbers are made up of four numeric characters.

ID and channel (Ch.) numbers are specified in the same manner as for send data.

However, "0000" is received for commands that do not specify an EJ Counter.

For details, see  "3.2.3 List of Commands" on page 32.

● Numeric values (only for commands requiring such values)

When outputting preset and tolerance values, use the + or - sign together with 10-digit numbers. The least significant digit corresponds to a resolution of 10 nm (0.0000001 in). Values are rounded according to the EJ Counter's resolution setting.

Example 1: To set +10.5 mm, specify "+0001050000".

Example 2: To set -0.001 in, specify "-0000010000".

Tips

- Unit, without decimal point.
- Numeric values must be specified as 10 digits. Pad empty parts with zero (0).
- When setting the resolution of an EJ Counter, any fractional value below the set resolution is discarded.

● Delimiter

Commands are delimited by the 2-byte sequence CRLF ("0x0D 0x0A").

3.2.3 List of Commands


Commands sent from the PC and corresponding content output from this product are explained below.

■ View commands


These commands are used to verify the settings of EJ Counters. They do not affect the EJ Counter settings or display.

Command format ^{*1}	Corresponding output ^{*1*2}	Description
GCJ,****(CRLF)	GCJ,****,(Err-1),+0123456789,(TJ-2),(DataER-2)(CRLF)	Read current values and tolerance judgments ^{*3*4}
GPR,****(CRLF)	GPR,****,(Err-1),+0123456789,(DataER-2)(CRLF)	Read preset values ^{*4}
GS1,****(CRLF)	GS1,****,(Err-1),+0123456789,(DataER-2)(CRLF)	Read tolerance value S1 ^{*4}
GS2,****(CRLF)	GS2,****,(Err-1),+0123456789,(DataER-2)(CRLF)	Read tolerance value S2 ^{*4}
GS3,****(CRLF)	GS3,****,(Err-1),+0123456789,(DataER-2)(CRLF)	Read tolerance value S3 ^{*4}
GS4,****(CRLF)	GS4,****,(Err-1),+0123456789,(DataER-2)(CRLF)	Read tolerance value S4 ^{*4}
GST,****(CRLF)	GST,****,(Err-1),(D-1)(D-2)(D-3)(D-4),(DataER-2)(CRLF)	Read the EJ Counter display state ^{*5}
GER,****(CRLF)	GER,****,(Err-1),(DataC-8),(DataER-2)(CRLF)	Read EJ Counter error flag details ^{*6}
GEH,****(CRLF)	GEH,****,(Err-1),(DataC-8),(DataER-2)(CRLF)	Read the EJ Counter error flag details history ^{*7}
GPM,****,(PMNum-2)(CRLF)	GPM,****,(Err-1),(PMNum-2),(PMDData-2),(DataER-2)(CRLF)	Read EJ Counter parameter settings ^{*8}
FNM,0011(CRLF)	FNM,0000,(Err-1),(Data-1)(CRLF)	Read the number of connected EJ Counters ^{*9}
FCI,0011(CRLF)	FCI,0000,(Err-1),(Data-16)(CRLF)	Reads EJ Counter IDs ^{*10}

*1 "****" indicates the counter ID and channel (Ch.) numbers.

For details, see  "3.2.2 Send and Receive Data Format" on page 30.

*2 "Err-1" is the interface unit's communications error flag.

For details, see  "3.3 List of USB Communication Errors" on page 36.

*3 "TJ-2" is the result of tolerance judgment.

When tolerance judgment is enabled, the result of tolerance judgment is output as a value from L1 to L5.

When tolerance judgment is disabled (when the EJ Counter produces an error), L0 is output.

For details on tolerance judgment result, see  "3.4 Tolerance Judgment Result" on page 40.

*4 Output of data conforming to the settings of EJ Counter Parameter Numbers 03 (display mode selection) and 22 (unit setting).




For details on numeric data output, see  "■ Receive data format (to PC from this product)" on page 31.

*5 "D-1" indicates the display state. "00" indicates standby, "01" indicates count display, and "02" indicates that a parameter preset or tolerance value is being set.

"D-2" indicates peak mode. "00" indicates the current value, "01" indicates MAX (the maximum value), "02" indicates MIN (the minimum value) and "03" indicates TIR (the value of MAX-MIN).

"D-3" indicates the HOLD state. "00" indicates no HOLD, and any other value indicates HOLD.

"D-4" indicates the unit. "00" indicates mm, and "01" indicates inch.

- *6 For details, see  "3.3.2 EJ Counter Error Flags" on page 37.
- *7 The EJ Counter error history contains up to the last four errors, and errors are read out starting with the oldest. Note that the error history is deleted even if the error data is not received by the PC. For details, see  "3.3.2 EJ Counter Error Flags" on page 37.
- *8 For the command's "PMNum-2" parameter, specify the Parameter Number. In the corresponding output, the setting of the specified Parameter Number is output for "PMData-2". For details about parameters, see  "4 EJ Counter Parameter Settings" on page 41.
- *9 "Data-1" is the number of connected EJ Counters (1 to 8).
- *10 ID numbers of connected EJ Counters are output for "Data-16". "FF" is output if no EJ Counter is connected.
For example, if eight EJ Counters with ID numbers 1 to 8 are connected, "0102030405060708" is output, and if three EJ Counters with ID numbers 1, 2 and 51 are connected, "010251FFFFFFFFFFFF" is output.

■ Setting and control commands

These commands are used to change EJ Counter settings and control operation of EJ Counters.

Command format ^{*1}	Corresponding output ^{*1*2}	Description
SPR,****,+0123456789 (CRLF)	SPR,****,(Err-1),+0123456789, (DataER-2)(CRLF)	Write preset values ^{*3}
SS1,****,+0123456789 (CRLF)	SS1,****,(Err-1),+0123456789, (DataER-2)(CRLF)	Write tolerance value S1 ^{*3*4}
SS2,****,+0123456789 (CRLF)	SS2,****,(Err-1),+0123456789, (DataER-2)(CRLF)	Write tolerance value S2 ^{*3*4}
SS3,****,+0123456789 (CRLF)	SS3,****,(Err-1),+0123456789, (DataER-2)(CRLF)	Write tolerance value S3 ^{*3*4}
SS4,****,+0123456789 (CRLF)	SS4,****,(Err-1),+0123456789, (DataER-2)(CRLF)	Write tolerance value S4 ^{*3*4}
SSU,****(CRLF)	SSU,****,(Err-1),(DataER-2)(CRLF)	Cancel the start-up standby state ("-----" display)
SPK,****,(D-2)(CRLF)	SPK,****,(Err-1),(DataC-8), (DataER-2)(CRLF)	Switch the peak mode ^{*5}
SEC,****(CRLF)	SEC,****,(Err-1),(DataER-2)(CRLF)	Clear the EJ Counter error history
PST,****(CRLF)	PST,****,(Err-1),(DataER-2)(CRLF)	Perform presets (set preset values set with the SPR command)
PZS,****(CRLF)	PZS,****,(Err-1),(DataER-2)(CRLF)	Zero current values
PCL,****(CRLF)	PCL,****,(Err-1),(DataER-2)(CRLF)	Clear preset values
PKC,****(CRLF)	PKC,****,(Err-1),(DataER-2)(CRLF)	Clear peak data (MAX and MIN data)
PEC,****(CRLF)	PEC,****,(Err-1),(DataER-2)(CRLF)	Clear errors ^{*6}
PSH,****(CRLF)	PSH,****,(Err-1),(DataER-2)(CRLF)	Hold current value ^{*7}
PCH,****(CRLF)	PCH,****,(Err-1),(DataER-2)(CRLF)	Cancel current value hold ^{*8}
PDA,****(CRLF)	PDA,****,(Err-1),(DataER-2)(CRLF)	Display EJ Counter ID (displays an EJ Counter's ID num- ber for a preset interval)
PDB,****(CRLF)	PDB,****,(Err-1),(DataER-2)(CRLF)	Specify EJ Counter display axis (switches display axes of the cur- rent value on an EJ Counter)
PPM,****,(PMNum-2), (PMDData-2)(CRLF)	PPM,****,(Err-1),(PMNum-2), (PMDData-2),(DataER-2)(CRLF)	Write parameter settings ^{*9}
RST,0011,SRST (CRLF)	RST,0000,(Err-1)(CRLF)	System reset ^{*10}

*1 "****" indicates the counter ID and channel (Ch.) numbers.

For details, see [3.2.2 Send and Receive Data Format] on page 30.

*2 "Err-1" is the interface unit's communications error flag.

For details, see [3.3 List of USB Communication Errors] on page 36.

*3 Use the + or - sign and specify 10-digit numbers with no decimal point.

For details on numeric data settings, please see [■ Send data format (from PC to this product)] on page 30.

*4 For 3-step tolerance, set tolerance values S1 and S4. Setting of S2 and S3 and read-out are not possible. Attempting to set S2/S3 or perform read-out will result in setting of an error flag (bit 0 of DataER-2) and transmission of error output "+2147483647".


For 5-step tolerance, set tolerance values S1 through S4.

Set the tolerance values in sequence from S1 to S4 or from S4 to S1.

*5 For "D-2", specify the peak mode.

Specify "00" for the current value, "01" for MAX (the maximum value), "02" for MIN (the minimum value), or "03" for TIR (the value of MAX-MIN).

When the peak mode is set properly, "00000000" is output for "DataC-8".

- *6 Clear the error state after first eliminating the cause of the error.
- *7 The HOLD signal is shared by all linked EJ Counters, and all linked EJ Counters enter the HOLD state.
When canceling HOLD with the PCH command, cancellation is required for EJ Counters on which HOLD is set. Set HOLD against the ID number of the linked EJ Counter that is adjacent to the interface unit.
- *8 The HOLD signal is shared by all linked EJ Counters, and HOLD is canceled for all linked EJ Counters.
Cancel HOLD on EJ Counters for which HOLD was set with the PSH command.
- *9 Specify the Parameter Number for "PMNum-2" and the setting value for "PMDData-2". For details about parameters, see  "4 EJ Counter Parameter Settings" on page 41.
- *10 A software reset is performed on this product and linked EJ Counters. Do not execute this command during while measurement is in progress.

3.3 List of USB Communication Errors

3.3.1 Interface Unit Communications Error Flags

When a communication error is detected by this product, it outputs the communications error flag (Err-1).

■ Communications error flags (Err-1)

Err-1	Description
5	Commands cannot be executed in this state. EJ Counters are in the standby or error state.
4	This indicates an undefined command. The command sent is undefined or its format is incorrect (missing a comma).
3	The data length of the command is incorrect. The command is missing data or includes unneeded data.
2	The command content is incorrect. The command includes an incorrect ID number or channel specification (contains a character other than a numeral).
1	There was an error in communication between the interface unit and EJ Counters. The ID number specified in a command does not belong to a connected EJ Counter.
0	No error

In the event of a command abnormality (undefined command), the response takes the following format.

CER,***,(Err-1)(CRLF)

For example, if the undefined command "GGG" is sent, the response is as follows.

Send command: GGG,0000(CRLF)

Output data: CER,0000,4(CRLF)

3.3.2 EJ Counter Error Flags

These error flags are output when an EJ Counter detects an error.

■ Error flags (DataER-2)

This error flag (DataER-2) is made up of data in hexadecimal notation. Bits that are set to "1" indicate the location of the alarm or error.

Data ER-2	Judgment	Description
bit 0	0: Normal 1: Alarm or error state	Indicates an error in communication between the interface unit and EJ Counters. Whether or not the command was normally executed cannot be determined. Check the command and execute it again.
bit 1		The EJ Counter is in the Busy state. EJ Counter settings are being made by key operation. Commands cannot be executed. Execute the command after putting the EJ Counter in the counting state.
bit 2		The origin of the requested channel has not been detected. Commands cannot be executed. Execute the command again after performing gage origin detection or disabling origin detection.
bit 3		An alarm occurred on the requested channel or both channels. Commands cannot be executed. The flag is set if the EJ Counter is in the Busy state (DataER-2 bit1), its origin has not been detected (DataER-2 bit 2), or it is in the counter stand-by state.
bit 4		A hardware error occurred on the requested channel or both channels.
bit 5		An alarm or hardware error occurred on one of the channels. The flag is set even if the alarm or hardware error occurred on the channel that was not requested. The command is executed if there is no abnormality the requested channel.
bit 6		Fixed to 0
bit 7		Fixed to 0

■ Error flag details (DataC-8)

Error flag details (DataC-8) are made up of data in hexadecimal notation. Bits that are set to "1" indicate the location of the alarm or error.

Data C-8	Judgment	Description	
bit 0	0: Normal 1: Alarm or error state	Alarm	EJ Counter Busy state (EJ Counter settings are being made by key operation). Put the EJ Counter in the counting state.
bit 1			A-axis origin not detected. Go through A-axis origin detection.
bit 2			B-axis origin not detected Go through B-axis origin detection.
bit 3			Counter stand-by state Cancel the counter standby state, putting the EJ Counter in the counting state.
Bits 4 to 7			Fixed to 0
bit 8		Hardware error	A-axis peak detection error (with peak mode only) If this error occurs continuously, verify measurement conditions (such as plunger movement speed).
bit 9			B-axis peak detection error (with peak mode only) If this error occurs continuously, verify measurement conditions (such as plunger movement speed).
bit 10			Ch.1 counter value overflow. Verify preset values.
bit 11			Ch.2 counter value overflow. Verify preset values.
bit 12			A-axis excess speed error. Verify measurement conditions (such as plunger movement speed).
bit 13			B-axis excess speed error. Verify measurement conditions (such as plunger movement speed).
bit 14			No gage head on the A-axis or discontinuity detection error. Verify gage head connection.
bit 15			No gage head on the B-axis or discontinuity detection error. Verify gage head connection.
bit 16			Internal memory abnormality. If operation is not restored upon clearing the error, there may be an internal malfunction.
bit 17			Power supply voltage abnormality. Clear the error after verifying supply of correct voltage.
bit 18			A-axis counter IC reset error. Occurred because a Linear Gage was connected or removed during operation.
bit 19			B-axis counter IC reset error. Occurred because a Linear Gage was connected or removed during operation.
bit 20			A-axis counter IC overflow. Electrical noise could be a problem.
bit 21			B-axis counter IC overflow. Electrical noise could be a problem.

Data C-8	Judgment	Description	
bit 22	0: Normal 1: Alarm or error state	Hardware error	No A-axis origin signal. When using a Linear Gage with origin, check whether the origin signal is disconnected. When using a Linear Gage without origin, set Parameter Number 05 to 0.
bit 23			No B-axis origin signal. When using a Linear Gage with origin, check whether the origin signal is disconnected. When using a Linear Gage without origin, set Parameter Number 05 to 0.
bit 24			Internal memory access error. If operation is not restored upon clearing the error, there may be an internal malfunction.
bit 25			Wrong number of EJ Counters connected (nine or more devices). Turn the power on after reducing the number of connected EJ Counters to no more than eight.
Bits 26 to 31			Fixed to 0

■ EJ Counter error history

If a hardware error occurs, error flag details are stored in the error history in the EJ Counter. Error details are not stored when alarms occur.

The EJ Counter error history holds up to the last four errors, and errors are read out starting with the oldest.


If a hardware error occurs when the error history already contains four errors, the oldest error is discarded.

If the error history is read when there are no errors in the EJ Counter error history, the value 0(0x00000000) is output.


3.4 Tolerance Judgment Result

■ Tolerance judgment output

● 3-step tolerance



● 5-step tolerance




4 EJ Counter Parameter Settings

No.	Set value	Per-axis setting	Set value: Operation	Default value	Description																											
01	Key protect	N/A	00: No key protect 01: Key protect	00	Operation of keys other than those used for setting parameters can be disabled to prevent operation errors. Tips Operation by external input cannot be disabled.																											
02	Origin initialization (Origin clear)	N/A	00: Do not initialize. 01: Initialize.	00	When a Linear Gage with origin mark is connected, the origin can be initialized without cycling on the power.																											
03	Display mode selection	N/A	<table><tr><th>Set value</th><th>Ch.1</th><th>Ch.2</th></tr><tr><td>00</td><td>A-axis counter</td><td>B-axis counter</td></tr><tr><td>01</td><td>Sum (A+B)</td><td>B-axis counter</td></tr><tr><td>02</td><td>Difference (A-B)</td><td>B-axis counter</td></tr><tr><td>03</td><td>A-axis counter</td><td>Sum (A+B)</td></tr><tr><td>04</td><td>A-axis counter</td><td>Difference (A-B)</td></tr><tr><td>05</td><td>A-axis speed</td><td>B-axis speed</td></tr><tr><td>06</td><td>A-axis counter</td><td>A-axis speed</td></tr><tr><td>07</td><td>B-axis counter</td><td>B-axis speed</td></tr></table>	Set value	Ch.1	Ch.2	00	A-axis counter	B-axis counter	01	Sum (A+B)	B-axis counter	02	Difference (A-B)	B-axis counter	03	A-axis counter	Sum (A+B)	04	A-axis counter	Difference (A-B)	05	A-axis speed	B-axis speed	06	A-axis counter	A-axis speed	07	B-axis counter	B-axis speed	00	Selects the values to be displayed on Ch.1 and Ch.2. Tips <ul style="list-style-type: none">When using only the A-axis or the B-axis, set 06 or 07.If the displayed content is the same both before and after changing the setting, the tolerance value, preset value and preset state settings are maintained.In order to set the speed display, set the speed sampling cycle with Parameter Number 17.The speed display unit is mm/s (or in/s). Display of lower digits may be fixed depending on the speed sampling time.When the minimum value (MIN) is selected for Peak mode, the speed display indicates the maximum speed in the reverse direction.Because speed display is simplified, it is not suitable for feedback control.
Set value	Ch.1	Ch.2																														
00	A-axis counter	B-axis counter																														
01	Sum (A+B)	B-axis counter																														
02	Difference (A-B)	B-axis counter																														
03	A-axis counter	Sum (A+B)																														
04	A-axis counter	Difference (A-B)																														
05	A-axis speed	B-axis speed																														
06	A-axis counter	A-axis speed																														
07	B-axis counter	B-axis speed																														

4 EJ Counter Parameter Settings

No.	Set value	Per-axis setting	Set value: Operation	Default value	Description
04	Linear Gage resolution (minimum reading)	✓	00: 0.005 mm (5 μ m), 0.0002 in 01: 0.001 mm (1 μ m), 0.00005 in 02: 0.0005 mm (0.5 μ m), 0.00002 in 03: 0.0001 mm (0.1 μ m), 0.000005 in	01	Set the minimum reading according to the resolution of the connected Linear Gage. Make settings individually for the A-axis and B-axis. Tips <ul style="list-style-type: none"> • Correct values will not be displayed if the settings do not match the resolution of the connected Linear Gage. • The unit for minimum reading is "in" when Parameter Number 22 is set to "1".
05	Origin detection function	N/A	00: Disabled 01: Enabled	00	Selects whether the origin function is enabled or disabled when a Linear Gage with an origin point mark is connected.
06	Counter direction	✓	00: + direction 01: - direction	00	Sets the relationship between the direction in which the numeric value changes and the direction of movement of the Linear Gage plunger. When 00 is set, the numeric value increases as the plunger moves toward top dead center. When 01 is set, the numeric value increases as the plunger moves toward bottom dead center. Make settings individually for the A-axis and B-axis.
07	Origin detection direction	✓	00: + direction 01: - direction	00	When a Linear Gage with an origin mark is connected, selects the direction of the plunger of the Linear Gage for origin detection. Make settings individually for the A-axis and B-axis.

4 EJ Counter Parameter Settings

No.	Set value	Per-axis setting	Set value: Operation	Default value	Description
08	Tolerance judgment setting	N/A	00: 3-step tolerance judgment 01: 5-step tolerance judgment 02: No tolerance judgment	00	<p>Selects whether or not the tolerance judgment function is used.</p> <p>When the tolerance judgment is used, selects the number of steps of tolerance judgment.</p> <p>Tips</p> <p>Changing the settings does not clear tolerance values S1 to S4, which are maintained. However, the following adjustments may be made in the event that the following inconsistencies occur.</p> <p>When the setting is changed from "3-step tolerance" or "No tolerance" to "5-step tolerance":</p> <p>When $S2 < S1$ or $S4 < S2$, S2 is replaced with the value of S1.</p> <p>When $S3 < S1$ or $S4 < S3$, S3 is replaced with the value of S4.</p>
09	Display at startup	N/A	00: Counter stand-by 01: Counter displayed	00	<p>Selects whether to display the standby state or the counter display at startup.</p> <p>Tips</p> <p>For details about screen display in the counter stand-by state, see  the separate "Compact Display Unit for Linear Gage EJ Counter User's Manual".</p>
10	ERR/ALLGO selection (I/O input/output setting)	N/A	00: Used as ERR 01: Used as ALLGO	00	<p>Selects whether to use the ERR or ALLGO signal as the external output function.</p> <p>Tips</p> <p>When multiple EJ Counters are linked together, all of them must have the same setting. Correct output will not be obtained if any of the EJ Counters has a different setting.</p>
11	Channel coupling selection (I/O input/output setting)	N/A	00: Do not couple channels 01: Couple channels	00	<p>Selects whether to couple the 1 or 2 SEL external input signal to the EJ Counter's display channel.</p> <p>Tips</p> <p>The EJ Counter's [SEL/CE] key also works to couple the signal.</p>

4 EJ Counter Parameter Settings

No.	Set value	Per-axis setting	Set value: Operation	Default value	Description
12	Origin re-detection (I/O input/output setting)	N/A	00: Disabled 01: Only effective for the axis that is dependent on the channel selected by 1/2 SEL. 02: Axis dependent on Ch.1 and axis dependent on Ch.2.	00	<p>When setting is enabled, origin re-detection goes on stand-by when the HOLD signal (I/O input) rises. If the HOLD signal rises again while original detection is on stand-by, origin re-detection is canceled.</p> <p>Tips</p> <p>This setting affects all axes related to the specified channel. However, this does not include the axis whose channel is displaying speed.</p> <p>Example:</p> <ul style="list-style-type: none"> • If the channel displaying the sum (A+B) and difference (A-B) is selected, the A-axis and B-axis are affected. • If the channel displaying the B-axis coordinates is selected, the B-axis is affected.
13	Preset by I/O input (I/O input setting)	N/A	00: Executed only for the channel selected by 1/2 SEL. 01: Executed for both channels.	00	Selects whether preset processing by external input is to be applied to just one channel or both channels.
14	Ch affected by the CLEAR signal (I/O input/output setting)	N/A	00: Executed only for the channel selected by 1/2 SEL. 01: Executed for both channels.	00	Selects whether peak clear and error clear are to be applied to just the specified channel or to both channels.
15	Peak value preset	N/A	00: Disabled 01: Enabled	00	<p>Sets whether the peak value is to be set as the standard during peak mode maximum value display or minimum value display.</p> <p>Tips</p> <p>Peak value preset cannot be set during run-out display.</p>
16	Smoothing	N/A	00: No smoothing (update at 5 ms intervals). 01: The average of 16 measurements is displayed (update at 80 ms intervals). 02: The average of 32 measurements is displayed (update at 160 ms intervals).	00	Counter values are averaged to minimize flicker of the lowest-order digit.

4 EJ Counter Parameter Settings




No.	Set value	Per-axis setting	Set value: Operation	Default value	Description
17	Speed sampling cycle	N/A	00: 10 ms 01: 50 ms 02: 100 ms	00	Selects the sampling interval for speed calculation.
18	Hide the lowest-order digit.	N/A	00: Display all digits. 01: Hide the lowest-order digit.	00	Hides the lowest-order digit. However, data output to the optional interface unit includes the lowest-order digit.
19	Arbitrary ID specification	N/A	00 to 49: ID numbers assigned automatically. 50 to 99: Arbitrary ID numbers assigned (ID numbers specified).	01	<p>Set the ID number required when an optional interface unit is connected. When arbitrary ID numbers are set in the range 50 to 99, the ID numbers set are assigned the next time the power is turned on.</p> <p>Tips</p> <ul style="list-style-type: none"> • After setting IDs, be sure to cycle the power off and on or perform a system reset. • When 00 to 49 is set, ID numbers 01 to 08 are automatically reassigned when the power is cycled off and on or after the system is reset. • If the same ID number is arbitrarily assigned to more than one EJ Counter, [EJ-CONNECT] will flash following power-on or system reset and the interface unit will not function properly. This will require checking ID settings at the EJ Counters themselves.
20	Power saving function	N/A	00: Display always lit 01 to 99: Display goes out after the specified interval passes (specify the interval length in minutes).	00	<p>Turning off display minimizes power consumption. Specify the time that elapses between when the last key is pressed until the display goes out (01 to 99 minutes). When display is turned off, press any key to turn it on again.</p> <p>Tips</p> <p>Counter operation for the axes, I/O input and output, and data communication through the optional interface unit continue even when the display is off.</p>
21	Parameter initialization	N/A	00: Do not initialize. 01: Initialize.	00	When this parameter is set to 01, the settings for all parameters other than number 19 (the arbitrary ID) and number 22 (the unit setting) are reset to their default values. Further, the tolerance and preset values are cleared.




4 EJ Counter Parameter Settings

No.	Set value	Per-axis setting	Set value: Operation	Default value	Description
22	Unit selection (EJ-102NE only)	N/A	00: mm (mm/s) 01: in (in/s)	00	<p>The unit for displayed values can be set to "mm" or "in".</p> <p>Tips</p> <ul style="list-style-type: none">• Changing this setting clears the preset and tolerance values.• The default value is not restored even if the parameters are re-initialized.• The resolution of the Linear Gage is fixed to "in".


5 Troubleshooting

When this product does not operate as expected, refer to the cause of the trouble and the solutions shown below:

Problem	Cause	Solution
Power does not go on.	The interface unit is not connected to an EJ Counter.	The interface unit draws power from an EJ Counter. Connect it to an EJ Counter. Tips For details, see  "2.1.2 Linking to EJ Counters" on page 21 and "2.3 Power Supply Connection" on page 25.
	Power is not supplied to the EJ Counter.	The interface unit draws power from an EJ Counter. Supply power to the EJ Counter.
	Power is not properly connected to the EJ Counter's connection plug.	Properly connect the power to the EJ Counter's connection plug. Tips For details, see  the separate "Compact Display Unit for Linear Gage EJ Counter User's Manual".
	Power supply capacity is insufficient.	Connect a noise-free power supply with a capacity of 10 V DC–27 V DC (30 W).
	You are attempting to supply power via USB.	This product is not designed to receive power via USB bus. Power must be supplied by an EJ Counter. Supply power to the EJ Counter.
	The counter or interface unit linkage connector is defective.	Replace the defective counter or interface unit with a good one.
The [POWER] indicator flashes.	The terminal unit is not connected.	Normal communication requires connection of the terminal unit. Connect the terminal unit. Tips For details, see  "2.1.2 Linking to EJ Counters" on page 21.
	The interface unit was connected to the EJ Counter while the EJ Counter's power was on.	The interface unit detects the EJ Counter when its power is switched on. Turn off the power, and then turn it back on again.
	Nine or more EJ Counters are linked together.	Turn off the power and then turn it back on after reducing the number of linked EJ Counters to no more than eight.
	When setting arbitrary IDs, the same ID was assigned to more than one EJ Counter.	Make parameter settings by key operation, taking care to assign a unique ID to each EJ Counter.
	The counter or interface unit linkage connector is defective.	Replace the defective counter or interface unit with a good one.

Problem	Cause	Solution
Connection lost between units.	DIN rail fixing bracket not installed.	Immobilize the interface unit and EJ Counter(s) using the DIN rail fixing bracket. Tips For details, see  "2.1.3 Attaching the DIN Rail Fixing Bracket" on page 22.
Unable to connect USB connector.	The USB connector is of the wrong type.	The interface unit uses a Type-C connector. Use a Type-C compatible cable. Tips For details, see  "2.2 Connection of External Devices" on page 24.
Unable to use USB communication.	Your device uses the wrong communication standard.	This product uses the USB 2.0 Full Speed communication standard and works with Windows 10 standard device drivers. Please verify that your device supports the USB 2.0 Full Speed standard.
	Your device has the wrong port setting.	With this interface unit, USB communication uses a virtual COM port. When making port settings on your device, check to make sure the settings work with the application use for communication.
Cannot retrieve current value data.	The EJ Counter has thrown an error, and is not counting.	Clear the error on the EJ Counter. Tips For details, see  the separate "Compact Display Unit for Linear Gage EJ Counter User's Manual".

Tips

For details on handling output errors, see  "3.3 List of USB Communication Errors" on page 36.

6 Specifications

6.1 Basic Specifications

Part No.		21HZA149
Product name		Interface Unit USB
Supported interfaces		USB 2.0 Full Speed
User interface		POWER indicator (green)
Functions		Current value read-out, current value hold (software hold), EJ Counter parameter setting, tolerance evaluation setting, preset value setting, preset/zero set clear, peak clear, error clear
Power supply specifications	Input voltage	10 V–27 V DC (supplied from EJ Counter) Power cannot be supplied by USB.
	Maximum power consumption	Interface unit by itself: 3 W or less With maximum number of linked EJ Counters: 30 W or less (including 8 EJ Counters and 16 Linear Gages)
Operating temperature (humidity) range		0 °C–50 °C (20% RH–80% RH, without condensation)
Storage temperature (humidity) range		-10 °C–60 °C (20% RH–80% RH, without condensation)
CE marking/UKCA marking		EMC Directive/Electromagnetic Compatibility Regulations: EN IEC 61326-1 Immunity test requirement: Clause 6.2 Table 2 Emission limit: Class A RoHS Directive/The Restriction of the Use of Certain Hazardous Substances in Electrical and Electronic Equipment Regulations: EN IEC 63000

6.2 Communication Specification

Item		Specifications
USB 2.0.	Baud rate	Full Speed (12 Mbps)*1
	Port used	Virtual COM port
	Connector type	Type-C


*1 Communication time is 5 to 10 ms when acquiring current values, and 20 to 30 ms when setting EJ Counter parameters (reference values).

Actual times will vary depending on the computer operating environment and conditions of use.

6.3 Outline Dimensional Drawing


■ Main unit dimensions

Unit: mm




■ DIN rail and connector installation dimensional drawing

Unit: mm



Maximum configuration dimensional drawing

Unit: mm



SERVICE NETWORK

*As of June 2023

Europe

Mitutoyo Europe GmbH

Borsigstrasse 8-10, 41469 Neuss, GERMANY
TEL: 49 (0)2137 102-0 FAX: 49 (0)2137 102-351

Mitutoyo CTL Germany GmbH

Von-Gunzert-Strasse 17, 78727 Oberndorf, GERMANY
TEL: 49 (0)7423 8776-0 FAX: 49 (0)7423 8776-99

KOMEG Industrielle Messtechnik GmbH

Zum Wasserwerk 3, 66333 Völklingen, GERMANY
TEL: 49 (0)6898 91110 FAX: 49 (0)6898 9111100

Germany

Mitutoyo Deutschland GmbH

Borsigstrasse 8-10, 41469 Neuss, GERMANY
TEL: 49 (0)2137 102-0 FAX: 49 (0)2137 86 85

M³ Solution Center Hamburg

Tempowerkring 9-im HIT-Technologiepark 21079
Hamburg, GERMANY
TEL: 49 (0)40 791894-0 FAX: 49 (0)40 791894-50

M³ Solution Center Berlin

Ernst-Lau-Straße 6, 12489 Berlin, GERMANY
TEL: 49 (0)30 2611 267 FAX: 49 30 67988729

M³ Solution Center Eisenach

Neue Wiese 4, 99817 Eisenach, GERMANY
TEL: 49 (0)3691 88909-0 FAX: 49 (0)3691 88909-9

M³ Solution Center Ingolstadt

Marie-Curie-Strasse 1A, 85055 Ingolstadt, GERMANY
TEL: 49 (0)841 954920 FAX: 49 (0)841 9549250

M³ Solution Center Leonberg

Am Längenbühl 3, 71229 Leonberg, GERMANY
TEL: 49 (0)7152 6080-0 FAX: 49 (0)7152 608060

Mitutoyo Deutschland GmbH - Small Tool Sales Division

Heidenheimer Strasse 14, 71229 Leonberg, GERMANY
TEL: 49 (0)7152 9237-0 FAX: 49 (0)7152 9237-29

U.K.

Mitutoyo (UK) Ltd. HQ

Joule Road, West Point Business Park,
Andover, Hampshire SP10 3UX, UNITED KINGDOM
TEL: 44 (0)1264 353123 FAX: 44 (0)1264 354883

Coventry M³ Solution Centre

Unit6, Banner Park, Wickmans Drive, Coventry,
West Midlands CV4 9XA, UNITED KINGDOM
TEL: 44 (0)2476 426300

Halifax M³ Solution Centre

Lowfields Business Park, Navigation Close, Elland,
West Yorkshire HX5 9HB, UNITED KINGDOM
TEL: 44 (0)1422 375566

East Kilbride M³ Solution Centre

The Bairds Building, Rankine Avenue, Scottish
Enterprise Technology Park, East Kilbride G75
0QF, UNITED KINGDOM
TEL: 44 (0)1355 581170

France

Mitutoyo France

Paris Nord 2-123 rue de la Belle Etoile, BP 59267
ROISSY EN FRANCE 95957 ROISSY CDG
CEDEX, FRANCE
TEL: 33 (0)149 38 35 00

M³ Solution Center LYON

Parc Mail 523, cours du 3ème millénaire, 69791
Saint-Priest, FRANCE
TEL: 33 (0)149 38 35 70

M³ Solution Center STRASBOURG

Parc de la porte Sud, Rue du pont du péage,
67118 Geispolsheim, FRANCE
TEL: 33 (0)149 38 35 80

M³ Solution Center CLUSES

290 Avenue des Lacs, 74950 Scionzier,
FRANCE
TEL: 33 (0)1 49 38 35 90

M³ Solution Center TOULOUSE

Aeroparc Saint Martin Cellule B08 ZAC de Saint
Martin du Touch 12 rue de Caulet 31300
Toulouse, FRANCE
TEL: 33 (0)1 49 38 42 90

M³ Solution Center RENNES

2, rue Claude Chappe, PA le Vallon - ZAC
Mivoie, 35230 Noyal-Châtillon-sur-Seiche,
FRANCE
TEL: 33 (0)1 49 38 42 10

Italy

Mitutoyo Italiana S.r.l.

Corso Europa, 7 - 20045 Lainate (MI), ITALY
TEL: 39 02 935781 FAX: 39 02 93578255

M³ Solution Center BOLOGNA

Via dei Carpini1/A - 40011 Anzola Emilia (BO), ITALY
TEL: 39 02 93578215 FAX: 39 02 93578255

M³ Solution Center CHIETI

Contrada Santa Calcagna - 66020 Rocca S. Giovanni (CH), ITALY
TEL: 39 02 93578280 FAX: 39 02 93578255

M³ Solution Center PADOVA

Via G. Galilei 21/F - 35035 Mestrino (PD), ITALY
TEL: 39 02 93578268 FAX: 39 02 93578255

Netherlands

Mitutoyo Nederland B.V.

Storkstraat 30, 3905 KX Veenendaal,
THE NETHERLANDS
TEL: 31(0)318-534911

Mitutoyo Nederland B.V. / M³ Solution Center Enschede

Institutenweg 50, 7521 PK Enschede,
THE NETHERLANDS
TEL: 31(0)318-534911

Mitutoyo Nederland B.V. / M³ Solution Center Eindhoven

De Run 1115, 5503 LB Veldhoven,
THE NETHERLANDS
TEL: 31(0)318-534911

Mitutoyo Research Center Europe B.V.

De Rijn 18, 5684 PJ Best, THE NETHERLANDS
TEL:31(0)499-320200 FAX:31(0)499-320299

Belgium

Mitutoyo Belgium N.V. / M³ Solution Center Melsele

Schaarbeekstraat 20, B-9120 Melsele, BELGIUM
TEL: 32 (0)3-2540444

Sweden

Mitutoyo Scandinavia AB

Släntvägen 6, 194 61 Upplands Väsby, SWEDEN
TEL: 46 (0)8 594 109 50

Mitutoyo Scandinavia AB / M³ Solution Center Alingsås

Ängsvaktaregatan 3A, 441 38 Alingsås, SWEDEN
TEL: 46 (0)8 594 109 50

Mitutoyo Scandinavia AB / M³ Solution Center Värnamo

Kalkstensvägen 7, 331 44 Värnamo, SWEDEN
TEL: 46 (0)8 594 109 50

Switzerland

Mitutoyo (Schweiz) AG

Steinackerstrasse 35, 8902 Urdorf, SWITZERLAND
TEL: 41 (0)447361150

Mitutoyo (Suisse) SA

Rue Galilée 4, 1400 Yverdon-les Bains, SWITZERLAND
TEL: 41 (0)244259422

Poland

Mitutoyo Polska Sp.z o.o.

Ul.Graniczna 8A, 54-610 Wrocław, POLAND
TEL: 48 (0)71354 83 50 FAX: 48 (0)71354 83 55

Czech Republic

Mitutoyo Česko s.r.o.

Dubská 1626, 415 01 Teplice, CZECH REPUBLIC
TEL: 420 417-514-011 Email: info@mitutoyo.cz

Mitutoyo Česko s.r.o. M³ Solution Center Ivančice

Ke Karlovu 62/10, 664 91 Ivančice, CZECH REPUBLIC
TEL: 420 417-514-011 Email: info@mitutoyo.cz

Mitutoyo Česko s.r.o. M³ Solution Center Ostrava Mošnov

Mošnov 314, 742 51 Mošnov, CZECH REPUBLIC
TEL: 420 417-514-050 Email: info@mitutoyo.cz

Mitutoyo Česko s.r.o. Slovakia Branch

Hviezdoslavova 124, 017 01 Povážská Bystrica, SLOVAKIA
TEL: 421 948-595-590 Email: info@mitutoyo.sk

Hungary

Mitutoyo Hungária Kft.

Galamb József utca 9, 2000 Szentendre, HUNGARY
TEL: 36 (30) 6410210

Romania

Mitutoyo Romania SRL

1A Drumul Garii Odai Street, showroom, Ground Floor, 075100 OTOPENI-ILFOV, ROMANIA
TEL: 40 (0)311012088 FAX: +40 (0)311012089

Showroom in Brasov

Strada Ionescu Crum Nr.1, Brasov Business Park Turnul 1, Mezanin, 500446 Brasov-Judetul Brasov, ROMANIA
TEL/FAX: 40 (0)371020017

Finland

Mitutoyo Scandinavia AB Finnish Branch

Vierherkitäjä 2A, 33960, Pirkkala, FINLAND

TEL: 358 (0)40 355 8498

Austria

Mitutoyo Austria GmbH

Salzburger Straße 260 / 3 A-4600 Wels, AUSTRIA

TEL: 43 (0)7242 219 998

Mitutoyo Austria GmbH Goetzis Regional showroom

Lastenstrasse 48a, 6840 Götzis, AUSTRIA

Singapore

Mitutoyo Asia Pacific Pte. Ltd.

Head office / M³ Solution Center

24 Kallang Avenue, Mitutoyo Building,
SINGAPORE 339415

TEL:(65)62942211 FAX:(65)62996666

Malaysia

Mitutoyo (Malaysia) Sdn. Bhd.

Kuala Lumpur Head Office / M³ Solution Center

Mah Sing Integrated Industrial Park, 4, Jalan Utarid U5/14,
Section U5, 40150 Shah Alam, Selangor, MALAYSIA

TEL:(60)3-78459318 FAX:(60)3-78459346

Penang Branch office / M³ Solution Center

30, Persiaran Mahsuri 1/2, Sunway Tunas, 11900
Bayan Lepas, Penang, MALAYSIA

TEL:(60)4-6411998 FAX:(60)4-6412998

Johor Branch office / M³ Solution Center

70 (Ground Floor), Jalan Molek 1/28, Taman
Molek, 81100 Johor Bahru, Johor, MALAYSIA

TEL:(60)7-3521626 FAX:(60)7-3521628

Thailand

Mitutoyo (Thailand) Co., Ltd.

Bangkok Head Office / M³ Solution Center

76/3-5, Chaengwattana Road, Kwaeng Anusaawaree,
Khet Bangkaen, Bangkok 10220, THAILAND

TEL:(66)2080 3500 FAX:(66)2521 6136

Chonburi Branch / M³ Solution Center

7/1, Moo 3, Tambon Bowin, Amphur Sriracha,
Chonburi 20230, THAILAND

TEL:(66)2080 3563 FAX:(66)3834 5788

ACC Branch / M³ Solution Center

122/8, 122/9, Moo 6, Tambon Donhuaroh, Amphur
Muangchonburi, Chonburi 20000, THAILAND

TEL:(66)2080 3565

Indonesia

PT. Mitutoyo Indonesia

Head Office / M³ Solution Center

Jalan Sriwijaya No.26 Desa cibatu Kec. Cikarang
Selatan Kab. Bekasi 17530, INDONESIA

TEL: (62)21-2962 8600 FAX: (62)21-2962 8604

Batam Branch Office

Business Center Adhya Building 3rd Floor Kom-
pleks Permata Niaga Blok A No. 1, Jalan jendral
Sudirman Kelurahan Sukajadi, Kecamatan Bat-
am Kota, Kepulauan Riau 29444, INDONESIA

TEL: (62)-778-4888000

Vietnam

Mitutoyo Vietnam Co., Ltd

Hanoi Head Office / M³ Solution Center

1st & 2nd floor, MHDI Building, No. 60 Hoang Quoc
Viet Road, Nghia Do Ward, Cau Giay District, Hanoi,
VIETNAM

TEL:(84)24-3768-8963 FAX:(84)24-3768-8960

Ho Chi Minh City Branch Office / M³ Solution Center

Unit No. B-00.07, Ground Floor, C1 Building, No.
6, Street D9, An Loi Dong Ward, Thu Duc City,
Ho Chi Minh City, VIETNAM

TEL:(84)28-3840-3489 FAX:(84)28-3840-3498

Hai Phong City Branch Office

Room 511, 5th Floor, Thanh Dat 3 Building, No. 4
Le Thanh Tong Street, May To Ward, Ngo Quyen
District, Hai Phong City, VIETNAM

TEL:(84)22-5398-9909

Philippines

Mitutoyo Philippines, Inc.

Head Office / M³ Solution Center

Unit 1B & 2B LTI, Administration Building 1, Annex 1, North
Main Avenue, Laguna Technopark, Binan Laguna 4024,
PHILIPPINES

TEL/FAX:(63) 49 544 0272

India

Mitutoyo South Asia Pvt. Ltd. Head Office

C-122, Okhla Industrial Area, Phase-I,
New Delhi-110 020, INDIA

TEL: (91) 11-40578485/86

MSA Technical Center

Plot no. 65, Ground Floor, Udyog Vihar, Phase-4 Gurga-
on, Haryana - 122016, INDIA

TEL : (91) 124-2340286/287

Mumbai Region Head office

303, Sentinel Hiranandani Business Park Powai,
Mumbai-400 076, INDIA

TEL: (91) 22-25700684/685/837/839

Pune Office / M³ Solution Center

G4/G5, Pride Kumar Senate, Off. Senapati Bapat
Road, Pune-411 016, INDIA

TEL:(91) 20-25660043/44/45

Ahmedabad Office / M³ Solution Center

A-104 & A-105, First Floor, Solitaire Corporate
Park, Near Divya Bhaskar Press, S.G. Road,
Ahmedabad - 380 015, INDIA

TEL: (91) 079 - 29704902/903

Bengaluru Region Head office / M³ Solution Center

116/117-2, Ground Floor, Sy. No. 93 & 94, 3rd
Phase, Peenya Industrial Area, Bengaluru-560
058, INDIA

TEL: (91) 80-25630946/47/48/49

Coimbatore Office

Regus, Srivari Srimath, 3rd Floor, Door No:1045,
Avinashi Road, Coimbatore - 641 018,INDIA

TEL: (91) 9345005663

Chennai Office / M³ Solution Center

No. 624, Anna Salai Teynampet, Chennai-600 018, INDIA

TEL: (91) 44-24328823/24/25

Kolkata Office

Unit No. 1208,Om Tower, 32,J.L.Nehru Road,
Kolkata-700 071, INDIA

TEL: (91) 33-22267088/40060635/22266817

Taiwan**Mitutoyo Taiwan Co., Ltd. / M³ Solution Center Taipei**

4F., No.71, Zhouzi St., Neihu Dist.,Taipei City 114,
TAIWAN

TEL:886(2)5573-5900 FAX:886(2)8752-3267

Taichung Branch / M³ Solution Center Taichung

1F., No. 299, Gaotie 1st Rd., Wuri Dist., Taichung
City 414, TAIWAN

TEL:886(4)2338-6822 FAX:886(4)2338-6722

Kaohsiung Branch / M³ Solution Center Kaohsiung

1F., No.31-1, Haibian Rd., Lingya Dist.,
Kaohsiung City 802, TAIWAN

TEL:886(7)334-6168 FAX:886(7)334-6160

South Korea**Mitutoyo Korea Corporation****Head Office / M³ Solution Center**

(Sanbon-Dong, Geumjeong High View Build.), 6F, 153-8,
Ls-Ro, Gunpo-Si, Gyeonggi-Do, 15808 KOREA

TEL:82(31)361-4200 FAX:82(31)361-4201

Busan Office / M³ Solution Center

(3150-3, Daejeo 2-dong) 8,Yutongdanji 1-ro
49beon-gil, Gangseo-gu, Busan, 46721 KOREA

TEL:82(51)324-0103 FAX:82(51)324-0104

Daegu Office / M³ Solution Center

(Galsan-dong, Daegu Business Center), 301-Ho, 217,
Seongseogongdan-ro, Dalseo-gu, Daegu 42704 KOREA

TEL:82(53)593-5602 FAX:82(53)593-5603

China**Mitutoyo Measuring Instruments (Shanghai) Co., Ltd.**

8th Floor, Tower 1 Lujiazui Jinkong Square
No.1788/1800 Century Ave., Pudong New Dis-
trict, Shanghai 200122, CHINA

TEL:86(21)5836-0718 FAX:86(21)5836-0717

Suzhou Office / M³ Solution Center China (Suzhou)

1/2 Floor, Building 4, No.175 Songbei Road,
Suzhou Free Trade Zone, Suzhou City, Jiangsu
215000, CHINA

TEL:86(512)6522-1790 FAX:86(512)6251-3420

Wuhan Office / M³ Solution Corner

Room 1701, Wuhan Wanda Center, No. 96,
Linjiang Road, Wuchang District, Wuhan
Hubei 430060, CHINA

TEL:86(27)8544-8631 FAX:86(27)8544-6227

Chengdu Office

Room 1-102, 1st Floor, Unit 1, Building 1, No. 24,
Wannian Road (Wannianchang Cool), Chenghua
District, Chengdu City, Sichuan 610056, CHINA

TEL:86(28)8671-8936 FAX:86(28)8671-9086

Hangzhou Office

Room 804, Eastern International Business Cen-
ter Building 1, No.600 Jinsha Road of

Hangzhou Economic and Technological
Development Zone, 310018, CHINA

TEL: 86(571)8288-0319 FAX: 86(571)8288-0320

Tianjin Office / M³ Solution Center China (Tianjin)

Room D 12/F, TEDA Building, No.256 Jie-fang
Nan Road Hexi District,Tianjin 300042, CHINA

TEL:86(22)5888-1700 FAX:86(22)5888-1701

Changchun Office

Room 815, 8F, Building A1, Upper East
International No.3000 Dongsheng Street,
Erdao District, Changchun, Jilin, 130031, CHINA

TEL:86(431)8192-6998 FAX:86(431)8192-6998

Chongqing Office

Room 1312, Building 3, Zhongyu Plaza, No.86,
Hongjin Avenue,Longxi Street, Yubei District,
Chongqing, 400000, CHINA

TEL:86(23)6595-9950 FAX:86(23)6595-9950

Qingdao Office

Room 638, 6F, No.192 Zhengyang Road, Chengyang District, Qingdao, Shandong, 266109, CHINA
TEL:86(532)8096-1936 FAX:86(532)8096-1937

Xi'an Office

Room 805, Xi'an International Trade Center, No. 196 Xiaozhai East Road, Xi'an, 710061, CHINA
TEL:86(29)8538-1380 FAX:86(29)8538-1381

Dalian Office / M³ Solution Center China (Dalian)

Room A-106 Shuijing SOHO, No.16 Harbin Road, Economic Development Zone, Dalian, 116600 CHINA
TEL:86(411)8718 1212 FAX:86(411)8754-7587

Zhengzhou Office

Room1801,18/F,Unit1,Building No.23, Shangwu Inner Ring Road, Zhengdong New District,Zhengzhou City, Henan 450018, CHINA
TEL:86(371)6097-6436 FAX:86(371)6097-6981

Dongguan Office / M³ Solution Center China (Dongguan)

Room 801, No 65, Chang'an Section Guanchang Road, Chang'an Town, Dongguan City, Guangdong 523841, CHINA
TEL:86(769)8541 7715 FAX:86(769)-8541 7745

Fuzhou Office

Unit 03, 7th floor of East Tower, Sansheng International Center, No.118 Wusi Road, Gulou Distrit, Fuzhou City, Fujian 350001, CHINA
TEL: 86 (591) 8761 8095
FAX: 86 (591) 8761 8096

Changsha Office

Room 2207, Building 1, Shiner International Plaza, No. 88, Kaiyuan Middle Road, Changsha City, Hunan 410100, CHINA
TEL: 86 (731) 8401 9276
FAX: 86 (731) 8401 9376

Changzhou Office

Room 1502, Joint Financial Tower, No.255, Tongjiang North Road, Tianning District, Changzhou City, Jiangsu 2130002, CHINA
TEL:86(519)8815 8319 FAX:86(519)8815 8319

Wenzhou Office

Room 512, Building 4, Xinjingdujiayuan, Sanyang Street, Ou Hai District, Wenzhou City, Zhejiang 325014, CHINA
TEL:86(577)8641 5280

Shunde Office

Room 1603, Buliding 26, Vanke Golden Riverside Plaza Phase II, No.13 Mid DeSheng Road, ShunDe District, Foshan City, Guangdong 528300, CHINA
TEL/FAX: 86(757)2228 8621

Mitutoyo Measuring Technology (Suzhou) Co., Ltd.

1/2 Floor, Building 4, No.175 Songbei Road, Suzhou Free Trade Zone, Suzhou City, Jiangsu 215000, CHINA
TEL:86(512)6252-2660 FAX:86(512)6252-2580

USA**Mitutoyo America Corporation**

965 Corporate Blvd., Aurora, IL 60502, U.S.A.
TEL:1-(630)820-9666 Toll Free No. 1-888-648-8869
FAX:1-(630)978-3501

Headquarters (Aurora) / M³ Solution Center

965 Corporate Blvd., Aurora, IL 60502, U.S.A.

Seattle (Renton) Office / M³ Solution Center

1000 SW 34th St. Suite G, Renton, WA 98057 U.S.A.
TEL:1-(888)-648-8869

Houston Office / M³ Solution Center

4560 Kendrick Plaza Drive Suite 120 Houston, TX 77032, U.S.A.
TEL:1-(888)-648-8869 FAX:1-(281)227-0937

Cincinnati (Mason) Office / M³ Solution Center

6220 Hi-Tek Ct., Mason, OH 45040, U.S.A.
TEL:1-(888)-648-8869 FAX:1-(513)754-0718

Detroit (Novi) Office / M³ Solution Center

46850 Magellan Drive, Suite 100 Novi, MI 48377, U.S.A.
TEL:1-(888)-648-8869 FAX: 1-(248)-926-0928

Los Angeles (City of Industry) Office / M³ Solution Center

16925 E. Gale Ave., City of Industry, CA 91745, U.S.A.
TEL:1-(888)-648-8869 FAX:1-(626)369-3352

Charlotte (Huntersville) Office / M³ Solution Center

11515 Vanstory Dr., Suite 140, Huntersville, NC 28078, U.S.A.
TEL:1-(888)-648-8869 FAX:1-(704)875-9273

Boston (Marlborough) Office / M³ Solution Center

753 Forest Street, Suite 110, Marlborough, MA 01752, U.S.A.
TEL:1-(888)648-8869 FAX:1-(508)485-0782

Mitutoyo America Corporation Calibration Lab

965 Corporate Blvd., Aurora, IL 60502, U.S.A.
TEL:1-(888)-648-8869 FAX:1-(630)978-6477

Mituoctyo America Corporation CT-Lab Chicago

965 Corporate Blvd., Aurora, IL 60502, U.S.A.
TEL: 1-(888)-648-8869 FAX: 1-(630)-820-3418

Mitutoyo Research & Development America, Inc.

11533 NE 118th St., Kirkland,
WA 98034-7111, U.S.A.

TEL:1-(425)821-3906 FAX:1-(425)821-32280

Mitutoyo Research & Development America, Inc. - California Office

16925 Gale Ave. City of Industry,
CA 91745-1806 U.S.A.

TEL: 1-(425)821-3906 FAX: 1-(425)821-3228

Canada

Mitutoyo Canada Inc.

2121 Meadowvale Blvd., Mississauga,
Ont. L5N 5N1., CANADA

TEL:1-(905)821-1261 FAX:1-(905)821-4968

Montreal Office

7075 Place Robert-Joncas Suite 129, Montreal,
Quebec H4M 2Z2, CANADA

TEL:1-(514)337-5994 FAX:1-(514)337-4498

Brazil

Mitutoyo Sul Americana Ltda.

Head office / M³ Solution Center

Avenida Mimes nº 25 – Loteamento Multivias II,
Jardim Ermida I, CEP 13212-216 Jundiaí - SP,
BRASIL

TEL: 55 (11) 5643-0004/0041

Filial Curitiba / M³ Solution Center

Rua Sergipe, nº 101, Sala A, Bairro Boneca
do Iguaçu, São José dos Pinhais – Paraná –
BRASIL CEP 83040120

TEL: 55 (41) 3534-1728

Argentina

Mitutoyo Sul Americana Ltda.

Argentina Branch / M³ Solution Center

Av. B. Mitre 891/899 – C.P. (B1603CQI)
Vicente López – Pcia. Buenos Aires – ARGENTINA

TEL:54 (11) 4730-1433 FAX:54 (11) 4730-1411

Sucursal Cordoba / M³ Solution Center

Av. Ricchieri 2872 L.4 – Bº Jardim – CP X5014O-
PJ Cordoba, ARGENTINA

TEL:54 (351) 464-4125

Mexico

Mitutoyo Mexicana, S.A. de C.V.

Industria Eléctrica No.15, Parque Industrial, Nau-
calpan de Juárez, Estado de México C.P.53370,
MÉXICO

TEL: 52 (01-55) 5312-5612

FAX: 52 (01-55) 5312-3380

Monterrey Office / M³ Solution Center

Blv. Interamericana No. 103, Parque Industrial
FINSA, C.P. 66636 Apodaca, N.L., MÉXICO

TEL: 52(01-81) 8398-8227/8228/8242/8244

FAX: 52(01-81) 8398-8226

Tijuana Office / M³ Solution Center

Calle José María Velazco 10501-C, Col. Cd. Industrial
Nueva Tijuana, C.P. 22500 Tijuana, B.C., MÉXICO

TEL: 52 (01-664) 647-5024

Querétaro Office / M³ Solution Center

Av. Cerro Blanco No.500-1, Colonia Centro Sur,
Querétaro, Querétaro, C.P. 76090, MÉXICO

TEL: 52 (01-442) 340-8018, 340-8019 and 340-8020

FAX: 52 (01-442) 340-8017

**Mitutoyo Mexicana, S.A. de C.V. Querétaro
Calibration Laboratory**

Av. Cerro Blanco 500 30 Centro Sur,
Querétaro, Querétaro, C.P. 76090, MÉXICO

TEL: 52 (01-442) 340-8018, 340-8019 and 340-8020

FAX: 52 (01-442) 340-8017

Aguascalientes Office / M³ Solution Center

Av. Aguascalientes No. 622, Local 15 Centro Comer-
cial El Cilindro Fracc. Pulgas Pandas Norte, C.P.
20138, Aguascalientes, Ags. MÉXICO

TEL: 52 (01-449) 174-4140 and 174-4143

Irapuato Office / M³ Solution Center

Boulevard a Villas de Irapuato No. 1460 L.1 Col. Ejido
Irapuato C.P. 36643

Irapuato, Gto., MÉXICO

TEL: 52 (01-462) 144-1200 and 144-1400

Revision Record

Date of publication	Revision status	Details of revision
October 1, 2020	First edition	Publication
December 1, 2021	Revised first edition	Changes in orthography and expressions Additions and changes due to the application of the UKCA (UK Conformity Assessed) marking
January 1, 2024	Revised second edition	Revision due to changes of the harmonized European standards, etc.

Mitutoyo Corporation

20-1, Sakado 1-Chome, Takatsu-ku, Kawasaki-shi, Kanagawa 213-8533, Japan
Tel: +81 (0)44 813-8230 Fax: +81 (0)44 813-8231
Home page: <https://www.mitutoyo.co.jp/global.html>

For the EU Directive, Authorized representative and importer in the EU:
Mitutoyo Europe GmbH
Borsigstrasse 8-10, 41469 Neuss, Germany

For the UK Regulation, Authorized representative and importer in the UK:
Mitutoyo (UK) Ltd.
Joule Road, West Point Business Park, Andover, Hampshire SP10 3UX, UNITED KINGDOM