



# **Separate Type ABSOLUTE Rotary Encoder**

**ABS OR700**

## **User's Manual - Instructions for use -**

Read this document thoroughly before operating the product. After reading, retain it close at hand for future reference.

This English language version of the document contains the original instructions.

No. 99MBE213A

Date of publication: June 1, 2025 (1)



---

## ■ Product names and model numbers covered in this document

Product name	Model number
Rotary Encoder	ABS OR700

## ■ Notice regarding this document

- Mitutoyo Corporation assumes no responsibilities for any damage to the product, caused by its use not conforming to the procedure described in this document.
- Upon loan or transfer of this product, be sure to attach this document to the product.
- In the event of loss or damage to this document, immediately contact the agent where you purchased the product or a Mitutoyo sales office (☎ "SERVICE NETWORK" on page App-1).
- Read this document thoroughly before operating the product. In particular, be sure to fully understand "Safety Precautions" on page 6 and "Precautions for Use" on page 6.
- The contents of this document are based on information current as of June 2025.
- No part or whole of this document may be transmitted or reproduced by any means without prior written permission of Mitutoyo Corporation.
- Some screen displays in this document may be highlighted, simplified or partially omitted for convenience of explanation. In addition, some of them may differ from actual ones to the extent that no user will misunderstand the functions and operations.
- Acrobat Reader is recommended for viewing PDF user's manuals.
- The corporation, organization and product names that appear in this document are their trademarks or registered trademarks.

©2025 Mitutoyo Corporation. All rights reserved.

---

# Contents

<b>Contents</b> .....	<b>1</b>
<b>About This Document</b> .....	<b>3</b>
<b>Conventions Used in This Document</b> .....	<b>4</b>
<b>Safety Precautions</b> .....	<b>6</b>
<b>Precautions for Use</b> .....	<b>6</b>
<b>Electromagnetic Compatibility (EMC)</b> .....	<b>7</b>
<b>Export Control Compliance</b> .....	<b>7</b>
<b>Notes on Export to European Countries</b> .....	<b>7</b>
<b>Disposal of Products outside the European Countries</b> .....	<b>7</b>
<b>Disposal of Old Electrical &amp; Electronic Equipment (Applicable in the European Countries with Separate Collection Systems)</b> .....	<b>7</b>
<b>China RoHS Compliance Information</b> .....	<b>8</b>
<b>Warranty</b> .....	<b>9</b>
<b>Disclaimer</b> .....	<b>9</b>
<b>1 Overview</b> .....	<b>11</b>
1.1 Features .....	11
1.2 System Configuration and Part Names .....	12
1.3 Flow of Main Tasks .....	13
<b>2 Setup for Installation</b> .....	<b>15</b>
2.1 Checking the Equipment Model .....	15
2.2 Installation Conditions .....	16
2.3 Designing the Encoder Installation Surface .....	17
2.4 Preliminary Preparation .....	18
<b>3 Installation onto the Machine Main Unit</b> .....	<b>19</b>
3.1 Checking the Package Contents .....	19
3.2 Installation Procedure .....	20
3.3 Verifying Installation Surface Dimensions .....	21
3.4 Temporarily Fixing the Stator and Rotor .....	22
3.5 Connecting the PC and Starting the Software .....	25
3.6 Verifying the Rotor Installation Status .....	25

---

3.7	Stator Position Adjustment and Fastening .....	26
3.8	Final Confirmation .....	27
3.9	Cable Handling .....	27
<b>4</b>	<b>Specifications .....</b>	<b>31</b>
4.1	Specifications .....	31
4.2	Feedback Cable .....	33
4.2.1	Mitsubishi Electric Corporation Connector Specifications .....	33
4.2.2	FANUC Corporation Connector Specifications .....	33
4.2.3	Panasonic Corporation Connector Specifications .....	34
4.2.4	Yaskawa Electric Corporation Connector Specifications .....	34
4.2.5	Mitutoyo Connector Specifications (D-SUB15) .....	35
4.2.6	Pigtail cable .....	35
4.3	Calculating Feedback Cable Length .....	36
4.4	Dimensional Drawings .....	37
<b>5</b>	<b>Troubleshooting .....</b>	<b>39</b>
5.1	Alarm Detection Function .....	39
5.2	Alarm Code Details .....	41
5.2.1	For Mitsubishi Electric-Compatible Models .....	41
5.2.2	For FANUC-Compatible Models.....	42
5.2.3	For Panasonic-Compatible Models .....	43
5.2.4	For Yaskawa Electric-Compatible Models .....	44
<b>SERVICE NETWORK</b>	<b>.....</b>	<b>App-1</b>

---

# About This Document

## ■ Positioning of this document

This describes the positioning of this document and its relationship with other installments.

ABS OR700  
User's Manual  
(Simplified Version)

This is a simplified instruction manual. It is included with the ABS OR700.

ABS OR700  
User's Manual  
(This Document)

This manual provides detailed information on hardware specifications and installation procedures for the ABS OR700.

ABS OR700  
Application Software  
User's Manual

This manual explains how to operate the application software. Please download it from our website (<https://www.mitutoyo.co.jp>).

## ■ Intended readers of this document



This manual is intended for users who are operating the ABS OR700 for the first time.

They are also assumed to be able to understand individual instructions by reading the described drawings.




---

# Conventions Used in This Document



## ■ Safety reminder conventions warning against potential hazards

 <b>CAUTION</b>	Indicates a hazard with a low level of risk which, if not avoided, <b>could result in minor or moderate injury.</b>
	Indicates a situation which, if not avoided, <b>may result in property damage.</b>

## ■ Conventions indicating prohibited and mandatory actions

	Indicates concrete information about prohibited actions.
	Indicates concrete information about mandatory actions.
	Indicates that grounding needs to be implemented.

## ■ Conventions indicating referential information or reference location

<b>IMPORTANT</b>	Indicates information that must be known when using the product.
<b>Tips</b>	Indicates further information and details relevant for the operating methods and procedures explained in that section.
	Indicates reference location if there is information that should be referred to in this document or an extraneous User's Manual. Example: For details about XX, see  "1.1 Appellations for Each Part" on page 5 in "1 Overview".

## Other conventions

( ): Round brackets	Represent a paraphrase of an immediately preceding phrase or a supplementary explanation.
" ": Double quotation marks	Represent a highlighted phrase. They also indicate an index where information to be referenced is described.
[ ]: Square brackets	Represents items displayed on the screen (menus, dialogs, buttons, tabs, etc.) and keys on the controller or keyboard. They also indicate an item to be purposely entered or selected by the customer. Furthermore, they indicate key switches on JSBOX (joystick box).
1, 2, 3 1, 2, 3, ...	Indicates the order and the contents of tasks. (1: indicates main tasks, 1: indicates detailed tasks)
»	Indicates the action resulted from some operation(s).

## Example of conventions use

X Operation

---

# X Operation

---

X.X Precautions for Use

**X.X.X Connecting the Power Cable**

Mitutoyo service personnel or the agent where you purchased the product will connect the power cable at the installation of the main unit.

**IMPORTANT**

Use only the power cable that is supplied with this product.

**Tips**

In case of emergency or for maintenance purposes, after unplugging the power cable from the AC inlet, plug it in again.

**X.X.X Mounting the Probe**

Mount the probe onto the probe head by "auto joint connection". This section explains connection procedure.

**CAUTION**

There is a risk of injury due to accidents that accompany the movements of the probe.

!

Turn off the main unit before mounting the probe.

**NOTICE**

There is a risk of damage to this product due to the instability of input signals.

!

Turn off the main unit before mounting the probe even if the input signals are disabled.

- 1 Make sure that the keyway on the rear of the probe is set to the unlock position.
- 2 Align the marks on the probe head and the probe.
- 3 Using the accessory tool, turn the keyway on the rear of the probe to the lock position.

» The probe mounting is completed.

XX

No. XXXXXXXXXXX

Important information

Supplementary information

Indicates an alert.

Indicates an alert.

Indicates an operating procedure to be performed or its outline.

A ">>" mark at the beginning of a sentence indicates the result of an operation.

X

Operation

---

# Safety Precautions

Read these "Safety Precautions" thoroughly before operating the product to use it properly. These safety precautions include such information as to prevent injury to the operator and other persons, damage to property and product defects. Be sure to observe these precautions carefully.

## ■ Precautions for this product

- When installing this product on the machine main unit, make sure that the power to the controller is turned off.
- Tighten the screws on each connection cable connector securely to ensure proper shielding.
- Do not touch the connector terminals as this may cause poor contact.

# Precautions for Use

## ■ Use and handling of the product

- The product is a measurement instrument.  
Do not use it for any other purpose than measurement.
- This product is for industrial usage.  
Do not use this product for purposes other than for industrial usage.
- The product is a precision instrument.  
Use it with extreme caution. Do not apply impact or excessive force to the product's parts during operation.

## ■ Environment for placement

### ● Vibration

To install the product onto a machine main unit, select a location where there is as little vibration as possible.

If the product is used for an extended period of time on a machine where there is a substantial amount of vibration, the built-in precision parts may be damaged, thereby adversely influencing the performance of the unit.

### ● Shock, dust, water protection

Be sure to attach a cover to the stator and rotor to prevent entry of water, oil, and dust, and to protect the product from being bumped by a workpiece.

### ● Ambient temperature and humidity

This product should be operated in an environment as shown below. "Operating environment" refers to the environment in which the rotary encoder is installed when the machine is in operation. Also, avoid using in places where the temperature or humidity changes rapidly.

<b>Operating environment</b>	<b>Temperature: 0 °C–50 °C</b> <b>Humidity: 20 %–80 % RH (non condensing)</b>
------------------------------	--

---

## Electromagnetic Compatibility (EMC)

This product complies with the EMC Directive and the UK Electromagnetic Compatibility Regulations. However, if it is exposed to electromagnetic interference that exceeds the limits specified in these directives and regulations, the warranty will be invalidated and appropriate measures will be required.

This product is an industrial product, and is not intended to be used in residential environment. If this product is used in residential environment, this product may cause electromagnetic interference with other instruments. In such a case, it is required to take appropriate measures for preventing such electromagnetic interference.

## Export Control Compliance

This product falls into the Catch-All-Controlled Goods and/or Catch-All-Controlled Technologies (including Programs) under Category 16 of Appended Table 1 of Export Trade Control Order or under Category 16 of Appended Table of Foreign Exchange Control Order, based on Foreign Exchange and Foreign Trade Act of Japan.

If you intend re-export of the product from a country other than Japan, re-sale of the product in a country other than Japan, or re-providing of the technology (including Programs), you shall observe the regulations of your country.

Also, if an option is added or modified to add a function to this product, this product may fall under the category of List-Control Goods, List-Control Technology (including Programs) under Category 1 - 15 of Appended Table 1 of Export Trade Control Order or under Category 1 - 15 of Appended Table of Foreign Exchange Control Order, based on Foreign Exchange and Foreign Trade Act of Japan. In that case, if you intend re-export of the product from a country other than Japan, re-sale of the product in a country other than Japan, or re-providing of the technology (including Programs), you shall observe the regulations of your country. Please contact Mitutoyo in advance.

## Notes on Export to European Countries

When you intend exporting of this product to any of the European countries, it may be required to provide User's Manual(s) in English and Declaration of Conformity in English (in some cases, the official language of the country to be exported). For detailed information, please contact Mitutoyo in advance.

## Disposal of Products outside the European Countries

Please follow the official instruction in each community and country.

## Disposal of Old Electrical & Electronic Equipment (Applicable in the European Countries with Separate Collection Systems)



This symbol on the product or on its packaging is based on WEEE Directive (Directive on Waste Electrical and Electronic Equipment), and this symbol indicates that this product shall not be treated as household waste.



To reduce the environmental impact and minimize the volume of landfills, please cooperate in reuse and recycle.

For how to dispose of the product, please contact the agent where you purchased the product or a Mitutoyo sales office.

# China RoHS Compliance Information

This product meets China RoHS requirements. See the table below.

## 产品中有害物质的名称及含量

部件名称	有害物质					
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr(VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
本体	○	○	○	○	○	○
电气设备部分	×	○	○	○	○	○
配件	○	○	○	○	○	○

部件名称	有害物质			
	邻苯二甲酸 二正丁酯 (DBP)	邻苯二甲酸 二异丁酯 (DIBP)	邻苯二甲酸 丁基苯酯 (BBP)	邻苯二甲酸 二(2-乙基己)酯 (DEHP)
	本体	○	○	○
电气设备部分	○	○	○	○
配件	○	○	○	○

本表格依据 SJ/T 11364 的规定编制。

○: 表示该有害物质在该部件所有均质材料中的含量均在 GB/T 26572 规定的限量要求以下。

×: 表示该有害物质至少在该部件的某一均质材料中的含量超出 GB/T 26572 规定的限量要求。



环保使用期限标识是根据《电器电子产品有害物质限制使用管理办法》以及《电器电子产品有害物质限制使用标识要求(SJ/T11364-2024)》制定的,适用于中国境内销售的电子电气产品的标识。

电器电子产品只要按照安全及使用说明内容在正常使用情况下,从生产日期算起,在此期限内产品中含有的有毒有害物质不致发生外泄或突变,不致对环境造成严重污染或对其人身、财产造成严重损害。

产品使用后,要废弃在环保使用年限内或者刚到年限的产品,请根据国家标准采取适当的方法进行处置。

另外,此期限不同于质量/功能的保证期限。

---

## Warranty

This product has been manufactured under strict quality management, but should it develop problems within one year of the date of purchase in normal use, repair shall be performed free of charge. Please contact the agent where you purchased the product or a Mitutoyo sales office (☎ “SERVICE NETWORK” on page App-1).

If this product fails or is damaged for any of the following reasons, it will be subject to a repair charge, even if it is still under warranty.

- Failure or damage owing to fair wear and tear
- Failure or damage owing to inappropriate handling, maintenance or repair, or to unauthorized modification
- Failure or damage owing to transport, dropping, or relocation of the product after purchase
- Failure or damage owing to fire, salt, gas, abnormal voltage, lightning surge, or natural disaster
- Failure or damage owing to use in combination with hardware or software other than those designated or permitted by Mitutoyo
- Failure or damage owing to use in ultra-hazardous activities

This warranty is effective only where the product is properly installed and operated in conformance with the instructions in this document within the original country of the installation.

EXCEPT AS SPECIFIED IN THIS WARRANTY, ALL EXPRESS OR IMPLIED CONDITIONS, REPRESENTATIONS, AND WARRANTIES OF ANY NATURE WHATSOEVER INCLUDING, WITHOUT LIMITATION, ANY IMPLIED WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, NONINFRINGEMENT OR WARRANTY ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE, ARE HEREBY EXCLUDED TO THE MAXIMUM EXTENT ALLOWED BY APPLICABLE LAW.

You assume responsibility for all results due to the selection of this product to achieve your intended results.

## Disclaimer

IN NO EVENT WILL MITUTOYO, ITS AFFILIATED AND RELATED COMPANIES AND SUPPLIERS BE LIABLE FOR ANY LOST REVENUE, PROFIT, OR DATA, OR FOR SPECIAL, DIRECT, INDIRECT, CONSEQUENTIAL, INCIDENTAL, OR PUNITIVE DAMAGES HOWEVER CAUSED AND REGARDLESS OF THE THEORY OF LIABILITY ARISING OUT OF THE USE OF OR INABILITY TO USE THIS PRODUCT EVEN IF MITUTOYO OR ITS AFFILIATED AND RELATED COMPANIES AND/OR SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

If, notwithstanding the foregoing, Mitutoyo is found to be liable to you for any damage or loss which arises out of or is in any way connected with use of this product by you, in no event shall Mitutoyo's and/or its affiliated and related companies' and suppliers' liability to you, whether in contract, tort (including negligence), or otherwise, exceed the price paid by you for the product only.

The foregoing limitations shall apply even if the above-stated warranty fails of its essential purpose. BECAUSE SOME COUNTRIES, STATES OR JURISDICTIONS DO NOT ALLOW THE EXCLUSION OR THE LIMITATION OF LIABILITY FOR CONSEQUENTIAL OR INCIDENTAL DAMAGES, IN SUCH COUNTRIES, STATES OR JURISDICTIONS, MITUTOYO'S LIABILITY SHALL BE LIMITED TO THE EXTENT PERMITTED BY LAW.



# 1 Overview

This chapter describes the features of this product, the names and functions of each part, and the main work flow for using this product.

1.1 Features .....	11
1.2 System Configuration and Part Names .....	12
1.3 Flow of Main Tasks .....	13

## 1.1 Features

This product is a rotary encoder for feedback control of rotation angle and rotation speed. It continuously detects and outputs the absolute angle within a single rotation.

Use of an electromagnetic induction detection method ensures that water, oil, and other contaminants do not affect the detection function, and the separate type structure eliminates mechanical contact and deterioration due to wear.



A special adjustment mechanism, tools, and software are available that make it easy to install this product on the machine main unit.

Furthermore, this product supports high-speed serial interface communication of various manufacturers and has the following interface specifications.

- FANUC Corporation Specifications
- Mitsubishi Electric Corporation Specifications
- Yaskawa Electric Corporation Specifications
- Panasonic Corporation Specifications
- Mitutoyo Corporation ENSIS® Specifications
- BiSS Serial Communication

## 1.2 System Configuration and Part Names

The configuration of the ABS OR700 Rotary Encoder and the names of its parts are shown below.




No.	Name
①	Rotor
②	Hexagon socket head bolt M3 x 12 (4 each, prepared by customer)
③	Hexagon socket head bolt M4 x 30 (3 each, included)
④	Adjustment mechanism (3 sets)
④-1	Adjustment bolt
④-2	Lock nut
④-3	Special size flat washer
⑤	Stator
⑥	Detector cable (1 m)
⑦	Output connector
⑧	Gap spacer (optional)
⑨	Clamp socket (optional)
⑩	Anti-rotation socket (optional)
⑪	Positioning pin (2 each, optional)

## 1.3 Flow of Main Tasks


The following chart shows the steps required for preliminary preparation and installation of this product on the machine main unit.

Application software is required for installing and adjusting this product on the machine main unit. Please download the application software from our website (<https://www.mitutoyo.co.jp>) and install it on your PC in advance.

For details, see "1 Overview" in the separate  "ABS OR700 Application Software User's Manual".



### IMPORTANT

- Make sure that the serial numbers of the rotor and stator match the combination listed on the inspection sheet.
- Adjustment tools, a PC, and other equipment are required to install and adjust the stator and rotor.  Refer to "2.4 Preliminary Preparation" on page 18 and prepare the necessary equipment.

**MEMO**

## 2 Setup for Installation

This chapter describes the preliminary preparations for installing this product on the machine main unit.

2.1	Checking the Equipment Model .....	15
2.2	Installation Conditions .....	16
2.3	Designing the Encoder Installation Surface .....	17
2.4	Preliminary Preparation .....	18

### 2.1 Checking the Equipment Model

This section describes the specifications of the rotary encoders indicated by the model numbers. Check that the specifications match those of the equipment to be installed.

Model number	Specifications
ABS OR700-B-23	BiSS interface
ABS OR700-E-23	Mitutoyo ENSIS® high-speed serial interface
ABS OR700-F-23	FANUC Corporation Specifications high-speed serial interface
ABS OR700-M-23	Mitsubishi Electric Corporation Specifications CNC Series high-speed serial interface
ABS OR700-M-23A	Mitsubishi Electric Corporation Specifications MELSERVO high-speed serial interface
ABS OR700-P-23	Panasonic Corporation Specifications MINAS high-speed serial interface
ABS OR700-Y-23	Yaskawa Electric Corporation Specifications $\Sigma$ Series high-speed serial interface

## 2.2 Installation Conditions

### ■ Dust and water protection

The ABS OR700 uses a sensor that is not affected by cutting fluid or dust, but it is not designed to prevent dust from entering between the stator and rotor, so it does not have an IP rating.

Small amounts of cutting fluid or dust on the rotary encoder do not affect its function, but due to its structure, the entry of iron dust may cause serious malfunctions. Therefore, use the device in environments where such exposure is minimized.

Please also note that the scale pattern or stator detection section may be damaged if foreign objects of approximately 0.4 mm in diameter enter the gap between the stator and the rotor during operation.

#### **IMPORTANT**

Be sure to attach a cover to the stator and rotor to prevent entry of contaminants such as water, oil, and dust.

### ■ Magnetism


The ABS OR700 uses a measurement sensor based on electromagnetic induction. Electromagnetic induction is a phenomenon in which applying an electric current to one of two opposing coils generates a magnetic flux, which induces an electric current in the other coil. Using this basic principle, the amount of displacement is calculated from the electric current generated in response to the displacement.

Therefore, if equipment that generates a strong magnetic field (such as a direct drive motor) is located near the rotary encoder, please observe the following precautions during installation:

- If a rotary encoder is to be installed near a direct drive motor, keep it as far removed from magnetic influence as possible.
- If the rotary encoder must be installed near a direct drive motor, choose a location where the magnetic field is 3 mT or less.

## 2.3 Designing the Encoder Installation Surface

Refer to the following figure and "4.4 Dimensional Drawings" on page 37 to design the encoder installation surface.



\*1: The stator is shipped with the step between the stator and rotor installation surfaces adjusted to 17.5 mm.

Even if there is a step difference of  $17.5 \pm 0.5$  mm, the stator can be adjusted and installed using the stator's adjustment mechanism. For details, see "3 Installation onto the Machine Main Unit" on page 19.

\*2: Secure sufficient space for adjustment tools (as shown in the diagram) and the fastening tool (torque wrench).

### IMPORTANT

Be sure to attach a cover to the stator and rotor to prevent entry of contaminants such as water, oil, and dust.

## 2.4 Preliminary Preparation

The following tools and equipment are required to install and adjust the ABS OR700. Please prepare them in advance.

Component		Note
Hexagon socket head bolt M3 x 12 (4 each)	Prepared by customer.	For installing the rotor
Adjustment tool (parts set) The parts set includes the following items. <ul style="list-style-type: none"> <li>• Clamp socket (part no. 06AHN841)</li> <li>• Anti-rotation socket (part no. 06AHN840)</li> <li>• Positioning pin (2 each, part no. 06AHL698)</li> <li>• Gap spacer (part no. 06AHL697)</li> </ul>	Optional	
Hex wrench (2.5 mm) Hex wrench (3.0 mm)	Prepared by customer.	For fastening the rotor For fastening the stator
Torque driver (for 2.5 mm and 3.0 mm socket head bolts) Torque wrench (width across flats: 19 mm)	Prepared by customer.	For torque control
ABS OR700 Application Software		Please download it from our website ( <a href="https://www.mitutoyo.co.jp">https://www.mitutoyo.co.jp</a> ).
Signal conversion unit (parts set) <ul style="list-style-type: none"> <li>• USB-485 DS15P (SYSTEM SACOM Industry Corp.)</li> <li>• USB cable (Type-A)</li> <li>• Connection cable (for servo amplifier connection, D-SUB15 connector)</li> </ul>	Optional	

Set numbers of signal conversion units are as follows.

Set No.	Description
26AAA118	Circular waterproof connector — D-SUB15
26AAA119	Mitsubishi cable
26AAA120	MAT cable
26AAA121	FANUC cable
26AAA122	Yaskawa cable
26AAA221	USB-485 DS15P (conversion unit)

Prepare a PC that satisfies the following conditions.

Item	Specifications
CPU	1 GHz or faster with 2 or more cores on a compatible 64-bit processor
Memory	4 GB or more
Supported operating systems	Windows 11 only
Free disk space required for installation	100 MB
Monitor	1024 x 768 or higher
USB port	USB 2.0 port, 1 each

# 3 Installation onto the Machine Main Unit

This chapter describes the procedures, methods, and precautions required when installing this product onto the machine main unit.

3.1	Checking the Package Contents.....	19
3.2	Installation Procedure .....	20
3.3	Verifying Installation Surface Dimensions .....	21
3.4	Temporarily Fixing the Stator and Rotor .....	22
3.5	Connecting the PC and Starting the Software .....	25
3.6	Verifying the Rotor Installation Status .....	25
3.7	Stator Position Adjustment and Fastening.....	26
3.8	Final Confirmation .....	27
3.9	Cable Handling .....	27

## 3.1 Checking the Package Contents

Before starting installation, make sure that the product package contains all of the following items.


If the specifications of your rotary encode are not as specified or you have any questions, contact your dealer or the nearest Mitutoyo office / service center (☎ "SERVICE NETWORK" on page App-1).

Name	Quantity	Note
Stator	1	Detector cable (1 m)
Adjustment mechanism		Provided attached to the stator.
Adjustment bolt	3	
Lock nut	3	
Washer	3	
Rotor	1	
Hexagon socket head bolt M4 x 30	3	For stator installation (with washers)
Inspection sheet	1	
User's Manual (Simplified Version)	1	No. 99MBE214B
Product warranty card	1	

Serial numbers are indicated on the stator and rotor. Make sure that these numbers match those listed on the inspection sheet.


## 3.2 Installation Procedure

The following chart shows the steps required for installation of this product on the machine main unit.




# 3.3 Verifying Installation Surface Dimensions


Refer to the drawing in "2.3 Designing the Encoder Installation Surface" on page 17 and the tolerance drawing below to check the installation section dimensions.




**Checking shaft runout**



**Checking rotor mounting surface runout**



**Checking step of rotor mounting surface**



**NOTICE**

If the dimensions of the installation section are outside the tolerances specified in the diagram, installation and adjustment as described in this manual may not be possible.


Contact between the rotor and stator may result in damage, so be sure to check.

3 Installation onto the Machine Main Unit

## 3.4 Temporarily Fixing the Stator and Rotor

Install the stator and rotor on the machine main unit and temporarily fix them in place.

### 1 Before installing the stator, adjust the height of the adjustment bolts (3 each).




- ① Loosen the lock nuts.
- ② Turn each adjustment bolt a half turn in the counterclockwise direction.
- ③ Lightly tighten the lock nuts.

For information on how to use the adjustment tool, see "■ How to use the adjustment tool" on page 24.

#### Tips

This procedure is performed to prevent parts from interfering with each other when fixing the rotor and to ensure smooth adjustment.

### 2 Temporarily fix the stator to the main unit using M4 x 30 hexagon socket bolts (3 each, included with the product).




### 3 Fix the rotor with hexagon socket head bolts M3 x 12 (4 each).

When doing so, insert the gap spacer (optional) into the gap.


Item	Fastening screw	Tightening torque
Rotor fastening	Hexagon socket head bolt M3 x 12 (4 each, prepared by customer)	0.6 N·m

#### Tips


To fix the rotor securely, make sure that the gap spacer moves smoothly without resistance.




#### 4 Temporarily adjust the gap between the stator and rotor.



- ① Loosen the lock nuts.
- ② Adjust by turning the adjustment bolts.
- ③ Lightly tighten the lock nuts.
- ④ Remove the gap spacer.

For information on how to use the adjustment tool, see  "■ How to use the adjustment tool" on page 24.




Move the gap spacer to find a position where you feel slight resistance, then temporarily tighten the lock nuts. After temporary tightening, remove the gap spacer.

#### Tips

Perform this procedure with the hexagon socket head bolts (M4 x 30) slightly loosened.  
Starting with adjustment mechanism A, which is farthest from the gap spacer, gradually adjust the gap in sequence.


**5 Temporarily adjust the stator's horizontal position.**

Insert the positioning pins (2 each, optional) into the stator holes, press the positioning pin against the outer circumference of the rotor, and temporarily tighten the three M4 x 30 hexagon socket head bolts. Once the temporary fixation is complete, be sure to remove the positioning pins.



**How to use the adjustment tool**


By changing locations turned with the optional adjustment tool, you can adjust various parts of the adjustment mechanism.



Turning each socket and hex wrench allows you to rotate the highlighted sections of the adjustment mechanism.


**Adjusting height and tilt**

Adjust after gradually loosening lock nut and hexagon socket head bolt.




**Fixing height**

Do after adjusting height and tilt.




**Fixing in position**


Do after adjusting height and tilt and fixing height.



## 3.5 Connecting the PC and Starting the Software

For instructions on using the application software for each task, see the separate  "ABS OR700 Application Software User's Manual".

### 1 Connect this product to the PC and start the application software.



\*1: Circular waterproof connector — D-SUB15

\*2: Circular waterproof connector — Servo amplifier connection connector

\*3: Servo amplifier connection connector — D-SUB15

### 2 On the software screen, select [Mounting Support] and perform the initial setup.

Select an installation position that is at eye level.

### 3 Using the application software, perform the installation and adjustment tasks from "3.6 Verifying the Rotor Installation Status" on page 25 through "3.8 Final Confirmation" on page 27.

## 3.6 Verifying the Rotor Installation Status

Use the application software to verify the rotor installation status. For details, see the separate  "ABS OR700 Application Software User's Manual".


As you slowly rotate the rotor, the software collects data and evaluates the installation status (eccentricity and tilt).

If the installation is determined to be unsatisfactory, you may need to repeat the tasks described in

 "3.3 Verifying Installation Surface Dimensions" on page 21.

## 3.7 Stator Position Adjustment and Fastening

- 1 Use the application software and adjustment tool (optional) to adjust the stator installation position (tilt, height, eccentricity).**


The application software automatically evaluates the installation position. For details, see the separate  "ABS OR700 Application Software User's Manual".

**⚠ CAUTION**

Stator positioning can be adjusted without rotating the rotor. To prevent damage or breakage, do not allow the rotor to rotate automatically during adjustment.

- 2 Once all items are evaluated as Pass, secure the stator with the specified torque.**

When fully tightening the lock nut with a torque wrench, apply the torque wrench to the clamp socket (width across flats: 19 mm). When tightening, apply pressure to hold the anti-rotation socket in place.



Item	Fastening screw	Tightening torque
Stator fastening	Hexagon socket head bolt M4 x 30 (3 each, included)	1.5 N·m
	Adjustment mechanism / lock nut (3 locations) * Turn the adjustment tool (width across flats: 19 mm) with a torque wrench.	3 N·m


**NOTICE**

The installation position of the stator may shift when torque is applied while tightening the lock nut or hexagon socket head bolts. If this occurs, readjust as necessary.

3 Installation onto the Machine Main Unit

## 3.8 Final Confirmation

After completing the adjustment and fastening of the stator installation position, rotate the rotor again according to the navigation instructions in the application software.


Recheck and calibrate positioning of the rotor and stator. For details, see the separate  "ABS OR700 Application Software User's Manual".

### Tips

Calibration: By acquiring and compensating for signal strength, accuracy is improved within a range narrower than the signal period.

Installation adjustment is now complete.


Exit the application software and disconnect the PC.

After performing the tasks described in  "3.9 Cable Handling" on page 27, connect to the servo amplifier.

## 3.9 Cable Handling

After installing the rotor and stator, connect and secure the cables.

### Tips


The feedback cable must be prepared by customer. Refer to  "4.2 Feedback Cable" on page 33 and obtain a cable appropriate for your equipment.

### 1 Arrange the cables carefully to avoid twisting or bending.

#### IMPORTANT


Do not bundle the Detector cable or feedback cable with other cables that are sources of electrical noise, or place them near relays that switch large currents on and off, as this may cause malfunctions due to noise.

### 2 Secure all cables with cable clamps or similar devices.



**Tips**

When installing this product, make sure that the stator and machine main unit are properly grounded. Without grounding, the unit may be affected by external noise. If grounding the stator installation section is difficult, be sure to ground the shield of the cable securely using an earth bar or similar method.




Example: Ground bar usage drawing

**NOTICE**

There is a risk of damage to or disconnection of cables, connectors, or the Detector.


- Take care to prevent **connectors** from being shaken due to vibration.




**NOTICE**

**There is a risk of cable damage or disconnection.**

- If repeated bending of the cable is expected, arrange the cables so that movement is limited to the feedback cable as much as possible, rather than the Detector cable. Please also ensure that no stress is applied near cable clamp.



- If the Detector cable must be bent, maintain the bending radius as specified below:



**MEMO**

# 4 Specifications

This chapter describes the specifications of this product.


## 4.1 Specifications

Item	Specifications	
Encoder type	Electromagnetic induction	
Angle detection / output method	Single-turn absolute	
Interfaces	Mitutoyo ENSIS® high-speed serial interface	
	Mitsubishi Electric Corporation Specifications MELSERVO high-speed serial interface	
	Mitsubishi Electric Corporation Specifications CNC Series high-speed serial interface	
	Panasonic Corporation Specifications MINAS high-speed serial interface	
	Yaskawa Electric Corporation Specifications $\Sigma$ Series high-speed serial interface	
	FANUC Corporation Specifications high-speed serial interface	
	BiSS interface	
Resolution	23 bit (approx. 0.15 arcseconds)	
Indication precision (at 20 °C)	±5 arcseconds	
Size (D: Outer diameter, d: Inner diameter, T: Thickness)	Stator	D 140 mm (d 40 mm) x T 16 mm D 140 mm (d 40 mm) x T 21.5 mm (including adjustment mechanism)
	Rotor	D 100 mm (d 25 mm) x T 7 mm
Response speed	2,000 min <sup>-1</sup>	
Detector cable length	1 m (directly connected from stator, with waterproof connector)	
Maximum cable length	19 m (when an optional 18 m feedback cable is connected) Maximum length: 29 m (when a 28 m cable is connected; this cable must be prepared by customer)	
Operating temperature range	0 °C–50 °C	
Storage temperature range	-20 °C–70 °C	
Operating/storage humidity range	20%–80% RH (non-condensing)	
Vibration resistance	196 m/s <sup>2</sup> (55 Hz–2,000 Hz)	
Shock resistance	980 m/s <sup>2</sup> (11 ms)	
Power supply voltage	5 V ± 10 % (ripple and spike noise components must be total 100 mV or less.)	
Maximum current consumption	270 mA	
Inrush current	600 mA or less	
Rise time	≤ 1 second	
Moment of inertia (rotor)	160 x 10 <sup>-6</sup> kgm <sup>2</sup>	
Weight (rotor)	130 g	
Weight (stator)	320 g (including 1 m Detector cable and adjustment mechanism)	


**Counting direction**

View from the rotor side. The arrow indicates the direction of rotor rotation.

CCW (decrement)      CW (increment)




**Detector cable connector (circular waterproof connector)**



Pin No.	Signal name (non-BiSS)	Signal name (BiSS)
A, G	GND	GND
B, H	+5 V	+5 V
D	SD	SL+
C	*SD	SL-
F	RQ (REQ)	MA+
E	*RQ (REQ)	MA-
Connector shell	F.G.	F.G.


## 4.2 Feedback Cable

### 4.2.1 Mitsubishi Electric Corporation Connector Specifications




Pin number	Signal
1	5V
2	GND
3	RQDT
4	$\overline{\text{RQDT}}$
7	DT
8	$\overline{\text{DT}}$
5, 6, 9, 10	Not used
Connector shell	Frame ground

### 4.2.2 FANUC Corporation Connector Specifications




Pin number	Signal
1	SD
2	*SD
5	RQ (REQ)
6	*RQ (REQ)
12, 14	GND
18, 20	+5 V
16	Frame ground
3, 4, 7-11, 13, 15, 17, 19	Not used

### 4.2.3 Panasonic Corporation Connector Specifications




Pin number	Signal
1	E5V
2	E0V
3	PS
4	/PS
Connector shell	Frame ground
5-10	Not used

### 4.2.4 Yaskawa Electric Corporation Connector Specifications



Pin number	Signal
1	VCC
2	GND
5	S
6	/S
Connector shell	Frame ground
3, 4	Not used

## 4.2.5 Mitutoyo Connector Specifications (D-SUB15)



Pin number	Signal
5	DT
6	$\overline{DT}$
7	RQDT
8	$\overline{RQDT}$
1, 2, 13	GND
3, 4, 11	+5 V
15	Frame ground
9, 10, 12, 14	Not used


## 4.2.6 Pigtail cable

Wire color	Signal name (non-BiSS)	Signal name (BiSS specification)
Orange	DT	SL+
Yellow	$\overline{DT}$	SL-
Green	RQDT	MA+
Blue	$\overline{RQDT}$	MA-
Red, white, white	+5 V	+5 V
Brown, black, black	GND	GND
Shielded cable	Frame ground	Frame ground

## 4.3 Calculating Feedback Cable Length

When making a feedback cable, use the following method to calculate the maximum cable length.

### ■ Configuration



For specifications of the optional feedback cable, see [4.2.6 Pigtail cable](#) on page 35.

### ■ Condition: Detector cable length is 1 m

Name	Specification or symbol	Unit
Length of feedback cable (made by customer)	L	m
Power supply wire resistance (feedback cable made by customer)	a	$\Omega/m$
Number of power supply wire pairs (feedback cable made by customer)	b	Pairs
Minimum supply voltage from the servo amplifier	4.95 <sup>*1</sup>	V
Maximum current consumption	0.25	A
Length of feedback cable (optional)	Lo	m
Voltage drop of feedback cable (optional)	$Vd = 0.0245 \times Lo$	V
Relay connector 1 voltage (minimum value)	4.54	V
Relay connector 2 voltage (minimum value)	$4.54 + Vd$	V

\*1 This is the standard supply voltage for the servo amplifier.

### ■ Formula

Allowable voltage drop  $\geq$  (current consumption x wire resistance x 2 x maximum cable length)  $\div$  number of power supply wire pairs (1)

Applying the conditions in the above table to formula (1) gives the following result.

$$(4.95 - 4.54 - Vd) [V] \geq (0.25 [A] \times a [\Omega/m] \times 2 \times L [m]) \div b [\text{pairs}] \quad (2)$$


Modify formula (2) as follows.

$$L [m] \leq \frac{b (4.95 - 4.54 - 0.0245 \times Lo)}{0.5 a} \quad (3)$$


Prepare a feedback cable with maximum cable length (L [m]), wire resistance (a [ $\Omega/m$ ]), and number of power supply wire pairs (b [pairs]) that satisfy formula (3).

# 4.4 Dimensional Drawings


## Stator dimensional drawing



## Rotor dimensional drawing



### ■ Dimensions after installation



# 5 Troubleshooting

This chapter describes the Alarm Detection function built into the Detector and describes the alarm codes for each manufacturer's interface.

5.1 Alarm Detection Function.....	39
5.2 Alarm Code Details .....	41

## 5.1 Alarm Detection Function

The ABS OR700 Detector is equipped with an Alarm Detection function.

### ■ Alarm detection details

Alarms detected by the Alarm Detection function are broadly classified into two types: warnings and errors, as shown below.


- **Warning:** This indicates conditions such as decreased signal strength of the sensor or abnormal temperature inside the Detector. Once the cause is removed, normal operation resumes.
- **Error:** This indicates conditions such as abnormal sensor signal strength or absolute position detection errors. Once an error occurs, the error state is maintained until a reset or the power is cycled.

Type of alarm detection		Description
Warning	Temperature abnormality	This warning is output when the internal temperature of the Detector reaches 75 °C or higher, and returns to normal when it falls below 70 °C.
	Signal strength	This warning is output when the signal strength drops to 30 % or lower, and returns to normal when it rises above 30 %.
Error	Signal strength	This error is output when the signal strength drops to 20 % or lower, or reaches 100 %.
	Transducer	This error is output when an abnormality occurs in the balance of internal signals.
	Absolute detection error	This error is output when absolute position detection fails.
	Absolute synthesis error	This error is output when absolute position data is synthesized erroneously.
	Initialization	This error is output when system initialization fails to complete normally at power-on.
	Overspeed	This error is output when a rotational speed exceeding 2,000 min <sup>-1</sup> is detected.

#### Tips


The history of alarms and errors can be checked using the application software.

#### NOTICE

The handling of warnings (alarms) and errors differs depending on the connected servo amplifier. For details, see  "5.2 Alarm Code Details" on page 41.

### ■ Signal strength

Signal strength is represented as three separate regions, as shown in the figure below. This diagram is displayed by the application software, allowing you to easily check the signal strength. The signal strength should always be within the normal region. If the signal strength falls within the warning or error regions, an alarm is output.



## 5.2 Alarm Code Details

For alarms related to ENSIS and BiSS, please contact the servo amplifier manufacturer.

### 5.2.1 For Mitsubishi Electric-Compatible Models

The table below shows the relationship between the ABS OR700-M-23 / ABS OR-700-M-23A alarms and the alarm codes displayed on servo amplifiers made by Mitsubishi Electric Corporation.

Servo amplifier alarm code	Description	Cause	Countermeasure
AL2A	<b>Rotary error occurred</b> <ul style="list-style-type: none"> <li>• Signal strength error</li> <li>• Absolute detection error</li> <li>• Absolute synthesis error</li> <li>• Hardware error</li> <li>• Initialization error</li> <li>• Overspeed</li> </ul>	The stator detected an error.	<ul style="list-style-type: none"> <li>• Check the positional relationship between the stator and rotor using the application software.</li> <li>• Perform installation and adjustment using the application software as needed.</li> </ul>
AL28	<b>Rotary error occurred</b> <ul style="list-style-type: none"> <li>• Thermal alarm</li> <li>• Signal strength alarm</li> </ul>	The stator detected a warning. There is no error in the position data, but it is necessary to review the installation and operating conditions.	<ul style="list-style-type: none"> <li>• The ambient temperature of the stator may have reached 60 °C or higher. If the temperature is 60 °C or higher, review the drive conditions (such as speed and acceleration).</li> <li>• Check the positional relationship between the stator and rotor using the application software.</li> <li>• Perform installation and adjustment using the application software as needed.</li> </ul>
AL16	<b>Communication error occurred</b> (during servo amplifier initialization) <ul style="list-style-type: none"> <li>• Three consecutive errors were received by the servo amplifier (including no response).</li> </ul>	A communication error occurred between the ABS OR700 and the servo amplifier (communication was not possible from the time the servo amplifier was powered on).	<ul style="list-style-type: none"> <li>• Check the connections of cables and connectors.</li> <li>• Check the routing of cables (for example, for noise effects from high-current cables).</li> <li>• When powering on, confirm that power is being supplied.</li> </ul>
AL20	<b>Communication error occurred</b> (during servo amplifier control) <ul style="list-style-type: none"> <li>• Three consecutive errors were received by the servo amplifier (including no response).</li> </ul>	A communication error occurred between the ABS OR700 and the servo amplifier (occurred during control by the servo amplifier).	<ul style="list-style-type: none"> <li>• Check the connections of cables and connectors.</li> <li>• Check the routing of cables (for example, for noise effects from high-current cables).</li> </ul>

## 5.2.2 For FANUC-Compatible Models

The table below shows the relationship between the ABS OR700-F-23 alarms and the alarm codes displayed on servo amplifiers made by FANUC Corporation. Note that the alarm codes of NC devices differ depending on whether a rotary encoder is used with fully closed loop control or with a direct drive motor.

Servo amplifier alarm code	Description	Cause	Countermeasure
<b>LED error</b> <ul style="list-style-type: none"> <li>When using fully closed loop connection 380</li> <li>When using a direct drive motor 365</li> </ul>	<b>Rotary error occurred</b> Hardware error	The stator detected an error.	Turn on the power again. If an error occurs again, the stator needs to be replaced.
<b>Phase error</b> <ul style="list-style-type: none"> <li>During fully closed connection 381</li> <li>When using a direct drive motor 361</li> </ul>	<b>Rotary error occurred</b> <ul style="list-style-type: none"> <li>Initialization error</li> <li>Absolute detection error</li> <li>Absolute synthesis error</li> <li>Overspeed</li> <li>Signal strength error</li> <li>Signal strength warning</li> </ul>	The stator detected an error.	<ul style="list-style-type: none"> <li>Check the positional relationship between the stator and rotor using the application software.</li> <li>Perform adjustment using the application software as needed.</li> </ul>
<b>Serial data error</b> <ul style="list-style-type: none"> <li>When using fully closed loop connection 385</li> <li>When using a direct drive motor 368</li> </ul>	<b>Communication error occurred</b> <ul style="list-style-type: none"> <li>No response</li> </ul>	An error in communication between the ABS OR700 and the NC device prevented receipt of data from the rotary encoder (no response).	<ul style="list-style-type: none"> <li>Check the connections of cables and connectors.</li> <li>Check the routing of cables (for example, for noise effects from high-current cables).</li> </ul>
<b>Data transfer error</b> <ul style="list-style-type: none"> <li>When using fully closed loop connection 386</li> <li>When using a direct drive motor 369</li> </ul>	<b>Communication error occurred</b> <ul style="list-style-type: none"> <li>Communication error</li> </ul>	CRC and stop bit errors occurred in the serial data from the rotary encoder during communication between the ABS OR700 and the NC device (communication error).	Check the routing of cables (for example, for noise effects from high-current cables).
<b>Hardware disconnection alarm</b> <ul style="list-style-type: none"> <li>When using fully closed loop connection 447</li> <li>When using a direct drive motor 446</li> </ul>	<b>Communication error occurred</b> <ul style="list-style-type: none"> <li>Cable disconnection</li> </ul>	Due to cable disconnection, a communication error occurred between the ABS OR700 and the NC device.	Check the connections of cables and connectors.

### 5.2.3 For Panasonic-Compatible Models

The table below shows the relationship between the ABS OR700-P-23 alarms and the alarm codes displayed on servo amplifiers made by Panasonic Corporation.

Servo amplifier alarm code	Description	Cause	Countermeasure
Err51.0	<b>Rotary error occurred</b> • Overspeed	The stator detected an overspeed error.	Review the drive conditions (commanded speed).
Err51.1	<b>Rotary error occurred</b> • Initialization error	The stator detected an error during initialization.	<ul style="list-style-type: none"> <li>• Check the positional relationship between the stator and rotor using the application software.</li> <li>• Perform installation and adjustment using the application software as needed.</li> <li>• Please check the power supply to the rotary encoder, including whether it contains ripple noise or other types of electrical noise.</li> </ul>
Err51.2	<b>Rotary error occurred</b> • Hardware error	The stator detected an error.	Turn on the power again. If an error occurs again, the stator needs to be replaced.
Err51.3	<b>Rotary error occurred</b> • Absolute position detection error (mismatch)	The stator detected an error.	<ul style="list-style-type: none"> <li>• Check the positional relationship between the stator and rotor using the application software.</li> <li>• Perform installation and adjustment using the application software as needed.</li> <li>• If there are no abnormalities with the installation, power supply, or other related factors, then the stator must be replaced.</li> </ul>
Err51.4	<b>Rotary error occurred</b> • Absolute position detection error (detection stopped)	The stator detected an error.	<ul style="list-style-type: none"> <li>• Check the positional relationship between the stator and rotor using the application software.</li> <li>• Perform installation and adjustment using the application software as needed.</li> <li>• If there are no abnormalities with the installation, power supply, or other related factors, then the stator must be replaced.</li> </ul>

Servo amplifier alarm code	Description	Cause	Countermeasure
Err51.5	<b>Rotary error occurred</b> <ul style="list-style-type: none"> <li>Signal strength error</li> </ul>	The stator detected a warning. There is no error in the position data, but it is necessary to re-view the installation and operating conditions.	<ul style="list-style-type: none"> <li>Check the positional relationship between the stator and rotor using the application software.</li> <li>Perform installation and adjustment using the application software as needed.</li> <li>If there are no abnormalities with the installation, power supply, or other related factors, then the stator must be replaced.</li> </ul>
<ul style="list-style-type: none"> <li>Err50.0</li> <li>Err50.1</li> </ul>	<b>Communication error occurred</b>	A communication error occurred between the ABS OR700 and the servo amplifier.	<ul style="list-style-type: none"> <li>Check the connections of cables and connectors.</li> <li>Check the routing of cables (for example, for noise effects from high-current cables).</li> </ul>

## 5.2.4 For Yaskawa Electric-Compatible Models

The table below shows the relationship between the ABS OR700-Y-23 alarms and the alarm codes displayed on servo amplifiers made by Yaskawa Electric Corporation.

Servo amplifier alarm code	Description	Cause	Countermeasure
<ul style="list-style-type: none"> <li>A.8A3 <sup>*1</sup></li> <li>A.84U <sup>*2</sup></li> </ul>	<b>Rotary error occurred</b> <ul style="list-style-type: none"> <li>Signal strength error</li> <li>Absolute detection error</li> <li>Absolute synthesis error</li> <li>Initialization error</li> </ul>	The stator detected an error.	<ul style="list-style-type: none"> <li>Check the positional relationship between the stator and rotor using the application software.</li> <li>Perform installation and adjustment using the application software as needed.</li> </ul>
<ul style="list-style-type: none"> <li>A.8A5 <sup>*1</sup></li> <li>A.85U <sup>*2</sup></li> </ul>	<b>Rotary error occurred</b> <ul style="list-style-type: none"> <li>Overspeed</li> </ul>	The stator detected an overspeed error.	Review the drive conditions (commanded speed).
<ul style="list-style-type: none"> <li>A.8A6 <sup>*1</sup></li> <li>A.860 <sup>*2</sup></li> </ul>	<b>Rotary error occurred</b> <ul style="list-style-type: none"> <li>Thermal alarm</li> <li>Signal strength alarm</li> </ul>	The stator detected a warning. There is no error in the position data, but it is necessary to re-view the installation and operating conditions.	<ul style="list-style-type: none"> <li>The ambient temperature of the stator may have reached 60 °C or higher. If the temperature is 60 °C or higher, review the drive conditions (such as speed and acceleration).</li> <li>Check the positional relationship between the stator and rotor using the application software.</li> <li>Perform installation and adjustment using the application software as needed.</li> </ul>

Servo amplifier alarm code	Description	Cause	Countermeasure
<ul style="list-style-type: none"> <li>• A.8A1 <sup>*1</sup></li> <li>• A.891 <sup>*2</sup></li> </ul>	<b>Scale error occurred</b> <ul style="list-style-type: none"> <li>• Hardware error</li> </ul>	The stator detected an error.	The stator needs to be replaced.
<ul style="list-style-type: none"> <li>• A.CF1 <sup>*1</sup></li> <li>• C90 <sup>*2</sup></li> </ul>	<b>Communication error occurred</b> (during servo amplifier control) <ul style="list-style-type: none"> <li>• Three consecutive errors were received by the servo amplifier (including no response).</li> </ul>	A communication error occurred between the ABS OR700 and the servo amplifier (occurred during control by the servo amplifier).	<ul style="list-style-type: none"> <li>• Check the connections of cables and connectors.</li> <li>• Check the routing of cables (for example, for noise effects from high-current cables).</li> </ul>

\*1 When using the rotary encoder with fully closed control

\*2 When using the rotary encoder with a direct drive motor

# SERVICE NETWORK

\*As of May 2025

## Europe

### Mitutoyo Europe GmbH

Borsigstrasse 8-10, 41469 Neuss, GERMANY  
TEL: 49 (0)2137 102-0 FAX: 49 (0)2137 102-351

### Mitutoyo CTL Germany GmbH

Von-Gunzert-Strasse 17, 78727 Oberndorf, GERMANY  
TEL: 49 (0)7423 8776-0 FAX: 49 (0)7423 8776-99

### KOMEG Industrielle Messtechnik GmbH

Zum Wasserwerk 3, 66333 Völklingen, GERMANY  
TEL: 49 (0)6898 91110 FAX: 49 (0)6898 911100

## Germany

### Mitutoyo Deutschland GmbH

Borsigstrasse 8-10, 41469 Neuss, GERMANY  
TEL: 49 (0)2137 102-0 FAX: 49 (0)2137 86 85

### M³ Solution Center Hamburg

Tempowerkring 9-im HIT-Technologiepark 21079  
Hamburg, GERMANY  
TEL: 49 (0)40 791894-0 FAX: 49 (0)40 791894-50

### M³ Solution Center Berlin

Ernst-Lau-Straße 6, 12489 Berlin, GERMANY  
TEL:49(0)30 2611 267 FAX: 49 30 67988729

### M³ Solution Center Eisenach

Neue Wiese 4, 99817 Eisenach,GERMANY  
TEL: 49 (0)3691 88909-0 FAX: 49 (0)3691 88909-9

### M³ Solution Center Ingolstadt

Marie-Curie-Strasse 1A, 85055 Ingolstadt, GERMANY  
TEL: 49 (0)841 954920 FAX: 49 (0)841 9549250

### M³ Solution Center Leonberg

Am Längenbühl 3, 71229 Leonberg, GERMANY  
TEL: 49 (0)7152 6080-0 FAX: 49 (0)7152 608060

### Mitutoyo Deutschland GmbH - Small Tool Sales Division

Am Längenbühl 4, 71229 Leonberg, GERMANY  
TEL: 49 (0)7152 9237-0 FAX: 49 (0)7152 9237-29

## U.K.

### Mitutoyo (UK) Ltd. HQ

Joule Road, West Point Business Park,  
Andover, Hampshire SP10 3UX, UNITED KINGDOM  
TEL: 44 (0)1264 353123 FAX: 44 (0)1264 354883

### Coventry M³ Solution Centre

Unit6, Banner Park, Wickmans Drive, Coventry,  
West Midlands CV4 9XA, UNITED KINGDOM  
TEL: 44 (0)2476 426300

### Halifax M³ Solution Centre

Lowfields Business Park, Navigation Close, Elland,  
West Yorkshire HX5 9HB, UNITED KINGDOM  
TEL: 44 (0)1422 375566

### East Kilbride M³ Solution Centre

The Bairds Building, Rankine Avenue, Scottish  
Enterprise Technology Park, East Kilbride G75  
0QF, UNITED KINGDOM  
TEL: 44 (0)1355 581170

## France

### Mitutoyo France

Paris Nord 2-123 rue de la Belle Etoile, BP 59267  
ROISSY EN FRANCE 95957 ROISSY CDG  
CEDEX, FRANCE  
TEL: 33 (0)149 38 35 00

### M³ Solution Center LYON

Parc Mail 523, cours du 3ème millénaire, 69791  
Saint-Priest, FRANCE  
TEL: 33 (0)149 38 35 70

### M³ Solution Center STRASBOURG

Parc de la porte Sud, Rue du pont du péage,  
67118 Geispolsheim, FRANCE  
TEL: 33 (0)149 38 35 80

### M³ Solution Center CLUSES

290 Avenue des Lacs, 74950 Scionzier, FRANCE  
TEL: 33 (0)1 49 38 35 90

### M³ Solution Center TOULOUSE

Aeroparc Saint Martin Cellule B08 ZAC de Saint  
Martin du Touch 12 rue de Caulet 31300  
Toulouse, FRANCE  
TEL: 33 (0)1 49 38 42 90

### M³ Solution Center RENNES

2, rue Claude Chappe, PA le Vallon - ZAC Mivoie,  
35230 Noyal-Châtillon-sur-Seiche, FRANCE  
TEL: 33 (0)1 49 38 42 10

## Italy

### Mitutoyo Italiana S.r.l.

Corso Europa, 7 - 20045 Lainate (MI), ITALY  
TEL: 39 02 935781 FAX: 39 02 93578255

### M³ Solution Center BOLOGNA

Via Stalingrado 67/22D 40128 Bologna, ITALY  
TEL: 39 02 93578215

### M³ Solution Center CHIETI

Contrada Santa Calcagna - 66020 Rocca S.  
Giovanni (CH), ITALY  
TEL: 39 02 93578280 FAX: 39 02 93578255

---

**M<sup>3</sup> Solution Center PADOVA**

Via G. Galilei 21/F - 35035 Mestrino (PD), ITALY  
TEL: 39 02 93578268 FAX: 39 02 93578255

**Netherlands****Mitutoyo Nederland B.V.**

Storkstraat 30, 3905 KX Veenendaal,  
THE NETHERLANDS  
TEL: 31(0)318-534911

**Mitutoyo Nederland B.V. / M<sup>3</sup> Solution Center Enschede**

Institutenweg 50, 7521 PK Enschede,  
THE NETHERLANDS  
TEL: 31(0)318-534911

**Mitutoyo Nederland B.V. / M<sup>3</sup> Solution Center Eindhoven**

De Run 1115, 5503 LB Veldhoven,  
THE NETHERLANDS  
TEL: 31(0)318-534911

**Mitutoyo Research Center Europe B.V.**

De Rijn 18, 5684 PJ Best, THE NETHERLANDS  
TEL:31(0)499-320200 FAX:31(0)499-320299

**Belgium****Mitutoyo Belgium N.V. / M<sup>3</sup> Solution Center Melsele**

Schaarbeekstraat 20, B-9120 Melsele, BELGIUM  
TEL: 32 (0)3-2540444

**Sweden****Mitutoyo Scandinavia AB**

Släntvägen 6, 194 61 Upplands Väsby, SWEDEN  
TEL: 46 (0)8 594 109 50

**Mitutoyo Scandinavia AB / M<sup>3</sup> Solution Center Alingsås**

Ängsvaktaregatan 3A, 441 38 Alingsås, SWEDEN  
TEL: 46 (0)8 594 109 50

**Mitutoyo Scandinavia AB / M<sup>3</sup> Solution Center Värnamo**

Kalkstensvägen 7, 331 44 Värnamo, SWEDEN  
TEL: 46 (0)8 594 109 50

**Switzerland****Mitutoyo (Schweiz) AG**

Steinackerstrasse 35, 8902 Urdorf, SWITZERLAND  
TEL: 41 (0)447361150

**Mitutoyo (Suisse) SA**

Rue Gallée 4, 1400 Yverdon-les Bains, SWITZERLAND  
TEL: 41 (0)244259422

**Poland****Mitutoyo Polska Sp.z o.o.**

Skrzypowa 1, 54-530 Wrocław, POLAND  
TEL: 48 (0)71354 83 50 FAX: 48 (0)71354 83 55

**Czech Republic****Mitutoyo Česko s.r.o.**

Dubská 1626, 415 01 Teplice, CZECH REPUBLIC  
TEL: 420 417-514-011 Email: info@mitutoyo.cz

**Mitutoyo Česko s.r.o. M<sup>3</sup> Solution Center Ivančice**

Ke Karlovu 62/10, 664 91 Ivančice, CZECH REPUBLIC  
TEL: 420 417-514-011 Email: info@mitutoyo.cz

**Mitutoyo Česko s.r.o. M<sup>3</sup> Solution Center Ostrava Mošnov**

Mošnov 314, 742 51 Mošnov, CZECH REPUBLIC  
TEL: 420 417-514-050 Email: info@mitutoyo.cz

**Mitutoyo Česko s.r.o. Slovakia Branch**

Šoltésovej 346/1, 017 01 Považská Bystrica,  
SLOVAKIA  
TEL: 421 948-595-590 Email: info@mitutoyo.sk

**Hungary****Mitutoyo Hungária Kft.**

Galamb József utca 9, 2000 Szentendre, HUNGARY  
TEL: 36 (30) 6410210

**Romania****Mitutoyo Romania SRL**

1A Drumul Garii Odai Street, showroom, Ground  
Floor, 075100 OTOPENI-ILFOV, ROMANIA  
TEL: 40 (0)311012088 FAX: +40 (0)311012089

**Showroom in Brasov**

Strada Ionescu Crum Nr.1, Brasov Business Park  
Turnul 1, Mezanin, 500446  
Brasov-Judetul Brasov, ROMANIA  
TEL/FAX: 40 (0)371020017

**Finland****Mitutoyo Scandinavia AB Finnish Branch**

Autokeskuksentie 16B, 33960 Pirkkala, FINLAND  
TEL: 358 (0)40 355 8498

**Austria****Mitutoyo Austria GmbH**

Salzburger Straße 260/2 und 260/3, 4600 Wels,  
AUSTRIA  
TEL: 43 (0)7242 219 998

**Mitutoyo Austria GmbH Goetzis Regional showroom**

Lastenstrasse 48a, 6840 Götzis, AUSTRIA

---

**Singapore****Mitutoyo Asia Pacific Pte. Ltd.****Head office / M<sup>3</sup> Solution Center**

24 Kallang Avenue, Mitutoyo Building,  
SINGAPORE 339415

TEL:(65)62942211 FAX:(65)62996666

**Malaysia****Mitutoyo (Malaysia) Sdn. Bhd.****Kuala Lumpur Head Office / M<sup>3</sup> Solution Center**

Mah Sing Integrated Industrial Park, 4, Jalan Utarid U5/14,  
Section U5, 40150 Shah Alam, Selangor, MALAYSIA

TEL:(60)3-78459318 FAX:(60)3-78459346

**Penang Branch office / M<sup>3</sup> Solution Center**

30, Persiaran Mahsuri 1/2, Sunway Tunas, 11900  
Bayan Lepas, Penang, MALAYSIA

TEL:(60)4-6411998 FAX:(60)4-6412998

**Johor Branch office / M<sup>3</sup> Solution Center**

70 (Ground Floor), Jalan Molek 1/28, Taman  
Molek, 81100 Johor Bahru, Johor, MALAYSIA

TEL:(60)7-3521626 FAX:(60)7-3521628

**Thailand****Mitutoyo (Thailand) Co., Ltd.****Bangkok Head Office / M<sup>3</sup> Solution Center**

2327 Onnut Road Kwaeng Onnut Khet Suanluang  
Bangkok 10250, THAILAND

TEL:(66)2080 3500

**Chonburi Branch / M<sup>3</sup> Solution Center**

7/1, Moo 3, Tambon Bowin, Amphur Sriracha,  
Chonburi 20230, THAILAND

TEL:(66)2080 3563 FAX:(66)3834 5788

**ACC Branch / M<sup>3</sup> Solution Center**

122/8, 122/9, Moo 6, Tambon Donhuaroh, Amphur  
Muangchonburi, Chonburi 20000, THAILAND

TEL:(66)2080 3565

**Indonesia****PT. Mitutoyo Indonesia****Head Office / M<sup>3</sup> Solution Center**

Jalan Sriwijaya No.26 Desa cibatu Kec. Cikarang  
Selatan Kab. Bekasi 17530, INDONESIA

TEL: (62)21-2962 8600 FAX: (62)21-2962 8604

**Batam Branch Office**

Business Center Adhya Building 3rd Floor Kom-  
pleks Permata Niaga Blok A No. 1, Jalan jendral  
Sudirman Kelurahan Sukajadi, Kecamatan Batam  
Kota, Kepulauan Riau 29444, INDONESIA

TEL: (62)-778-4888000

**Vietnam****Mitutoyo Vietnam Co., Ltd****Hanoi Head Office / M<sup>3</sup> Solution Center**

1st & 2nd floor, MHDI Building, No. 60 Hoang Quoc  
Viet Road, Nghia Do Ward, Cau Giay District, Hanoi,  
VIETNAM

TEL:(84)24-3768-8963 FAX:(84)24-3768-8960

**Ho Chi Minh City Branch Office / M<sup>3</sup> Solution Center**

Unit No. B-00.07, Ground Floor, C1 Building, No.  
6, Street D9, An Loi Dong Ward, Thu Duc City, Ho  
Chi Minh City, VIETNAM

TEL:(84)28-3840-3489 FAX:(84)28-3840-3498

**Hai Phong City Branch Office**

Room 511, 5th Floor, Thanh Dat 3 Building, No. 4  
Le Thanh Tong Street, May To Ward, Ngo Quyen  
District, Hai Phong City, VIETNAM

TEL:(84)22-5398-9909

**Philippines****Mitutoyo Philippines, Inc.****Head Office / M<sup>3</sup> Solution Center**

Unit 1B & 2B LTI, Administration Building 1, Annex 1, North  
Main Avenue, Laguna Technopark, Binan Laguna 4024,  
PHILIPPINES

TEL/FAX:(63) 49 544 0272

**India****Mitutoyo South Asia Pvt. Ltd. Head Office**

C-122, Okhla Industrial Area, Phase-I,  
New Delhi-110 020, INDIA

TEL: (91) 11-40578485/86

**MSA Technical Center**

Plot no. 65, Ground Floor, Udyog Vihar, Phase-4 Gurga-  
on, Haryana - 122016, INDIA

TEL : (91) 124-2340286/287

**Mumbai Region Head office**

303, Sentinel Hiranandani Business Park Powai,  
Mumbai-400 076, INDIA

TEL: (91) 22-25700684/685/837/839

**Pune Office / M<sup>3</sup> Solution Center**

G4/G5, Pride Kumar Senate, Off. Senapati Bapat  
Road, Pune-411 016, INDIA

TEL:(91) 20-25660043/44/45

**Ahmedabad Office / M<sup>3</sup> Solution Center**

A-104 & A-105, First Floor, Solitaire Corporate  
Park, Near Divya Bhaskar Press, S.G. Road,  
Ahmedabad - 380 015, INDIA

TEL: (91) 079 - 29704902/903

**Bengaluru Region Head office / M<sup>3</sup> Solution Center**

116/117-2, Ground Floor, Sy. No. 93 & 94, 3rd  
Phase, Peenya Industrial Area, Bengaluru-560  
058, INDIA

TEL: (91) 80-25630946/47/48/49

---

**Coimbatore Office**

Regus, Srivari Srimath, 3rd Floor, Door No:1045,  
Avinashi Road, Coimbatore - 641 018,INDIA  
TEL: (91) 9345005663

**Chennai Office / M<sup>3</sup> Solution Center**

No. 624, Anna Salai Teynampet, Chennai-600 018, INDIA  
TEL: (91) 44-24328823/24/25

**Kolkata Office**

Unit No. 1208,Om Tower, 32,J.L.Nehru Road,  
Kolkata-700 071, INDIA  
TEL: (91) 33-22267088/40060635/22266817

**Taiwan****Mitutoyo Taiwan Co., Ltd. / M<sup>3</sup> Solution Center Taipei**

4F., No.71, Zhouzi St., Neihu Dist.,Taipei City 114,  
TAIWAN

TEL:886(2)5573-5900 FAX:886(2)8752-3267

**Taichung Branch / M<sup>3</sup> Solution Center Taichung**

1F., No. 299, Gaotie 1st Rd., Wuri Dist., Taichung  
City 414, TAIWAN

TEL:886(4)2338-6822 FAX:886(4)2338-6722

**Kaohsiung Branch / M<sup>3</sup> Solution Center Kaohsiung**

1F., No.31-1, Haibian Rd., Lingya Dist.,  
Kaohsiung City 802, TAIWAN

TEL:886(7)334-6168 FAX:886(7)334-6160

**South Korea****Mitutoyo Korea Corporation****Head Office / M<sup>3</sup> Solution Center**

33, Eungyejungang-ro 306beon-gil, Siheung-si,  
Gyeonggi-do, 15120 KOREA

TEL:82(31)361-4200 FAX:82(31)361-4201

**Busan Office / M<sup>3</sup> Solution Center**

(3150-3, Daejeo 2-dong) 8,Yutongdanji 1-ro  
49beon-gil, Gangseo-gu, Busan, 46721 KOREA

TEL:82(51)324-0103 FAX:82(51)324-0104

**Daegu Office / M<sup>3</sup> Solution Center**

(Galsan-dong, Daegu Business Center), 301-Ho, 217,  
Seongseogongdan-ro, Dalseo-gu, Daegu 42704 KOREA

TEL:82(53)593-5602 FAX:82(53)593-5603

**China****Mitutoyo Measuring Instruments (Shanghai) Co., Ltd.**

18/F, NEW BUND Shun Tak Center, No.18, Lane  
666, West Haiyang Road, Pudong New District,  
Shanghai 200124, CHINA

TEL:86(21)5836-0718 FAX:86(21)5836-0717

**Suzhou Office / M<sup>3</sup> Solution Center China (Suzhou)**

1/2 Floor, Building 4, No.175 Songbei Road,  
Suzhou Free Trade Zone, Suzhou City, Jiangsu  
215000, CHINA

TEL:86(512)6522-1790 FAX:86(512)6251-3420

**Wuhan Office / M<sup>3</sup> Solution Corner**

Room 1701, Wuhan Wanda Center, No. 96, Linji-  
ang Road, Wuchang District, Wuhan  
Hubei 430060, CHINA

TEL:86(27)8544-8631 FAX:86(27)8544-6227

**Chengdu Office**

Room 1-102, 1st Floor, Unit 1, Building 1, No. 24,  
Wannian Road (Wanniancang Cool), Chenghua  
District, Chengdu City, Sichuan 610056, CHINA

TEL:86(28)8671-8936 FAX:86(28)8671-9086

**Hangzhou Office**

Room 329, 3F, Building D, West Square of Hang-  
zhoudong Railway Station, No. 260 Xinfeng Road,  
Shangcheng District, Hangzhou City, Zhejiang  
310002, CHINA

TEL: 86(571)8288-0319 FAX: 86(571)8288-0320

**Tianjin Office / M<sup>3</sup> Solution Center China (Tianjin)**

Room D 12/F, TEDA Building, No.256 Jie-fang  
Nan Road Hexi District,Tianjin 300042, CHINA

TEL:86(22)5888-1700 FAX:86(22)5888-1701

**Changchun Office**

Room 815, 8F, Building A1, Upper East  
International No.3000 Dongsheng Street,  
Erdao District, Changchun, Jilin, 130031, CHINA

TEL:86(431)8192-6998 FAX:86(431)8192-6998

**Chongqing Office**

Room 1312, Building 3, Zhongyu Plaza, No.86,  
Hongjin Avenue,Longxi Street, Yubei District,  
Chongqing, 400000, CHINA

TEL:86(23)6595-9950 FAX:86(23)6595-9950

**Qingdao Office**

Room 638, 6F, No.192 Zhengyang Road, Chengyang  
District, Qingdao, Shandong, 266109, CHINA

TEL:86(532)8096-1936 FAX:86(532)8096-1937

**Xi'an Office**

Room 1503 Jianke Building, No.99 Yanta Road,  
Beilin District, Xi'an City, Shaanxi 710054, CHINA

TEL:86(29)8538-1380 FAX:86(29)8538-1381

**Dalian Office / M<sup>3</sup> Solution Center China (Da-  
lian)**

Room A-106 Shuijing SOHO, No.16 Harbin Road,Eco-  
nomic Development Zone,Dalian, 116600 CHINA

TEL:86(411)8718 1212 FAX:86(411)8754-7587

**Zhengzhou Office**

Room 5003, 50th Floor, South Tower of Greenland  
Centre, No.36 Yulin North Road, Zhengdong New  
District, Zhengzhou, Henan, 450000, CHINA

TEL:86(371)6097-6436 FAX:86(371)6097-6981

---

**Dongguan Office / M<sup>3</sup> Solution Center China (Dongguan)**

Room 801, No 65, Chang'an Section Guanchang Road, Chang'an Town, Dongguan City, Guangdong 523841, CHINA

TEL:86(769)8541 7715 FAX:86(769)-8541 7745

**Fuzhou Office**

Unit 03, 7th floor of East Tower, Sansheng International Center, No.118 Wusi Road, Gulou District, Fuzhou City, Fujian 350001, CHINA

TEL: 86 (591) 8761 8095

FAX: 86 (591) 8761 8096

**Changsha Office**

Room 2207, Building 1, Shiner International Plaza, No. 88, Kaiyuan Middle Road, Changsha City, Hunan 410100, CHINA

TEL: 86 (731) 8401 9276

FAX: 86 (731) 8401 9376

**Changzhou Office**

Room 1502, Joint Financial Tower, No.255, Tongjiang North Road, Tianning District, Changzhou City, Jiangsu 2130002, CHINA

TEL:86(519)8815 8319 FAX:86(519)8815 8319

**Wenzhou Office**

Room 512, Building 4, Xinjingdujiayuan, Sanyang Street, Ouhai District, Wenzhou City, Zhejiang 325014, CHINA

TEL:86(577)8641 5280

**Shunde Office**

Room 1603, Building 26, Vanke Golden Riverside Plaza Phase II, No.13 Mid DeSheng Road, Shunde District, Foshan City, Guangdong 528300, CHINA

TEL/FAX: 86(757)2228 8621

**Hefei Office**

UnitB3111-1, 1F, Block B3, Hulanbaodi Huiyuan, Heping Road, Yaohai District, Hefei City, Anhui 230001, CHINA

TEL: 86(551)6560 1006

**Mitutoyo Measuring Technology (Suzhou) Co., Ltd.**

1/2 Floor, Building 4, No.175 Songbei Road, Suzhou Free Trade Zone, Suzhou City, Jiangsu 215000, CHINA

TEL:86(512)6252-2660 FAX:86(512)6252-2580

**USA**

**Mitutoyo America Corporation**

965 Corporate Blvd., Aurora, IL 60502, U.S.A.

TEL:1-(630)820-9666 Toll Free No. 1-888-648-8869

FAX:1-(630)978-3501

**Headquarters (Aurora) / M<sup>3</sup> Solution Center**

965 Corporate Blvd., Aurora, IL 60502, U.S.A.

**Seattle (Renton) Office / M<sup>3</sup> Solution Center**

1000 SW 34th St. Suite G, Renton, WA 98057 U.S.A.

TEL:1-(888)-648-8869

**Houston Office / M<sup>3</sup> Solution Center**

4560 Kendrick Plaza Drive Suite 120 Houston, TX 77032, U.S.A.

TEL:1-(888)-648-8869 FAX:1-(281)227-0937

**Cincinnati (Mason) Office / M<sup>3</sup> Solution Center**

6220 Hi-Tek Ct., Mason, OH 45040, U.S.A.

TEL:1-(888)-648-8869 FAX:1-(513)754-0718

**Detroit (Novi) Office / M<sup>3</sup> Solution Center**

46850 Magellan Drive, Suite 100 Novi, MI 48377, U.S.A.

TEL:1-(888)-648-8869 FAX: 1-(248)-926-0928

**Los Angeles (City of Industry) Office / M<sup>3</sup> Solution Center**

16925 E. Gale Ave., City of Industry, CA 91745, U.S.A.

TEL:1-(888)-648-8869 FAX:1-(626)369-3352

**Charlotte (Huntersville) Office / M<sup>3</sup> Solution Center**

11515 Vanstory Dr., Suite 140, Huntersville, NC 28078, U.S.A.

TEL:1-(888)-648-8869 FAX:1-(704)875-9273

**Boston (Marlborough) Office / M<sup>3</sup> Solution Center**

753 Forest Street, Suite 110, Marlborough, MA 01752, U.S.A.

TEL:1-(888)648-8869 FAX:1-(508)485-0782

**West Chester (Ohio) / Metrology Service Center**

8876 Beckett road, West Chester, OH 45069, USA

TEL:1-(888)-648-8869

**Mitutoyo America Corporation Calibration Lab**

965 Corporate Blvd., Aurora, IL 60502, U.S.A.

TEL:1-(888)-648-8869 FAX:1-(630)978-6477

**Mitutoyo America Corporation CT-Lab Chicago**

965 Corporate Blvd., Aurora, IL 60502, U.S.A.

TEL: 1-(888)-648-8869 FAX: 1-(630)-820-3418

---

**Mitutoyo Research & Development America, Inc.**

11533 NE 118th St., Kirkland,  
WA 98034-7111, U.S.A.  
TEL:1-(425)821-3906 FAX:1-(425)821-32280

**Mitutoyo Research & Development America, Inc. - California Office**

16925 Gale Ave. City of Industry,  
CA 91745-1806 U.S.A.  
TEL: 1-(425)821-3906 FAX: 1-(425)821-3228

**Canada**

**Mitutoyo Canada Inc.**

2121 Meadowvale Blvd., Mississauga,  
Ont. L5N 5N1., CANADA  
TEL:1-(905)821-1261 FAX:1-(905)821-4968

**Montreal Office**

7075 Place Robert-Joncas Suite 129, Montreal,  
Quebec H4M 2Z2, CANADA  
TEL:1-(514)337-5994 FAX:1-(514)337-4498

**Brazil**

**Mitutoyo Sul Americana Ltda.**

**Head office / M<sup>3</sup> Solution Center**

Avenida Mimes nº 25 – Loteamento Multivias II,  
Jardim Ermida I, CEP 13212-216 Jundiaí - SP,  
BRASIL  
TEL: 55 (11) 5643-0004/0041

**Filial Curitiba / M<sup>3</sup> Solution Center**

Rua Sergipe, nº 101, Sala A, Bairro Boneca do  
Iguaçu, São José dos Pinhais – Paraná – BRA-  
SIL CEP 83040120  
TEL: 55 (41) 3534-1728

**Filial Joinville / M<sup>3</sup> Solution Center**

Rua Sorocaba, No.265, Bairro Floresta, Join-  
ville, Santa Catarina, BRASIL, CEP 89212-210  
TEL: 55 (47) 3025-8062

**Filial Porto Alegre / M<sup>3</sup> Solution Center**

Rua Emilio Boeckel nº 325, Bairro: Flao, São  
Leopoldo - RS, BRASIL CEP 93020-600  
TEL: 55 (51) 3037-9383

**Argentina**

**Mitutoyo Sul Americana Ltda.**

**Argentina Branch / M<sup>3</sup> Solution Center**

AV. MITRE 1249 Piso. PB– FLORIDA – BUENOS  
AIRES ARGENTINA  
TEL:54 (11) 4730-1433 FAX:54 (11) 4730-1411

**Mexico**

**Mitutoyo Mexicana, S.A. de C.V.**

Industria Eléctrica No.15, Parque Industrial, Nau-  
calpan de Juárez, Estado de México C.P.53370,  
MÉXICO

TEL: 52 (01-55) 5312-5612  
FAX: 52 (01-55) 5312-3380

**Monterrey Office / M<sup>3</sup> Solution Center**

Blv. Interamericana No. 103, Parque Industrial  
FINSA, C.P. 66636 Apodaca, N.L., MÉXICO  
TEL: 52(01-81) 8398-8227/8228/8242/8244  
FAX: 52(01-81) 8398-8226

**Tijuana Office / M<sup>3</sup> Solution Center**

Calle José María Velazco 10501-C, Col. Cd. Industrial  
Nueva Tijuana, C.P. 22500 Tijuana, B.C., MÉXICO  
TEL: 52 (01-664) 647-5024

**Querétaro Office / M<sup>3</sup> Solution Center**

Av. Cerro Blanco No.500-1, Colonia Centro Sur,  
Querétaro, Querétaro, C.P. 76090, MÉXICO  
TEL: 52 (01-442) 340-8018, 340-8019 and 340-8020  
FAX: 52 (01-442) 340-8017

**Mitutoyo Mexicana, S.A. de C.V. Querétaro  
Calibration Laboratory**

Av. Cerro Blanco 500 30 Centro Sur,  
Querétaro, Querétaro, C.P. 76090, MÉXICO  
TEL: 52 (01-442) 340-8018, 340-8019 and 340-8020  
FAX: 52 (01-442) 340-8017

**Aguascalientes Office / M<sup>3</sup> Solution Center**

Av. Aguascalientes No. 622, Local 15 Centro Comer-  
cial El Cilindro Fracc. Pulgas Pandas Norte, C.P.  
20138, Aguascalientes, Ags. MÉXICO  
TEL: 52 (01-449) 174-4140 and 174-4143

**Irapuato Office / M<sup>3</sup> Solution Center**

Boulevard a Villas de Irapuato No. 1460 L.1 Col. Ejido  
Irapuato C.P. 36643  
Irapuato, Gto., MÉXICO  
TEL: 52 (01-462) 144-1200 and 144-1400



---

## Revision Record

Date of publication	Revision status	Details of revision
June 1, 2025	First edition	Publication

# Mitutoyo Corporation

---

20-1, Sakado 1-Chome, Takatsu-ku, Kawasaki-shi, Kanagawa 213-8533, Japan  
Tel: +81 (0)44 813-8230 Fax: +81 (0)44 813-8231  
Home page: <https://www.mitutoyo.co.jp/global.html>

For the EU Directive, Authorized representative and importer in the EU:  
Mitutoyo Europe GmbH  
Borsigstrasse 8-10, 41469 Neuss, Germany

For the UK Regulation, Authorized representative and importer in the UK:  
Mitutoyo (UK) Ltd.  
Joule Road, West Point Business Park, Andover, Hampshire SP10 3UX, UNITED KINGDOM