

ID-F125/150

Digimatic Indicator

User's Manual

Read this User's Manual thoroughly
Before operating the instrument. After reading,
retain it close at hand for future reference.

Mitutoyo

CONVENTIONS USED IN USER'S MANUAL

Safety Precautions

To operate the instrument correctly and safely, Mitutoyo manuals use various safety signs(Signal Words and Safety Alert Symbols) to identify and warn against hazards and potential accidents.

The following signs indicate general warnings:



WARNING

- Indicates a potentially hazardous situation which, if not avoided, could result in serious injury or death.



CAUTION

- Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury or property damage.

On Various Type of Notes

The following types of notes are provided to help the operator obtain reliable measurement data through correct instrument operation.

IMPORTANT •An important note is a type of note that provides information essential to the completion of a task. You cannot disregard this note to complete the task.
•An important note is a type of precaution, which if neglected could result

NOTE A note emphasizes or supplements important points of the main text. A note supplies information that may only apply in special cases (e.g.. Memory limitations, equipment configurations, or details that apply to specific versions of a program).

TIP •A tip is a type of note that helps the user apply the techniques and procedures described in the text to their specific needs.
It also provides reference information associated with the topic being discussed.

Mitutoyo assumes no liability to any party for any loss or damage, direct or indirect, caused by use of this instrument not conforming to this manual.

Information in this document is subject to change without notice.

Copyright ©1997-2020 Mitutoyo Corporation All right reserved.

Cautions on Use

Power Supply Warnings



WARNING

- External power is supplied to the instrument from an AC power source, through an AC adapter. Use only the AC adapter specified by Mitutoyo (standard accessory).
- If the instrument is used near a device requiring high voltage, frequency or current, be sure that this device and the instrument's AC adapter have separate power supplies.
- Use only an AC power supply which conforms to the voltage and frequency written on the AC adapter. Using a voltage or frequency outside the allowed range may result in fire or explosion.
- When not using the instrument for an extended period, always unplug the AC adapter from the power supply to avoid the risk of fire.

Other Cautions on Use

Observe the following precautions to avoid instrument failure or malfunction.



CAUTION

- Do not knock, drop or subject the instrument to excessive force.
- Do not disassemble or modify the instrument.
- Do not operate the keys with a pointed instrument (such as a screwdriver).
- Avoid use or storage of the instrument in direct sunlight, or in extremely hot or cold areas.
- Use of the instrument in areas of low or high atmospheric pressure may cause instrument failure due to material deterioration.
- Do not store the instrument in a highly damp or dusty environment. Avoid getting water or oil on the instrument during use.
- Do not use an electric marking or other high voltage device near the instrument. Electronic parts in the instrument may be damaged. Use in areas where a large amount of electrical noise is present may result in malfunction.
- Secure the instrument with a dial gage stand or similar fixture in a vibration-free environment.
- Do not subject the spindle to a vertical load or torsion.
- To clean the instrument, use a dry soft cloth or cotton swab, or one soaked in diluted neutral detergent. Use of organic solvents (such as thinner or benzene) may result in failure.
- The contaminated spindle may cause malfunction. Wipe them off with a cloth damped with alcohol.

To maintain measuring accuracy, take note of the following point.

IMPORTANT

- In areas of significant temperature fluctuation, thermal expansion of component parts may cause the measured origin to shift from the set origin. Use the instrument in a temperature-controlled room with as little temperature fluctuation as possible. Before starting measurement, allow the instrument and the item measured sufficient time to thermally stabilize.

Disposal Warnings

Liquid crystal is used in this product. When disposing the product, be sure to conform to the local ordinances or regulations in effect in your area.



- Liquid crystal parts contain a liquid which acts as an irritant. If this liquid accidentally contacts eyes or skin, cleanse the contacted area with clean running water. If taken into the mouth, rinse the mouth immediately and swallow plenty of water. Induce vomiting, then consult a physician.

Warranty

This instrument is manufactured under Mitutoyo's strict quality control system. Should the instrument fail within one year after the date of purchase under normal usage conditions, Mitutoyo will repair it free of charge. Contact your place of purchase or a Mitutoyo sales office.

Mitutoyo will not repair the instrument free of charge in the following cases:

- ◆ If the instrument is damaged or broken due to incorrect operation or unauthorized modifications or repair.
- ◆ If the instrument is damaged or broken due to a drop or shock during moving or shipping after purchase.
- ◆ If the instrument is damaged or broken due to fire, salt damage, toxic gas, abnormal voltage or natural calamity.

This warranty is valid only in the area of purchase.

WARNING ON EXPORT CONTROL COMPLIANCE

The goods, technologies or software described herein may be subject to National or International, or Japanese Export Controls. To export directly or indirectly such matter without due approval from the appropriate authorities may therefore be a breach of export control regulations and the law.


Contents

CONVENTIONS USED IN USER'S MANUAL	<i>i</i>
Safety Precautions	<i>i</i>
On Various Type of Notes	<i>i</i>
Cautions on Use	<i>ii</i>
Power Supply Warnings	<i>ii</i>
Other Cautions on Use	<i>ii</i>
Disposal Warnings	<i>iii</i>
Warranty	<i>iii</i>
WARNING ON EXPORT CONTROL COMPLIANCE	<i>iii</i>
1 NAME OF PARTS	<i>1</i>
1.1 Main Unit	<i>1</i>
1.2 Detail of LCD	<i>2</i>
2 Installing the INSTRUMENT	<i>3</i>
2.1 Securing the Instrument to a Stand or Fixture	<i>3</i>
2.2 Mounting the Lifting Lever	<i>3</i>
2.3 Mounting the Release	<i>3</i>
2.4 Mounting the Back	<i>4</i>
2.5 Replacing the Contact Point	<i>4</i>
3 Basic Operations	<i>5</i>
3.1 Connecting the Power Source	<i>6</i>
3.2 Starting/ Stopping the Instrument	<i>6</i>
3.3 Initial Settings	<i>6</i>
3.3.1 Switching the Inch/ Metric	<i>6</i>
3.3.2 Switching the Resolution	<i>6</i>
3.3.3 Switching the Measurement System	<i>6</i>
3.3.4 Setting the Origin (PRESET)	<i>7</i>
3.4 Measurement Modes	<i>8</i>
3.4.1 Normal Mode	<i>8</i>
3.4.2 Tolerance Mode	<i>8</i>
3.4.3 Max. Peak Hold Mode	<i>9</i>
3.4.4 Min. Peak Hold Mode	<i>9</i>
3.4.5 TIR (Run-Out) Measurement Mode	<i>9</i>

3.5 Analog Display	10
3.5.1 Switching the Display Range	10
3.5.2 Pointer Centering	10
3.6 Switching the Counting Direction	10
3.7 Function Lock	10
4 Data I/O	11
4.1 Output Connector	11
4.2 Output Data Format(DATA1)	11
4.3 Timing Chart	12
5 Error Messages & Corrective Measures	13
6 Specifications	14
6.1 Specifications of the main unit	14
6.2 Standard accessories	14
6.3 Optional accessories	14
6.4 Dimensions	15


1 NAME OF PARTS

1.1 Main Unit



- | | | |
|--------------------|--|-------------------------------------|
| ① Cap | ⑧ LCD | ⑮ +/− key |
| ② Flat back | ⑨ ZERO/ABS key | ⑯ in/mm key(AGD model) |
| ③ Stem | ⑩ PRESET/SET key | ⑰ Release hole
(With Rubber cap) |
| ④ Spindle | ⑪ RES key | ⑱ AC adapter |
| ⑤ Contact point | ⑫ RANGE/ \rightarrow Adj. \leftarrow key | ⑲ Lifting lever |
| ⑥ Output connector | ⑬ MODE key | |
| ⑦ DC jack | ⑭ ON/OFF key | |

1.2 Detail of LCD



- ① Analog range
- ② Upper over range
- ③ Upper pointer(blink)
- ④ Pointer
- ⑤ Lower pointer(blink)
- ⑥ Lower over range
- ⑦ Hold sign
- ⑧ Function lock
- ⑨ Comparison measure
- ⑩ Reverse count measure
- ⑪ Min. peak hold mode
- ⑫ TIR mode
- ⑬ Max. peak hold mode
- ⑭ Unit
- ⑮ Preset the origin
- ⑯ GO/NG judgment display

-
- The pointers ③,④and⑤ blink more quickly when two or more overlap.
 - The parameters indicated by pointers ③ and ⑤ are determined by the measurement mode, as shown below.
-

mode	Nomal	Tolerance	Max.peak hold	Min.peak hold	TIR hold
③	(disappear)	Upper limit	Max. point	(disappear)	Max. point
⑤	(disappear)	Lower limit	(disappear)	Min. point	Min. point

2 INSTALLING THE INSTRUMENT

2.1 Securing the Instrument to a Stand or Fixture

- Secure the instrument by its stem to a dial gage stand (sold separately) or similar fixture.
- When securing the instrument to a fixture, fixing the stem using a slotted holder with an indentation of $\text{Ø}8\text{G7(AGD:Ø9.52)}^{+0.02}_{-0.005}$ mm. is recommended.

NOTE

- Avoid using a lock screw to fix the stem directly. If it is fixed under a clamping torque of 150cN·m or greater, the spindle may not move smoothly.
- Set up the instrument with the spindle perpendicular to the reference plane or the measured surface. If the spindle axis is not perpendicular to the reference plane (measured surface), measurement errors will result.

TIP

For example, if the spindle axis is inclined by an angle ϕ from the perpendicular to the reference plane, for a measured length of about 25 mm and 50mm, the measurement error δ_{25} , will be:


$$\phi = 1^\circ : \delta_{25} = 0.004\text{mm}, \phi = 2^\circ : \delta_{25} = 0.015\text{mm}, \phi = 3^\circ : \delta_{25} = 0.034\text{mm}$$

the measurement error δ_{50} , will be:

$$\phi = 1^\circ : \delta_{50} = 0.008\text{mm}, \phi = 2^\circ : \delta_{50} = 0.031\text{mm}, \phi = 3^\circ : \delta_{50} = 0.069\text{mm}$$


2.2 Mounting the Lifting Lever

- Fit the spindle into the groove on the lifting lever (No. 137693/ standard accessory), holding the spindle's other end so that it doesn't bend.



2.3 Mounting the Release

- Remove the rubber cap from the release mounting hole, and then insert the release (No.21JZA295/ sold separately) into the hole as deep as possible.
(Store the remove rubber cap, taking care not to lose. When attaching the rubber cap, screw it into the hole.)




- CAUTION**
- Pulling sharply on the release or knocking it may strip the thread.
 - Inserting objects other than the release into the release hole, or applying excessive force to the hole may cause instrument failure.
 - When using the release, the amount of lift is about 25 mm (1"). from the lower limit.

2.4 Mounting the Back

The gage can be used with various types of backs for Mitutoyo standard dial indicators (2 series).

- Remove the four screws on top of the back and use them to attach the original back and the optional back.




TIP Refer to Mitutoyo's general catalog for the lineup of available backs.

2.5 Replacing the Contact Point

Various types of interchangeable contact points and extension rods are available for Mitutoyo dial indicators.

- Hold the spindle with a pair of pliers, protecting its surface with a rag.
- Use another pair of pliers to screw in the contact point or remove it.



- CAUTION**
- Hold the spindle in place while doing this procedure, or internal instrument failure may result. Use a rag to protect the spindle's surface. The spindle may not move smoothly if scratched.

TIP


- Refer to Mitutoyo's general catalog for the lineup of interchangeable contact points, and extension rods.
- Roller contact point run-out and other contact point errors decrease measurement accuracy.
- Replacing the contact point changes the external dimensions, measuring force and other parameters.
- For questions about replacement parts, contact your place of purchase or Mitutoyo service center.

3 BASIC OPERATIONS

Key function list

Key	Condition	Functions	page
ON/OFF	Anytime	Switching ON↔OFF	6
RES	Anytime	Switching 0.001mm↔0.01mm(.00005"↔.0005")	6
ZERO /ABS	Normal or Tolerance mode	<2sec Switch to the INC system & set to zero >2sec Switch to the ABS system	6 6
	While preset	Cancel preset value & return to the previous condition.	7
	Max, Min hold mode, >2sec	ABS Set to zero at the hold position. INC Set to zero at the current position	9 9
	Normal mode	Enter the origin setting(Switch to the ABS system)	7
	While check limit, >2sec	Enter the tolerance limit setting	8
PRESET /SET	except above	Enter the selected mode, release the hold	8
	Normal mode	Select measurement modes	8
MODE	except above, >2sec	Return to the normal mode	8
	<2sec	Switching the analog display range	10
RANGE/ →Adj.←	>2sec	Pointer centering in analog display's range	10
+/-	Normal mode, <2sec	Switching the Counting Direction	10
	Any modes, >2sec	Switching the function lock↔unlock	10
in/mm	(AGD model)	Switching inch↔mm	6

※ ABS:Absolute measurement system, INC:Comparative measurement system,
>2sec:Press longer than 2sec., <2sec:Short press(less than 2sec.),



3.1 Connecting the Power Source

- Remove the DC jack cover at the top of the instrument's display. Insert the DC plug of the AC adapter (standard accessory) securely into the DC IN jack.
- Insert the AC plug at the other end securely into a power outlet or extension cord.
- As soon as power is supplied, LCD appears and the back light turns on.

IMPORTANT • Before shutting off the power supply, always press the [ON/OFF] key to turn the instrument off. Shutting off the power while the instrument is operating can damage origin and other memory data.

3.2 Starting/ Stopping the Instrument

- Press the [ON/OFF] key to start(begin) and stop(end) the instrument.

3.3 Initial Settings

3.3.1 Switching the Inch/ Metric

- Press the [in/mm] key to toggle the display units between inches↔metric (AGD model).

3.3.2 Switching the Resolution

- Press the [RES] key a short press to toggle the display resolution (between 0.206 mm.↔0.21 mm., for example).
- When using inch units, press and hold the [RES] key for 5 seconds or longer in the normal mode to switch the resolution between .00005"↔.0001"(.0005"↔.001") (AGD model only).

[RES]<5sec			
[in/mm]	0.001mm	↔	0.01mm
↔			
[RES] >5sec	0.00005"	↔	0.0005"
	↔		↔
	0.0001"	↔	0.001"

Switching the Resolution

NOTE

- When the resolution and units are switched, the analog display range also switches.
- The last digit of preset values and tolerance setting values is rounded off according to the number of display digits and units.
- When the display resolution is toggled between .00005"↔.0001"(.0005"↔.001"), set preset values and tolerance values are erased.

3.3.3 Switching the Measurement System

3.3.3.1 Absolute (ABS) Measurement System

When the origin is set in the ABS system, the absolute origin position for measurement is stored in memory. The origin position is held, as long as its position in relation to the absolute origin, or setting value do not change. Measured values are displayed as distances from the absolute origin.

- To switch to the INC system, press the [ZERO/ABS] key in the normal mode or tolerance determination mode. "INC" appears in the LCD and the display is set to zero. (Press and hold the [ZERO/ABS] key again to return to ABS mode).

3.3.3.2 Comparative (INC) Measurement System

The INC system holds the position data of the absolute origin, and displays the distance from the position set to zero.

- To switch to the ABS system, press and hold the [ZERO/ABS] key for 2 seconds or longer in the normal mode or tolerance determination mode.

3.3.4 Setting the Origin (PRESET)

This section describes how to set the absolute origin for measurement (preset value). You can use a calibrated reference gage or master gage to set a reference plane outside the instrument's measuring range as absolute origin.

- To set the preset value, press [PRESET/SET] key3 in the normal mode. The previously set preset value appears and "P" blinks in the display.
- The gage is forcibly switched to the ABS system when the origin is preset.
- To set a new preset value, press and hold the [PRESET] key for 2 seconds to select which digit to set. The blinking digit can be set. Give the [PRESET] key a short press to increase the value of the blinking digit.
- While "P" is blinking, give the [PRESET] key a short press to set the new preset value. This value is stored in memory as the distance (origin data) from the absolute origin to the current position of the contact point.


For example, to measure a length which cannot be measured by the instrument alone, as shown in the diagram, set the absolute origin with the bottom end of the master gauge as the measurement reference (0.000 mm.). When the calibration value of the master gauge length is approx. 100.002 mm. and the contact point is contacting the master gauge, set the calibration value to the preset value (origin position setting) by the following procedure.

[PRESET]key	Display value
(set value) press ↓ 2sec.	5.432 mm +000.000 mm P
↓ 2sec.	±000.000 mm P
release	+000.000 mm P
short press	+100.000 mm P
press ↓ 2sec.	+100.000 mm P
↓ 2sec.	+100.000 mm P
↓ 2sec.	+100.000 mm P
↓ 2sec.	+100.000 mm P
↓ 2sec.	+100.000 mm P
release	+100.000 mm P
short press x2	+100.002 mm P
press ↓ 2sec.	+100.002 mm P
release	+100.002 mm P
short press (fix)	100.002 mm
(repeat value) press short press (fix)	99.876 mm +100.002 mm P 100.002 mm

“_” mean blinking the digit.

NOTE

- When setting the origin or the preset value, be sure to lift the spindle at least 0.2mm above the bottom dead center.
- After starting to set the preset value, pressing [ZERO/ABS] before the new preset value has been fixed returns the instrument to the condition it was in before the setting (returns to 99.876 mm. or 5.432 mm. in the above example).
- If the instrument is turned off and on during preset or tolerance setting, the value being set is erased and the gage returns to the condition it was in before setting.



3.4 Measurement Modes

The instrument has the five measurement modes described below (see page 5.).

3.4.1 Normal Mode

This mode is used for normal measurement, and to select the other modes.

- NOTE**
- To set the origin, switch between + and -, set tolerance limits, or select a new measurement mode, you must return to the normal mode.

3.4.2 Tolerance Mode

3.4.2.1 Checking and Setting Tolerance Limits

Tolerance mode is used to check and set the tolerance limits. Note that the tolerance limits must be set separately for the ABS system and the INC system.

- Press the [MODE] key once in the normal mode. "◀○▶" blinks in the display.
- Press the [PRESET/SET] key to check the tolerance upper limit setting. The previously set upper limit appears with a blinking "▶" sign.
- To change the upper limit setting, press the [SET] key, and use the same procedure used to set the origin.
- When the new value has been set ("▶" blinks), press the [SET] key quickly to check the tolerance lower limit setting. The previously set lower limit appears with a blinking "◀" sign. Change the setting by the same procedure used to change the upper limit setting.
- When both limits have been set correctly, give the [SET] key short press to enter tolerance determination mode.
- Press and hold the [MODE] key for 2 seconds or longer to return to the normal mode from Tolerance mode.

3.4.2.2 Tolerance Determination

If the current measurement value deviates from the range of the tolerance limits set in the previous section, the back lights red as a warning.

- When the tolerance limits have been checked by the procedure in the previous section, the instrument starts tolerance determination straight away.

- NOTE**
- There is no tolerance determination function for max./ min. hold and TIR measurement values.
 - To change the setting of the tolerance limits, first return to the normal mode and then switch to tolerance mode again.


3.4.3 Max. Peak Hold Mode

In this mode, the instrument holds the maximum value in the series of varying measured values.

- Press the [MODE] key twice in the normal mode. "Max" blinks in the display.
- Press the [PRESET/SET] key to switch to Max hold mode ("Max" stops blinking).
- When the spindle moves, the maximum value is held ("H" appears).
- Press the [SET] key to release the hold, display the current position, and start measuring a new maximum value.
- Press and hold the [MODE] key for 2 seconds or longer to return to the normal mode from Max. Peak Hold mode.


difference of Max,Min,TIR hold mode.

Path	0	→	a	→	b	→	c	→	d
Max mode	0.00	↗		5.00		↗	10.00		
Min mode			0.00	↘		5.00		-5.00	
TIR mode	0.00	↗	5.00	↗	10.00	↗	15.00		



- If max. hold mode is entered from the ABS system, press the [ZERO/ABS] key for 2 seconds or longer to set the position being held to zero. The instrument can be used for comparative measurement.
- If max. hold mode is entered from the INC system, press the [ZERO/ABS] key for 2 seconds or longer to set the current position to zero.

difference of after Zero set (at Max. hold mode)



3.4.4 Min. Peak Hold Mode

In this mode, the instrument holds the minimum value in the series of varying measured values.

- Press the [MODE] key three times in the normal mode. "Min" blinks in the display.
- Min. hold mode operations are done by the same procedure as max. hold mode.

3.4.5 TIR (Run-Out) Measurement Mode

In this mode, the instrument holds the run-out width in the series of varying measured values. Only this mode has the same operation in both the ABS and INC systems.

- Press the [MODE] key four times in the normal mode. "TIR" blinks in the display.
- Press the [PRESET/SET] key to set the display to zero ("TIR" appears).
- When the spindle moves, the run-out width is held ("H" appears).
- Press the [SET] key to release the held value and start measuring a new run-out width value.

3.5 Analog Display

An analog scale and pointer in the form of dial indicator are continuously displayed at the top of the instrument's LCD. In tolerance determination mode, the limit positions blink in this area. In max./ min. hold mode or TIR mode, the maximum and minimum positions blink in this area.

3.5.1 Switching the Display Range

The analog display range can be switched to prevent pointers going too high or low.

- Press the [RANGE/→Adj.←] key a short press to toggle the display range.

Resolution	Switching the display range(loop)				
0.001mm	0.02(mm)	→0.04	→0.1	→0.2	→0.4
0.01mm	0.2(mm)	→0.4	→1	→2	→4
.00005"	0.001("	→0.002	→0.004	→0.01	→0.02
.0005"	0.01("	→0.02	→0.04	→0.1	→0.2
.0001"	0.002("	→0.004	→0.01	→0.02	→0.04
.001"	0.02("	→0.04	→0.1	→0.2	→0.4


3.5.2 Pointer Centering

When a pointer is out of the analog display's range, use this function to shift the display so that the pointer is centered. This has the same effect as adjusting the bezel of a dial indicator to the desired scale.

- Press the [RANGE/→Adj.←] key for 2 seconds or longer to center the pointer.

NOTE •The pointer position is adjusted so that the current measured value is in the center.

e.g., In case of judgement tolerance for the 10.000 ± 0.02 (Upper & lower limit: 10.020 & 9.980)



3.6 Switching the Counting Direction

By default, the instrument takes the positive direction to be the direction the spindle moves in when it is pushed in. If desired, this direction can be set as the negative direction.

- To reverse the counting direction, press the [+/-] key in the normal mode ("REV" appears).

3.7 Function Lock


- Pressing the [+/-] key for 2 seconds or longer deactivates all key input except ON/OFF and hold release (🔒 appears).
- To reactivate the keys, press the [+/-] key again for 2 seconds or longer.

4 DATA I/O


Using the Connecting Cable (sold separately), the instrument can be connected to the DP-1VA LOGGER Digimatic Mini-processor or similar data processors, to transfer, total and record measurement values.

- Remove the output connector cover and insert the cable securely. (Store the cover in a safe place).


4.1 Output Connector




PIN#	Signal	I/O
1.	GND	-
2. *1	DATA1	OUT
3. *1	\overline{CK}	OUT
4.	-	-
5. *2	\overline{REQ}	IN
6.	-	-
7.	-	-
8.	+9V	-
9.	+9V	-
10.	GND	-




4.2 Output Data Format (DATA1)



For example., In case of output data as "-2.471mm".



4.3 Timing Chart



IMPORTANT

- Use only the Connecting Cable specified by Mitutoyo. Use of incompatible or deteriorated cables may result in data output failure.
- Before outputting data, read the manual that comes with the data processor carefully to ensure correct operation.
- Data output may be disabled if an output request (REQ) is received when the spindle is in motion, or if the output request interval is too short.

CAUTION

- *1: To make an output request (REQ), hold the REQ signal at "Low" until "CK" is output. Return it to "High" before the final (52nd) "CK" bit is output.

5 ERROR MESSAGES & CORRECTIVE MEASURES

Display	Description and Corrective measures
XXXXE	ABS composition error If this error occurs while the spindle is stopped, it is a malfunction in the internal sensor. <ul style="list-style-type: none">▪ The instrument requires repair. Contact the Mitutoyo distributor or sales office where you purchased the product.▪ When this error is displayed and soon disappears during spindle movement, this is not the result of an instrument malfunction. This is just an internal processing.
E--SE	Tolerance setting error The tolerance limit value is set with the upper limit value being smaller than the lower limit value. <ul style="list-style-type: none">▪ Press the Set key to return to tolerance value setting, and then set the value so that the upper limit value is greater than the lower limit value.
E-->SE	Upper limit value setting error The upper limit value exceeds the number of digits which can be displayed. <ul style="list-style-type: none">▪ Press and hold the SET key to return to the upper limit value setting, and then set an appropriate value again.
E--<SE	Lower limit value setting error The Lower limit value exceeds the number of digits which can be displayed. <ul style="list-style-type: none">▪ Press and hold the SET key to return to the lower limit value setting, and then set an appropriate value again.
E--OF	Display overflow The display value exceeds the number of digits which can be displayed. <ul style="list-style-type: none">▪ During the ABS measurement mode, press the SET key to start measurement origin setting, and then set the preset value again.▪ During the INC measurement mode, press the SET key at an appropriate position to zeroset.

6 SPECIFICATIONS

6.1 Specifications of the main unit

Model name Code No. *1	ID-F125 543-551	ID-F150 543-553	ID-H150H 543-557	ID-F125E 543-552	ID-F150E 543-554	ID-F150HE 543-558				
Resolution	0.001 mm/0.01 mm			0.001/0.01 mm/0.00005/0.0005/0.0001/0.001 in						
Measuring range	25.4 mm	50.8 mm		25.4 mm = 1 in	50.8 mm = 2 in					
Error of indication for the total measuring range MPE _E (20°C)	0.003 mm	0.006 mm	0.003 mm	0.003 mm / ±0.00012 in	0.006 mm / ±0.00024 in	0.003 mm / ±0.00012 in				
Hysteresis MPE _H (20°C)	0.002 mm			0.002 mm/0.00010 in						
Repeatability MPE _R (20°C)	0.002 mm			0.002 mm/0.00010 in						
Stem diameter Contact point	Ø8 mm Carbide (M2.5x0.45)			Ø9.52 mm = 3/8 in DIA Carbide (#4-48UNF)						
Measuring force MPL	1.8 N or less	2.3 N or less		1.8 N or less	2.3 N or less					
Protection level	Equivalent to IP30 (IEC 60529/JIS C 0920 at factory default)									
Plunger direction	Below the horizon									
Power supply	AC adapter, 9V, 1.2 A									
Operating temp.	0 °C ~ 40 °C									
Storage temp.	-10 °C ~ 60 °C									
Net weight	Approx. 220 g	Approx. 290g		Approx. 220 g (0.49 lbs.)	Approx. 290 g (0.64 lbs.)					

*1 : The code No. suffix varies depending on the included AC adapter.

6.2 Standard accessories


#99MAH001B	User's manual Warranty Product regulation manual Certificate of Inspection
#137693	Lifting lever
#06AGC585JA	AC adapter (100-240V : Japan, USA, Canada, &Co.)
#06AGC585D	AC adapter (100-240V : Germany, &Co.)
#06AGC585E	AC adapter (100-240V : UK, &Co.)
#06AGC585K	AC adapter (100-240V : Korea for KC)
#06AEG302DC	AC adapter (100-240V : China for CCC)

6.3 Optional accessories


#21JZA295	Release cable
#936937	M-SPC cable 1m
#965014	M-SPC cable 2m
#02ACA571	Coil spring for upside-down position (for 125 model)
#02ACA773	Coil spring for upside-down position (for 150 model)
Backs for Mitutoyo standard dial gages (2 series)	
Interchangeable contact point and extension rods for Mitutoyo dial gages	

6.4 Dimensions

Dimension shown in the double column are $\frac{\text{mm}}{\text{inch}}$, except they are mm.



ID-F125 (543-551-1)
ID-F125E (543-552-1)



ID-F150	(543-553-1)
ID-F150E	(543-554-1)
ID-F150H	(543-557-1)
ID-F150HE	(543-558-1)

SERVICE NETWORK

*As of May 2020

Europe

Mitutoyo Europe GmbH

Borsigstrasse 8-10, 41469 Neuss, GERMANY
TEL: 49 (0)2137 102-0 FAX: 49 (0)2137 102-351

Mitutoyo CTL Germany GmbH

Von-Guntzert-Strasse 17, 78727 Oberndorf, GERMANY
TEL: 49 (0)7423 8776-0 FAX: 49 (0)7423 8776-99

KOMEG Industrielle Messtechnik GmbH

Zum Wasserwerk 3, 66333 Völklingen, GERMANY
TEL: 49 (0)6898 91110 FAX: 49 (0)6898 9111100

Germany

Mitutoyo Deutschland GmbH

Borsigstrasse 8-10, 41469 Neuss, GERMANY
TEL: 49 (0)2137 102-0 FAX: 49 (0)2137 86 85

M³ Solution Center Hamburg

Tempowerkling 9-im HIT-Technologiepark 21079
Hamburg, GERMANY
TEL: 49 (0)40 791894-0 FAX: 49 (0)40 791894-50

M³ Solution Center Berlin

Ernst-Lau-Straße 6, 12489 Berlin, GERMANY
TEL: 49 (0)30 2611 267 FAX: 49 30 67988729

M³ Solution Center Eisenach

Neue Wiese 4, 99817 Eisenach, GERMANY
TEL: 49 (0)3691 88909-0 FAX: 49 (0)3691 88909-9

M³ Solution Center Ingolstadt

Marie-Curie-Strasse 1A, 85055 Ingolstadt, GERMANY
TEL: 49 (0)841 954920 FAX: 49 (0)841 9549250

M³ Solution Center Leonberg

Steinbeisstrasse 2, 71229 Leonberg, GERMANY
TEL: 49 (0)7152 6080-0 FAX: 49 (0)7152 608060

Mitutoyo-Messgeräte Leonberg GmbH

Heidenheimer Strasse 14, 71229 Leonberg, GERMANY
TEL: 49 (0)7152 9237-0 FAX: 49 (0)7152 9237-29

U.K.

Mitutoyo (UK) Ltd.

Joule Road, West Point Business Park,
Andover, Hampshire SP10 3UX, UNITED KINGDOM
TEL: 44 (0)1264 353 123 FAX: 44 (0)1264 354883

M³ Solution Center Coventry

Unit6, Banner Park, Wickmans Drive, Coventry,
Warwickshire CV4 9XA, UNITED KINGDOM
TEL: 44 (0)2476 426300 FAX: 44 (0)2476 426339

M³ Solution Center Halifax

Lowfields Business Park, Navigation Close, Elland,
West Yorkshire HX5 9HB, UNITED KINGDOM
TEL: 44 (0)1422 375566 FAX: 44 (0)1422 328025

M³ Solution Center East Kilbride

The Baird Building, Rankine Avenue, Scottish
Enterprise Technology Park, East Kilbride G75
0QF, UNITED KINGDOM
TEL: 44 (0)1355 581170 FAX: 44 (0)1355 581171

France

Mitutoyo France

Paris Nord 2-123 rue de la Belle Etoile, BP 59267
ROISSY EN FRANCE 95957 ROISSY CDG
CEDEX, FRANCE
TEL: 33 (0)149 38 35 00

M³ Solution Center LYON

Parc Mail 523, cours du 3ème millénaire, 69791
Saint-Priest, FRANCE
TEL: 33 (0)149 38 35 70

M³ Solution Center STRASBOURG

Parc de la porte Sud, Rue du pont du péage,
67118 Geispolsheim, FRANCE
TEL: 33 (0)149 38 35 80

M³ Solution Center CLUSES

Espace Scionzier 480 Avenue des Lacs, 74950
Scionzier, FRANCE
TEL: 33 (0)149 38 35 90

M³ Solution Center TOULOUSE

Aeroparc Saint Martin Cellule B08 ZAC de Saint
Martin du Touch 12 rue de Caulet 31300
Toulouse, FRANCE
TEL: 33 (0)149 38 42 90

M³ Solution Center RENNES

2, rue Claude Chappe, PA le Vallon - ZAC
Mivoie, 35230 Noyal-Châtillon-sur-Seiche,
FRANCE
TEL: 33 (0)149 38 42 10

Italy

MITUTOYO ITALIANA S.r.l.

CORSO EUROPA, 7 - 20020 LAINATE (MI), ITALY
TEL: 39 02 935781 FAX: 39 02 9373290•93578255

M³ Solution Center BOLOGNA

VIA DEI CARPINI 1/A - 40011 ANZOLA EMILIA (BO), ITALY
TEL: 39 02 93578215 FAX: 39 02 93578255

M³ Solution Center CHIETI

Contrada Santa Calcagna - 66020 Rocca S.
Giovanni (CH), ITALY
TEL: 39 02 93578280 FAX: 39 02 93578255

M³ Solution Center PADOVA

VIA G. GALILEI 21/F - 35035 MESTRINO (PD), ITALY
TEL: 39 02 93578268 FAX: 39 02 93578255

Netherlands

Mitutoyo Nederland B.V.

WILTONSTRAAT 25, 3905 KW Veenendaal,
THE NETHERLANDS
TEL: 31(0)318-534911

Mitutoyo Research Center Europe B.V.

DE RIJN 18, 5684 PJ BEST, THE NETHERLANDS
TEL: 31(0)499-320200 FAX: 31(0)499-320299

Belgium

Mitutoyo Belgium N.V. / M³ Solution Center Melsele

SCHAARBEEKstraat 20, B-9120 Melsele, BELGIUM
TEL: 32 (0)3-2540444

Sweden

Mitutoyo Scandinavia AB

SLÄNTVÄGEN 6, 194 61 UPPLANDS VÄSBY, SWEDEN
TEL: 46 (0)8 594 109 50 FAX: 46 (0)8 590 924 10

M³ Solution Center Alingsås

ÄNGSVAKTAREGATAN 3A, 441 38 ALINGSÅS, SWEDEN
TEL: 46 (0)8 594 109 50 FAX: 46 (0)322 63 31 62

M³ Solution Center Värnamo

STORGATSBACKEN 1, 331 30 VÄRNAMO, SWEDEN
TEL: 46 (0)8 594 109 50 FAX: 46 (0)370 463 34

Switzerland

Mitutoyo (Schweiz) AG

STEINACKERSTRASSE 35, 8902 URDORF, SWITZERLAND
TEL: 41 (0)447361150 FAX: 41(0)447361151

Mitutoyo (Suisse) SA

RUE GALILIÉ 4, 1400 YVERDON-LES BAINS, SWITZERLAND
TEL: 41 (0)244259422 FAX: 41 (0)447361151

Poland

Mitutoyo Polska Sp.z o.o.

UL.GRANICZNA 8A, 54-610 WROCŁAW, POLAND
TEL: 48 (0)71354 83 50 FAX: 48 (0)71354 83 55

Czech Republic

Mitutoyo Česko s.r.o.

DUBSKÁ 1626, 415 01 TEPlice, CZECH REPUBLIC
TEL: 420 417-514-011 FAX: 420 417-579-867

Mitutoyo Česko s.r.o. M³ Solution Center Ivančice

KE KARLOVU 62/10, 664 91 IVANČICE, CZECH REPUBLIC
TEL: 420 417-514-011 FAX: 420 417-579-867

Mitutoyo Česko s.r.o. M³ Solution Center Ostrava Mošnov

MOŠNOV 314, 742 51 MOŠNOV, CZECH REPUBLIC
TEL: 420 417-514-050 FAX: 420 417-579-867

Mitutoyo Česko s.r.o. Slovakia Branch

Hviezdoslavova 124, 017 01 Povážská
Bystrica, SLOVAKIA
TEL: 421 948-595-590

Hungary

Mitutoyo Hungária Kft.

ZÁHONY UTCA 7, D-ÉPÜLET / FSZ, 1031 BUDAPEST, HUNGARY
TEL: 36 (0)1 2141447 FAX: 36 (0)1 2141448

Romania

Mitutoyo Romania SRL

1A DRUMUL GARII ODAI STREET, SHOWROOM, GROUND
FLOOR, 075100 OTOPENI-ILFOV, ROMANIA
TEL: 40 (0)311012088 FAX: +40 (0)311012089

Showroom in Brasov

STRADA IONESCU CRUM NR.1, BRASOV BUSINESS
PARK TURNUL 1, MEZANIN, 500446
BRASOV-JUDETUL BRASOV, ROMANIA
TEL/FAX: 40 (0)371020017

Russian Federation

Mitutoyo RUS LLC

13 SHARIKOPODSHIPNIKOVSKAYA, BLD.2,
115088 MOSCOW, RUSSIAN FEDERATION
TEL: 7 495 7450 752

Finland

Mitutoyo Scandinavia AB Finnish Branch

VIHERKIUTTÄJÄ 2A, 33960, PIRKKALA, FINLAND
TEL: 358 (0)40 355 8498

Austria

Mitutoyo Austria GmbH

Salzburger Straße 260 / 3 A-4600 Wels, AUSTRIA
TEL: 43 (0)7242 219 998

Mitutoyo Austria GmbH Goetzis Regional showroom

Lastenstrasse 48a 6840 Götzis AUSTRIA

Singapore

Mitutoyo Asia Pacific Pte. Ltd.

Head office / M³ Solution Center

24 Kallang Avenue, Mitutoyo Building,
SINGAPORE 339415
TEL:(65)62942211 FAX:(65)62996666

Malaysia

Mitutoyo (Malaysia) Sdn. Bhd.

Kuala Lumpur Head Office / M³ Solution Center

Mah Sing Integrated Industrial Park, 4, Jalan Utarid U5/14,
Section U5, 40150 Shah Alam, Selangor, MALAYSIA
TEL:(60)3-78459318 FAX:(60)3-78459346

Penang Branch office / M³ Solution Center

30, Persiaran Mahsuri 1/2, Sunway Tunas, 11900
Bayan Lepas, Penang, MALAYSIA
TEL:(60)4-6411998 FAX:(60)4-6412998

Johor Branch office / M³ Solution Center

70 (Ground Floor), Jalan Molek 1/28, Taman
Molek, 81100 Johor Bahru, Johor, MALAYSIA
TEL:(60)7-3521626 FAX:(60)7-3521628

Thailand

Mitutoyo(Thailand)Co., Ltd.

Bangkok Head Office / M³ Solution Center

76/3-5, Chaengwattana Road, Kwaeng Anusaowaree,
Khet Bangkaen, Bangkok 10220, THAILAND
TEL:(66)2-080-3500 FAX:(66)2-521-6136

Chonburi Branch / M³ Solution Center

7/1, Moo 3, Tambon Bowin, Amphur Sriracha,
Chonburi 20230, THAILAND
TEL:(66)2-080-3563 FAX:(66)3-834-5788

ACC Branch / M³ Solution Center

122/8, 122/9, Moo 6, Tambon Donhuaroh, Amphur
Muangchonburi, Chonburi 20000, THAILAND
TEL:(66)2-080-3565

Indonesia

PT. Mitutoyo Indonesia

Head Office / M³ Solution Center

Jalan Sriwijaya No.26 Desa cibatu Kec. Cikarang
Selatan Kab. Bekasi 17530, INDONESIA
TEL: (62)21-2962 8600 FAX: (62)21-2962 8604

Vietnam

Mitutoyo Vietnam Co., Ltd

Hanoi Head Office / M³ Solution Center

1st & 2nd floor, MHDI Building, No. 60 Hoang Quoc
Viet Road, Nghia Do Ward, Cau Giay District, Hanoi,
VIETNAM

TEL:(84)24-3768-8963 FAX:(84)24-3768-8960

Ho Chi Minh City Branch Office / M³ Solution Center

123 Dien Bien Phu Street,Ward 15,Binh Thanh
District, Ho Chi Minh City, VIETNAM
TEL:(84)28-3840-3489 FAX:(84)28-3840-3498

Philippines

Mitutoyo Philippines, Inc.

Head Office / M³ Solution Center

Unit 1B & 2B LTI, Administration Building 1, Annex 1, North
Main Avenue, Laguna Technopark, Binan Laguna 4024,
PHILIPPINES

TEL:(63)49 544 0272 FAX:(63)49 544 0272

India

Mitutoyo South Asia Pvt. Ltd. Head Office

C-122, Okhla Industrial Area, Phase-I,
New Delhi-110 020, INDIA
TEL:(91) 11-26372090 FAX: (91) 11-26372636

MSA Gurgaon technical center

Plot no. 65, Ground Floor, Udyog Vihar, Phase-4 Gurgaon,
Haryana - 122016
TEL : (91) 124-2340286/287

Mumbai Region Head office

303, Sentinel Hiranandani Business Park Powai,
Mumbai-400 076, INDIA
TEL:(91) 22-25700684/837/839 FAX: (91) 22-25700685

Pune Office / M³ Solution Center

G4/G5, Pride Kumar Senate, Off. Senapati Bapat
Road, Pune-411 016, INDIA
TEL:(91) 20-25660043/44/45 FAX: (91) 20-66033644

Bengaluru Region Head office / M³ Solution Center

No. 5, 100 Ft. Road, 17th Main, Koramangala,
4th Block, Bengaluru-560 034, INDIA
TEL:(91) 80-25630946/47/48 FAX: (91) 80-25630949

Chennai Office / M³ Solution Center

No. 624, Anna Salai Teynampet, Chennai-600 018, INDIA
TEL: (91) 44-24328823/24
FAX: (91) 44-24328825

Kolkata Office

Unit No. 1208,Om Tower, 32,J.L..Nehru Road,
Kolkata-700 071, INDIA
Tel: 91 33-22267088/40060635 Fax: (91) 33-22266817

Ahmedabad Office/M³ Solution Center (Ahmedabad)
A-104 & A-105, First Floor, Solitaire Corporate Park, Near Divya Bhaskar Press, S.G. Road, Ahmedabad - 380 015, INDIA
TEL: (91) 079 - 29704902/903

Coimbatore Office
Regus, Srivari Srimath, 3rd Floor, Door No:1045, Avinashi Road, Coimbatore - 641 018,INDIA
TEL: (91) 9345005663

Taiwan

Mitutoyo Taiwan Co., Ltd. / M³ Solution Center Taipei
4F., No.71, Zhouzi St., Neihu Dist.,Taipei City 114, TAIWAN (R.O.C.)
TEL:886(2)5573-5900 FAX:886(2)8752-3267

Taichung Branch / M³ Solution Center Taichung
1F., No. 299, Gaotie 1st Rd., Wuri Dist., Taichung City 414, TAIWAN (R.O.C.)
TEL:886(4)2338-6822 FAX:886(4)2338-6722

Kaohsiung Branch / M³ Solution Center Kaohsiung
1F., No.31-1, Haibian Rd., Lingya Dist., Kaohsiung City 802, TAIWAN (R.O.C.)
TEL:886(7)334-6168 FAX:886(7)334-6160

South Korea

Mitutoyo Korea Corporation
Head Office / M³ Solution Center
(Sanbon-Dong, Geumjeong High View Build.), 6F, 153-8, Ls-Ro, Gunpo-Si, Gyeonggi-Do, 15808 KOREA
TEL:82(31)361-4200 FAX:82(31)361-4201

Busan Office / M³ Solution Center
(3150-3, Daejeo 2-dong) 8,Yutongdanji 1-ro 49beon-gil, Gangseo-gu, Busan, 46721 KOREA
TEL:82(51)324-0103 FAX:82(51)324-0104

Daegu Office / M³ Solution Center
(Galsan-dong, Daegu Business Center), 301-Ho, 217, Seongseogongdan-ro, Dalseo-gu, Daegu 42704 KOREA
TEL:82(53)593-5602 FAX:82(53)593-5603

China

Mitutoyo Measuring Instruments (Shanghai) Co., Ltd.
8th Floor, Tower 1 Lujiazui Jinkong Square No.1788/1800 Century Ave., Pudong New District, Shanghai 200122, CHINA
TEL:86(21)5836-0718 FAX:86(21)5836-0717

Suzhou Office / M³ Solution Center (Suzhou)
No. 46 Baiyu Road, Suzhou 215021, CHINA
TEL:86(512)6522-1790 FAX:86(512)6251-3420

Wuhan Office
Room 1701, Wuhan Wanda Center, No. 96,

Linjiang Road, Wuchang District, Wuhan Hubei 430060, CHINA
TEL:86(027)8544-8631 FAX:86(027)8544-6227

Chengdu Office
1-701, New Angle Plaza, 668# Jindong Road, Jinjiang District, Chengdu, Sichuan 610066,CHINA
TEL:86(28)8671-8936 FAX:86(28)8671-9086

Hangzhou Office
Room 804, Eastern International Business Center Building 1, No.600 Jinsha Road of Hangzhou Economic and Technological Development Zone, 310018, CHINA
TEL: 86(571)8288-0319 FAX: 86(571)8288-0320

Tianjin Office / M³ Solution Center China (Tianjin)
Room D 12/F, TEDA Building, No.256 Jie-fang Nan Road Hexi District,Tianjin 300042, CHINA
TEL:86(22)5888-1700 FAX:86(22)5888-1701

Changchun Office
Room 815, 8F, Building A1, Upper East International No.3000 Dongsheng Street, Erdao District, Changchun, Jilin, 130031, CHINA
TEL:86(431)8192-6998 FAX:86(431)8192-6998

Chongqing Office
Room 1312, Building 3, Zhongyu Plaza, No.86, Hongjin Avenue,Longxi Street, Yubei District, Chongqing, 400000, CHINA
TEL:86(23)6595-9950 FAX:86(23)6595-9950

Qingdao Office
Room 638, 6F, No.192 Zhengyang Road, Chengyang District, Qingdao, Shandong, 266109, CHINA
TEL:86(532)8096-1936 FAX:86(532)8096-1937

Xi'an Office
Room 805, Xi'an International Trade Center, No. 196 Xiaozhai East Road, Xi'an, 710061, CHINA
TEL:86(29)8538-1380 FAX:86(29)8538-1381

Dalian Office
Room A-106 Shuijing SOHO, No.16 Harbin Road,Economic Development Zone,Dalian, 116600 CHINA
TEL:86(411)8718 1212 FAX:86(411)8754-7587

Zhengzhou Office
Room1801,18/F,Unit1,Building No.23, Shangwu Inner Ring Road, Zhengdong New District,Zhengzhou City, Henan Province, 450018,CHINA
TEL:86(371)6097-6436 FAX:86(371)6097-6981

Mitutoyo Leepot Metrology (Hong Kong) Limited
Room 818, 8/F, Vanta Industrial Centre, No.21-33, Tai Lin Pai Road, Kwai Chung, NT, HONG KONG
TEL:(852)2992-2088 FAX:(852)2670-2488

Mitutoyo Leepot Metrology (Dongguan) Limited / M³ Solution Center Dongguan

No.26, Guan Chang Road, Chong Tou Zone, Chang An Town, Dong Guan, 523855 CHINA
TEL:86(769)8541 7715 FAX:86(769)-8541 7745

Mitutoyo Leepot Metrology (Dongguan) Limited – Fuzhou office

Room 2104, City Commercial Centre, No.129 Wu Yi Road N., Fuzhou City, Fujian Province, 350005 CHINA
TEL 86 (591) 8761 8095
FAX 86 (591) 8761 8096

Mitutoyo Leepot Metrology (Dongguan) Limited –Changsha office

Room 2207, Shiner International Plaza, No. 88, Kai-yuan Middle Road, Changsha City, Hunan Province, 410100 CHINA
TEL 86 (731) 8401 9276
FAX 86 (731) 8401 9376

Mitutoyo Leepot Metrology (Dongguan) Limited -Guangzhou Office

Room 605, Tower A, No. 264 Xing Tai Road, Shi Qiao Street, Pan Yu District, Guangzhou, Guangdong Province, 511400 CHINA
TEL:(86) 20-8466 1987 FAX:(86) 20-8466 1897

Mitutoyo Measuring Instruments (Suzhou) Co., Ltd.
No. 46 Baiyu Road, Suzhou 215021, CHINA
TEL:86(512)6252-2660 FAX:86(512)6252-2580

U.S.A.

Mitutoyo America Corporation

965 Corporate Blvd., Aurora, IL 60502, U.S.A.
TEL:1-(630)820-9666 Toll Free No. 1-888-648-8869
FAX:1-(630)978-3501

M³ Solution Center-Illinois

965 Corporate Blvd., Aurora, IL 60502, U.S.A.

M³ Solution Center-Ohio

6220 Hi-Tek Ct., Mason, OH 45040, U.S.A.
TEL:1-(888)-648-8869 FAX:1-(513)754-0718

M³ Solution Center-Michigan

46850 Magellan Drive, Suite 100 Novi, MI 48377, U.S.A.
TEL:1-(888)-648-8869 FAX: 1-(248)-926-0928

M³ Solution Center-California

16925 E. Gale Ave., City of Industry, CA 91745, U.S.A.
TEL:1-(888)-648-8869 FAX:1-(626)369-3352

M³ Solution Center-North Carolina

11515 Vanstory Dr., Suite 140, Huntersville, NC 28078, U.S.A.
TEL:1-(888)-648-8869 FAX:1-(704)875-9273

M³ Solution Center-Alabama

2100 Riverchase Center Suite 106, Birmingham, AL 35244, U.S.A
TEL:1-(888)-648-8869 FAX:1-(205)-988-3423

M³ Solution Center-Washington

1000 SW 34th St. Suite G, Renton, WA 98057 U.S.A.
TEL:1-(888)-648-8869

M³ Solution Center-Texas

4560 Kendrick Plaza Drive Suite 120 Houston, TX 77032, U.S.A.
TEL:1-(888)-648-8869 FAX:1-(281)227-0937

M³ Solution Center-Massachusetts

753 Forest Street, Suite 110, Marlborough, MA 01752, U.S.A.
TEL:1-(888)648-8869 FAX:1-(508)485-0782

Mitutoyo America Corporation Calibration Lab

965 Corporate Blvd., Aurora, IL 60502, U.S.A.
TEL:1-(888)-648-8869 FAX:1-(630)978-6477

Micro Encoder, Inc.

11533 NE 118th St., Kirkland, WA 98034-7111, U.S.A.
TEL:1-(425)821-3906 FAX:1-(425)821-3228

Micro Encoder Los Angeles, Inc.

16925 Gale Ave. City of Industry, CA 91745-1806 U.S.A.
TEL: 1-626-961-9661 FAX:1-626-333-8019

Mitutoyo America Corporation CT-Lab Chicago

965 Corporate Blvd., Aurora, IL 60502, U.S.A.
TEL: 1-(888)-648-8869 FAX: 1-(630)-820-3418

Canada

Mitutoyo Canada Inc.

2121 Meadowvale Blvd., Mississauga, Ont. L5N 5N1., CANADA
TEL:1-(905)821-1261 FAX:1-(905)821-4968

Montreal Office

7075 Place Robert-Joncas Suite 129, Montreal, Quebec H4M 2Z2, CANADA
TEL:1-(514)337-5994 FAX:1-(514)337-4498

Brazil

Mitutoyo Sul Americana Ltda.

Head office / M³ Solution Center / Factory
Rodovia Índio Tibiriçá 1555, CEP 08655-000 - Vila Sol Nascente - Suzano - SP - BRASIL
TEL:55 (11)5643-0040

Argentina**Mitutoyo Sul Americana Ltda.****Argentina Branch / M³ Solution Center**

Av. B. Mitre 891/899 – C.P. (B1603CQI)
Vicente López – Pcia. Buenos Aires – ARGENTINA
TEL: 54(11)4730-1433 FAX: 54(11)4730-1411

Sucursal Cordoba / M³ Solution Center

Av. Amadeo Sabattini, 1296, esq. Madrid Bº
Crisol Sur – CP 5000, Cordoba, ARGENTINA
TEL/FAX: 54 (351) 456-6251

Mexico**Mitutoyo Mexicana, S.A. de C.V.**

Industria Eléctrica No.15, Parque Industrial, Naucalpan de Juárez, Estado de México C.P.53370, MÉXICO

TEL: 52 (01-55) 5312-5612
FAX: 52 (01-55) 5312-3380

Monterrey Office / M³ Solution Center

Bvl. Interamericana No. 103, Parque Industrial FINSA, C.P. 66636 Apodaca, N.L., MÉXICO
TEL: 52(01-81) 8398-8227/8228/8242/8244
FAX: 52(01-81) 8398-8226

Tijuana Office / M³ Solution Center

Calle José María Velazco 10501-C, Col. Cd. Industrial Nueva Tijuana, C.P. 22500 Tijuana, B.C., MÉXICO
TEL: 52 (01-664) 647-5024

Querétaro Office / M³ Solution Center

Av. Cerro Blanco No.500-1, Colonia Centro Sur, Querétaro, Querétaro, C.P. 76090, MÉXICO
TEL: 52 (01-442) 340-8018, 340-8019 and 340-8020
FAX: 52 (01-442) 340-8017

**Mitutoyo Mexicana, S.A. de C.V. Querétaro
Calibration Laboratory**

Av. Cerro Blanco 500 30 Centro Sur, Querétaro, Querétaro, C.P. 76090, MÉXICO
TEL: 52 (01-442) 340-8018, 340-8019 and 340-8020
FAX: 52 (01-442) 340-8017

Aguascalientes Office / M³ Solution Center

Av. Aguascalientes No. 622, Local 15 Centro Comercial El Cilindro Fracc. Pulgas Pandas Norte, C.P. 20138, Aguascalientes, Ags. MÉXICO
TEL: 52 (01-449) 174-4140 and 174-4143

Irapuato Office / M³ Solution Center

Boulevard a Villas de Irapuato No. 1460 L.1 Col. Ejido Irapuato C.P. 36643
Irapuato, Gto., MÉXICO
TEL: 52 (01-462) 144-1200 and 144-1400