


レリーズの取付け

No.99MAG013B2




- ① レリーズ
- ② 取付け板
- ③ ストップネジ
- ④ スピンドル

—取り付け—


- I. キャップを取り外した後、お手持ちの製品のストップネジを取り外します。
- II. 取付け板をスピンドルに取り付けます。(ネジは取り外したストップネジをご使用下さい)
- III. 取付け板のネジ穴にレリーズを取り付けてください。

—注意事項—

ストップネジを取り外した際、スピンドルが下方方向に動き、歯車の噛合いが外れる恐れがありますので、スピンドルを手などで固定し、作業を行ってください。



オートストップ機構(オートストップがある機種のみ)
ねじ部を反時計回りに回転させると
オートストップが機能します。
また、ねじ部を時計回りに回転させて戻すと
オートストップが解除されます。




『リフティングレリーズご使用上の注意』

リフティングレリーズのご使用に際しましては、下記の点にご注意下さい。

- ・屈曲部分をねじったり、分解しないで下さい。
- ・束ねたり、巻いた状態での結束や、他の機器類に結束しないで下さい。
- ・出荷時に結束した状態で出荷する場合がありますが、結束を解いた状態でご使用下さい。
これらは全て、作動不良や故障の原因となります。




注意



Mitutoyo

Mounting Release

No.99MAG013B2




- ① Release
- ② Release attachment
- ③ Stop screw
- ④ Spindle

—Attaching the Release—

- I . After removing the cap on your indicator, remove the spindle stop from the indicator.
- II . Attach the release attachment to the spindle using the removed stop screw.
- III . Attach the release to screw holes on the release attachment.


—Caution—

When the stop screw is removed, the spindle may move downward and the gears may be disengaged. Hold the spindle by hand before starting work.



Auto stop mechanism (Auto stop type only)
Auto stop works by rotating the screw counterclockwise.


Also, auto stop releases by rotating the screw clockwise.



『Notes on using Lifting-Releases.』

Make sure to observe the following points when using Lifting-Releases:

- Do not twist the bend part or disassemble the Lifting-Release.
 - Do not fold the bend part or tie it in a knot.
 - Do not bundle Lifting-Releases together or roll them up and bind them.
- Also, do not bundle Lifting-Releases with other devices.



Mitutoyo